

EA02-025

FORD 10/27/03

APPENDIX N

BOOKS 11 OF 61

PART 3 OF 4

Box_Files

110947 REPLACED DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.
 93788 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
 RECALL 99S15 REQUIRED REPL BRAKE DEACTIVATOR SWITCH PER RECALL 99S15.
 CAMPAIGN COMPLETED

64438 RECALL 99S15 99S15B 0.5 0.5 RECALL
 RECALL INSTALL DEACTIVATION SWITCH AS PER RECAL
 RECALL 99S15
 PERFORM RECALL 99S15

REPLACED DEACTIVATION SWITCH AND CONNECTOR
 REPLACE SWITCH PER RECALL
 125680 CRUISE DEACTIVATION SWITCH RECAL 99S15 INSTAL CRUISE DEACTIVATION SWITCH FOR RECAL 23
 100488 PERFORM 99S15 RECALL
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 INSPECT AND REPLACE CRUISE CONTROL SWITCH
 MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

00 99S15
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 AS PER RECALL 99S15 RECALL TO INSTALL HARSHHELL CONNECTOR KIT
 COMPLETED AS PER RECALL
 99S15 PERFORMED RECAL
 RECALL 99S15 RECALL 99S15
 INSTALLED KIT PER FACTORY RECALL

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15
 COMPLETED RECALL PER INSTRUCTIONS
 RECALL PERFORMED RECAL
 RECALLED 99S15 PERFORMED
 REPLACED SWITCH

99S15 99S15

PERFORM RECALL 99S15 BLEED BRAKE SYSTEM ROAD TEST OK AT THIS TIME...
 D 99S15 WAS FOR 99S15E.
 177224 PERFORM RECALL AS PER INSTRUCTIONS

TECH REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL
 RECALL REPLACE SWITCH PER RECALL
 RECALL 99S15 PERFORMED
 102279 INSTALLED RECALL 99S15.
 27255 00 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL.....
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
 99S15B 99S15B

Box_Files

COMPLETED AS PER RECALL
PERFORM RECALL
SUPPLEMENT #1 5-88 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
RECALL 98S15 REPLACED DEACTIVATION SWITCH PER RECALL
1 REPLACED SWITCH
COMPLETED RECALL PER INSTRUCTIONS
PERFORM RECALL AS REQUIRED
98S15
PERFORMED RECALL 98S15
REPAIR CRUISE CTL PER RECALL
RECALL 98S15 INSTALLED MODIFICATION FOR CRUISE CONTROL
COMPLETED RECALL 98S15
CRUISE SWITCH 98S15 REPLACE CRUISE SWITCH AND CONNECTOR
INSTALL CRUISE CONTROL CANCEL SWITCH
REPLACED SWITCH PER FACTORY RECALL
SPEED CONTROL SWITCH 98S15 RECALL
PERFORM RECALL 98S15 INSTALL KIT
RECALL COMPLETE
PERFORMED RECALL 1

98S15 SPEED CONTROL RECALL
REPLACED SWITCH
84285 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
11260 RECALL 98S15B 0.6-HRS REPLACE SWITCH AND CONECTOR TK372
PERFORMED RECALL
82 RECALL 98S15-R&R SPEED CONTROL DEACTIVATION SWITCH

PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
98S15 INSTALL SWITCH CONNECTOR
PERFORMED RECALL TECH 1737
PERFORM RECALL
82888 RECALL 98S15B 0.5, ADMIN 0.1 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL
REPLACED DEACTIVATION SWITCH AND COVER
102009 RECALL WP40 PERFORM RECALL REPLACE BRAKE PRESSURE SWITCH
112885 PERFORM 98S15 SPEED CONTROL DEACT SWITCH
INSTALLED KIT 98S15 RECALL PERFORMED
RECALL SPEED CONTROL DEACTIVATION SWITCH

PERFORMED THE RECALL 98S15
REPLACED CRUISE CONTROL SWITCH PER RECALL
1 REPLACE CRUISE CONTROL SWITCH AS PER RECALL
PERFORMED THE RECALL 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH
91706 RECALL 98S15
PERFORM 98S15 RECALL
0894-REPLACE HARDSHELL CONNECTOR AND SWITCH
01085 PERFORM RECALL

Box_Files

42754 99S15 R&R CRUISE CONTROL SWITCH
REPLACE SWITCH AND CONNECTOR FOR RECALL RECALL
PERFORMED RECALL
TYPE 2 PROGRAM 99S15 PERFORM RECALL PER GUIDELI

RECALL 99S15 COMPLETED
REPLACED DEACTIVATION SWITCH
COMPLETED RECALL

SHORT MAY DIASABLE SPEED CONTROL OR CAUSE BRAKE LIGHT FUSE TO OPEN DISCONNECT CONNECTOR FROM CRUISE DEACTIVATION SWITCH & PROTECT END FROM COI
PERFORM RECALL

PERFORMED RECALL 99S15 CRUISE SWITCH REPLACEMENT

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONN

82052 99S15 RECALL R&R SWITCH AND CONNECTOR PER RECALL

46842 42 WP40 COMPLETE RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTION

63332 RECALL 99S15B 0.5HRS REPLACE SWITCH AND CONECTOR TK372

84448 RECALL TECH 9177 PERFORM RECALL 99S15 INSTALL SWITCH AND CONNECTOR

84284 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745

OK AND REPAIR AS PER RECALL

PERFORMED RECALL 99S15.. REPLACED THE SPEED CONTROL DEACTIVATION SWITCHES.. NOTE: SPEED CONTROL DID NOT OPERATE PRIOR TO RECALL RECOMMEND SPEE
INSTALL KIT

1 PERFORMED RECALL-REPLACE CRUISE CONTROL DEACTIVATION SWITCH

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15

24598 INSTALLED NEW SPEED DEACTIVATION SWITCH AS PER RECALL 99S15.

RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS

46051 RECALL J REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B

3098 WLM 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACED CRUISE DEACTIVATION SWITCH PER RECALL

99S15 COMPLETED

REPLACED SWITCH PER RECALL

99S15 SPEED CONTROL RECALL

NA PERFORMED REPAIRS AS PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

PERFORM RECALL

PERFORMED RECALL PERFORMED RECALL

INSPECT OR REPLACE CABLE PERFORMED RECALL 99S09

22458 CC 42 PERFROM RECALL 99S15

RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT

REPLACE CRUISE CONTROL SWITCH AS PER RECALL

PERFORMED RECALL 99S15

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

99S15 99S15 RECALL

PERFORMED RECALL

99S15 REPL SPEED CONTROL DEACTIVATION SWITCH

INSPECT AND REPALCE CRUISE CONTROL CONNECTOR

PERFORM RECALL

RECALL 99S15

RECALL 99S15 PERFORM RECALL 99S15 PER LETTER

Box Files

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
PERFORMED AS PER RECALL
PERFORMED RECALL 99S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
PERFORM RECALL
REPLACE SWITCH AND HARNESS PER RECALL
PERFORMED CRUISE RECALL
PERFORM RECALL 99S15
FACTORY RECALL COMPLETED RECALL
99S15 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL
PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK
R
REPLACE SWITCH PER RECALL INSTRUCTIONS

94993 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST
PERFORMED THE RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
39908 CC-42 RECALL TECH 8045 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15
PERFORM RECALL
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
REPLACE SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
99824 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL # 99S15
REPLACE AS PER RECALL 99S15
PREFROEMD RECALL

90921 RECALL#99S15 SPEED CONTROL DEACT SWITCH. REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL#99S15.
RECALL SPEED CONTROL DEACTIVATION SWITCH SELF APPROV FOR MISENTERED MILEAGE
PERFORM RECALL INSTALL SWITCH
COMPLETED RECALL
PERFORM RECALL -DONE
RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH
REPL SWITCH PER RECALL 99S15

COMPLETED RECALL
RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH
48673 PERFORMED RECALL 99S15
128360 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL

REPLACED SWITCH AND CONNECTOR AS PER RECALL
PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK
INSTALL UPDATED SPEED CONTROL DEACTIVATION SWITCH
31094 RECALL 99S15B 0.5, ADMIN 0.1 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL
1 REPLACED SPEED CONTROL SWITCH AND CONNECTOR
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
RECALL PERFORMED RECALL
REPLACED DISENGAGE SWITCH PER RECALL 99S15
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
79995 REPLACE DEACT SWITCH AND CONN PER RECALL 99S15
REPAIR SPEED CTL PER RECALL
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

5982-825-A 3575

Box_Files

98S15 RECALL
PERFORM RECALL

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

RECALL
RECALL 98S15 CONNECTOR MELTED WIRES MELTED AND FUSE BLOWN REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15 ALSO REPLACED BURNT W

CRUISE RECALL
RECALL 98S15
PERFORM RECALL
PERFORMED RECALL 98S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH
COMPLETE RECALL

REPL. SW.

98S15

98S15

INSTALL DEACTIVATION SWITCH KIT
1 DO RECALL 98S15

COMPLETE RECALL
120138 RECALL PERFORM RECALL 98S15 REPLACE SWIT
COMPLETE RECALL

REPLACED SWITCH PER RECALL 98S15
84208 W.. REPLACE CRUISE SWITCH PER RECALL(CC&2)

98S15
98S15
RECALL
REPAIR PER RECA

RECALL
98S15 RECALL PERFORMED
PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL, BLED BRAKES, CHECKS OK
48008 INSTALLED 98S15 SPEED CONTROL SWITCH
98S15

98S15

1 REPLACED DEACTIVATION SW AS PER RECALL 98-S-1

RECALL 98S15
98S15
98S15 RECALL
INSTALL SWITCH KIT

RECALL 98S15

98S15

COMPLETE RECALL

COMPLETE RECALL 98S15
PERFORM RECALL 98S15
COMPLETE RECALL
PERFORM RECALL 98S15 REPLACE SWITCH
PERFORM RECALL 98S15
98S15-4404 REPLACED SPEED CONTROL DEACTIVATION SWITCH

98S15

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 98S15

98S15B
RECALL
RECALL 98S15

98S15 RECALL

RECALL 98S15

PERFORM RECALL SPEED CTRL DEACT SWITCH
REPLACED CRUISE SWITCH AND CONNECTOR PER RECALL
98S15 REPLACED CRUISE DEACTIVATION REPLACED DEACTIVATION SWITCH FOR CRUISE CONTROL

Box_Files

132585 R-R SW PER RECALL
INSPECT AND REPAIR CRUISE SWITCH AND CONNECTOR
45718 W PERFORM RECALL

90090 RECALL INSTALL RECALL SWITCH AND CONTACTOR AS INSTRUCTED
1 PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR (98S15B .5) COMPLETED
REPL SWITCH PER RECALL 98S15

PERFORM RECALL 98S15- REPLACE CRUISE CONTROL PARTS

98S15 98S15 RECALL
78135 REPLACE SWITCH AS PER RECALL
RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.
PERFORMED RECALL 98S138.

COMPLETE RECALL 98S15
5400 98S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR
REPAIR AS PER RECALL 98S15.
98S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
PERFORMED RECALL
COMPLETED RECALL
REPL SWITCH PER RECALL 98S15
98S15 98S15

PERFORMED RECALL 98S15
REPLACED SWITCH AS PER RECALL
PERFORMED RECALL 98S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
007 COMPLETED RECALL 98S15
PERFORMED RECALL
70014 RECALL WP40 PERFORM RECALL REPLACE BRAKE PRESSURE SWITCH AND CONNECTOR
PERFORMED OPEN RECALL
90087 RECALL 98S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITC
98S15 98S15 RECALL

PERFORMED 98S15 RECALL
PERFORM SAFETY RECALL
98S15 RECALL PERFORMED 98S15 RECALL
UNKNOWN INSTALL CRUISE DEACTIVATION SWITCH PER 98S15
30837 .3 + .1 ADMIN. 98S15B. REPLACED DE- ACTIVATION SWITCH.
REPL KIT PER RECALL 98S15
158891 REPLACED SPEED CONTROL SWITCH AS PER RECALL # 98S15
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
PERFORMED 98S15 RECALL
PERFORM 98S15 RECALL
PERFORMED RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH
PERFORM RECALL
PERFORMED RECALL

ES92-025-R 3877

Box_Files

61575 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 99S15 99S15-REPLACED THE CRUISE CONTROL SWITCH
 RECALL INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 115517 99S15
 PERFORMED RECALL

AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL HARDSHELL SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 128063 99S15B 0.5 0.5 PERFORM 99S15
 RECALL DONE AS PER RECALL
 23448 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL
 REPLACE SWITCH AND HARD SHELL
 OPEN RECALL PERFORM RECALL
 REPLACE DEACTIVATION SWITCH
 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL
 99S15 99S15
 COMPLETED RECALL 99S15
 99S15 INSTALLED REPAIR KIT AS PER RECALL
 COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH
 19C733 42 ROAD TEST TO VERIFY, EVAC & RECHARGE TO REMOVE EXCESS OIL REPLACE ORFICE & PRESS SWITCH & BLEND DOOR ACT & PET.OMETER
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 RECALL 99S15
 161849 RECALL W INSPECT REPLACE DEACTIVATOR SWITCH AND CONNECTOR PER 99S15 511 1166
 REPLACED CRUISE DEACTIVATION SWITCH

RECALL 99S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 68548 PERFORM RECALL 99S15
 PERFORME 99S15
 86632 WARRANTY, PERFORMED SPEED CONTROL SWITCH RECALL AS PER RECALL INSTR.
 REPLACE SPEED CONTROL SWITCH
 PERFORMED RECALL 99S15
 99S15 RECALL INSTALL SWITCH AND HARDSHELL CONNECTOR
 1 RECALL 99S15
 118818 PERFORM 99S15 RECALL, REPLACE DEACTIVATION SWITC
 38448 PERFORMED RECALL 99S15.
 PERFORMED RECALL 99S15
 REPLACE CRUISE DEACTIVATION SWITCH
 RECALL 99S15 REPLACE DEACTIVATION SWITCH
 PERFORM RECALL 99S15 --REPLACE CRUISE CONTROL SWITCH
 RECALL 99S15 RECALL
 SPEED CONTROL SWITCH 99S15 RECALL

INSTALL HARDSHELL CONNECTOR
 43395 99S15B .5 REPLACE SWITCH AND HARDSHELL
 99S15 99S15
 RECALL 99S15

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .5
 REPL SWITCH PER RECALL 99S15

Box_Files

REPL SWITCH PER RECALL 99S15

99S15B 0.5

COMPLETED RECALL 99S15

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

REPLACED DEACTIVATION SWITCH PER 99S15 RECALL

84994 DID RECALL # 99S15

X

PERFORMED RECAL

106221 INSPECTED AND REPLACED THE SPEED DEACTIVATION SWITCH AS PER RECALL 99S15.

1 REPLACE CRUISE CONTROL SWITCH AS NEEDED

B 5 INSTALLED SWITCH AND WIRING 7548

SWITCH AND WIRING CONNECTOR 1

1 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION

201433 RECALL 99S15 RPL BRAKE PRESSURE SW AND CNCTR PER 99S15

REPLACE SWITCH PER RECALL

REPLACE SPEED CONTROL SWITCH

99S15

SPEED CONTROL RECALL

RECALL

99S15 REPLACE C-C SW

99S15 RECALL

99S15 RECALL INSTALLED SPEED CONTROL CABLE PER RECALL

99S28 WHILE REMOVING THE DEACTIVATOR SWITCH THE THREADS PULLED OUT OF THE METERING VALVE THE VEHICLE NEEDS A NEW VALVE INSTALLED NEW SWITCH AS PE

PERFORMED RECALL

82265 RECALL W REPLACE SWITCH AND PLUG GA

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

REPLACED HARD SHELL AND SWITCH AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

94168 INSTALLED THE BRAKE INPUT SWITCH FOR THE SPEED CONTROL SYSTEM PER RECALL NOTICE

REPLACED SC DEACTIVATION SWITCH 99S15

REPLACED DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL 99S15

REPL SWITCH PER RECALL 99S15

PERFORM RECALL 99S15

PERFORMED RECALL 99S15

RECALL

99S15 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITC

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITC

RECALL

RECALL COMPLETE

99S15

REPLACE DEACTIVATION SWITCH

RECALL 99S15

PERFORM RECALL 99S15

RECALL

RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL

PERFORMED RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH 99S15

RECALL INSTALL NEW DEACTIVATION SWITCH

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

99S15

99S15 RECALL

OWNER NOTIFICATION

CRUISE CONTROL RECALL 99S15

2002-02-01 3:17:19

Box_Files

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS

99S15 COMPLETED 99S15 COMPLETED

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACED SPEED CONTROL

RECALL PERFORM RECALL .RRENEW SWITCH AND CONNECTOR

99S15 PERFORM RECALL 99S15

1 1 REPL DEACTIVATION SWITCH AND CONNECTOR

1 REPLACED DEACTIVATION SWITCH AS PER RECALL 99S15

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

RECALL 99S15

9 PERFORM RECALL 99S15

14882 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST

PERFORMED RECALL 99S15

PERFORM RECALL

RECALL 99S15 RECALL 99S15 COMPLETED.

99S15 SPEED CONTROL RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS

VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK

RECALL 99S15 RECALL

REPL SWITCH AND CONNECTOR REPAIR AS PER RECALL 99S15

REPLACED KIT PER RECALL

PERFORMED RECALL

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN

99S15 REPLACE DEACTIVATOR SWITCH AND CONNECTOR AS PER RECALL

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH

99S15B PERFORMED RECALL

PERFORM RECALL 99S15

RECALL 99S15 PERFORM RECALL 99S15

RECALL COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACE DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL 99S15

PERFORM RECALL 99S15

42249 W 762 PERFORMED RECALL 99S15

PERFORM RECALL

INTERM REPAIR REMOVED TAPE SECURE THE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15E 0 3 HRS PERMANENT REPAIR REPLACED SP EED CON

REPLACE DEACTIVATION SWITCH FOR CRUISE CONTROL

REPLACE DEACTIVATION SWITCH. MILEAGE WAS VERIFIE

REPLACED SPEED CONTROL SWITCH AND CONNECTOR

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

REPLACE DEACTIVATION SWITCH

1 INSTALLED SWITCH AND CONNECTOR

REPL SWITCH PER RECALL 99S15

107836 RECALL 99S15 PERFORM RECALL 99S15 AS PER TSB TEST DRIVE 4 MILES O. K

Box_Files

REPLACED CRUISE DEACTIVATION SWITCH
PERFORM RECALL 99S15
99S15 99S15 COMPLETED

89054 RECALL WP340 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15
OPEN RECALL PERFORM RECALL
CRUISE DEACTIVATION SWITCH, PERF RECALL AS PERSCRIBED ROAD TESTED OK

X RECALL

1 INSTALLED SWITCH AND WIRE CONNECTOR
PERFORMED AS PER RECALL
REPLACED SWITCH AND CONNECTOR AS PER RECALL
RECALL RECALL DONE
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CKT THAT MAY RESULT IN AN UNDERHOOD FIRE. INTERIM REPAIR-REMOVE, TAPE AND SECURE SPEED CONTR
CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA
99S15 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15
PERFORM RECALL INSTALL SWITCH
118884 RECALL 99S15B 0.5 0.5 RECALL
REPLACED SWITCH
PERFORM RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
99S15 COMPLETED 99S15 COMPLETED
PERFORMED THE RECALL 99S15
PERFORMED RECALL 99S15
99S15 PERFORMED RECALL
RECALL COMPLETED
COMPLETED RECALL 99S15

161436 RECALL W/ PERFORMED RECALL 99S15 REPLACED BRAKE DEACTIVATION SWITCH AND CONNECTOR
PERFORM RECALL
1 REPLACED SPEED CONTROL DEACTIVATION SWITCH
1 PERFORMED RECALL
RECALL 99S15 RECALL, REPLACE SWITCH
75203 99S15 WARR REPLACED SWITCH AND CONN
PERFORMED RECALL
PERFORMED RECALL
SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACT. SWITCH AS DIRECTED
PERFORMED 99S15 RECALL

JS PERFORM RECALL REPL DEACTAVITON SWITCH AND CONNECTOR
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
REPLACED DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH. DIFFERENCE OF ONE MILE FOR ROAD TESTING.
SERVICE REPLACED SWITCH AND BLEED BRAKES PER RECALL
REPLACED DEACTIVATION SWITCH PER RECALL

8902-025-4 3901

Box_Files

RECALL 99S15 REPLACE C-C SW

PERFORMED THE RECALL 99S15

PERFORM SPEED CONTROL RECALL

PERFORM RECALL 99S15

PER RECALL RPLC SPEED CONTROL DEACTIVATR SW PER RECALL & HARD SHELL

1 RECALL 99S15 COMPLETED

MILEAGE ENTERED IS CORRECT. ON 8/2 VEHICLE HAD 6993 MILES, THEN ON 7/28 IT HAD 71004. DONT UNDERSTAND PROBLEM ?

99203 99S15 RECALL ADD ON OKD BY R.A.B. INSPECT AND INSTALL DEACTIVON SWITCH AND HARD SHELL AS PER 99S15 INSTRUCTIONS

RECALL 99S15 PERFORMED RECALL 99S15

SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 99S15

PERFORMED THE RECALL 99S15

CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION SWITCH AS

PERFORM RECALL 99S15

42505 RECALL 99S15 W 99S15B 0.5 HRS ADMS 0.1 HRS REPLACE SPEED CONTROL DEACTIVATION SWITCH AND C ONNECTER PER RECALL 99S15-B

RECALL 99S15

OPEN RECALL PERFORMED RECALL 99S15

99S15 RECALL 99S15 RECALL

RECALL RECALL

INSTALLED NEW SPEED CONTROL SWITCH AS PER RECALL 99S15 ROAD TEST NORMAL . TECH 408-05845

RECALL INSTALL SPEED CONTROL DEACTIVATION SWITC

REPLACE DEACTIVATION SWITCH PER RECALL

119408 RECALL 99S15 INSTALL SPEED CONTROL SWITCH AND HARNESS

REPLACE DEACTIVATION SWITCH.

REPLACED DEACTIVATION SWITCH

99S15B 99S15B

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

REPLACE SPEED CONTROL SWITCH AS PER RECALL 99S15

RECALLED 99S15 PERFORMED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15 SERVICE WRITER FORGOT TO ADD MILEAGE FROM REPLACEMENT SPEEDOMETER

RECALL PERFORM RECALL

CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA

1 COMPLETED RECALL 99S15

99774 RECALL 99S15B-0.5 HRS PERFORMED RECALL 99S-15 TK 8276

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15

RECALL 99S15 - B - RECALL

PERFORM RECALL 99S15

RECALL 99S15 - B - RECALL

RECALL CRUISE CONTROL RECALL 99S15

99772 RECALL REPLACED SWITCH AND TEST DROVE WORKS NORMAL

PERFORMED THE RECALL 99S15

PERFORMED RECALL

REPLACED CRUISE DEACT SWITCH

PERFORM RECALL 99S15

PERFORM SPEED CONTROL RECALL

10002-025-9 23632

Box_Files

REMOVED & REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 PERFORMED RECALL 99S15
SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
REPLACED DEACTIVATION SWITCH PER RECALL
RECALL 99S15 99S15
DIAG REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 99S15
1 PERFORMED RECALL 99S15
PERFORM RECALL 99S15 AS PER TECHNICAL INSTRUCTIO

PERFORM RECALL 99S15
RECALL 99S15 REPLACE C-C SW
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST LE
99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL
PER RECALL PERF RECALL
99S15 - SPEED CONTROL SWITCH 99S15 - REPLACE SWITCH AND CONNECTOR

REPLACED CABLE
RECALL 99S15 RECALL COMPLETE
RECALL 99S15 REMOVED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY AS PER RECALL 99S15
INSTALLED SPEED CONTROL DEACTIVATION SWITCH
RECALL REPLACE CRUISE SWITCH CONNECTO,
99S15 99S15

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL
RECALL 99S15 RECALL
REPL SWITCH PER RECALL 99S15
PERFORMED RECALL 99S15, REPL DEACTIVATION SWITCH
42099 PERFORM RECALL 99S15 INSTALL SWITCH
REPLACE SPEED CONTROL SWITCH PER RECALL
PERFORMED RECALL
MODIFIED PER RECALL
82283 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH
INSTALL DEACTIVATION SWITCH
COMPLETED RECALL
PERFORMED RECALL 99S15 F
RECALL PERFORM RECALL, INSTALL NEW CRUISE CONTROL DEACTIVATION SWITCH
1 PERFORMED RRECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
REPLACE DEACTIVATION SWITCH AS PER 99S15
1 COMPLETED RECALL 99S15
INSTALL DEACTIVATION SWITCH 99S15 RECALL PER FORD INSTRUCTIONS
COMPLETED AS PER RECALL
1 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH.
136888 RECALL 99S15 R/R CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15
81957 REPLACED DEACTIVATION SWITCH 3314
115- CRUISE SWITCH RECALL - 99S15 - REPLACE CRUISE BRAKE SWITCH AND CONN PER 99S15

COMPLETED RECALL INSTALL SW
PERFORMED RECALL 99S15

INSTALLED SWITCH PLUG PER RECALL 99S15
 RECALL 99S15 99S15 REPLACE C-C SW
 RECALL 99S15 RECALL 99S15
 30413 INSTALLED RECALL KIT 99S15 OPERATION OK
 99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
 REPLACED SPEED CONTROL SWITCH PER RECALL
 RECALL COMPLETED
 PERFORM RECALL
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 1 COMPLETED RECALL
 FDF RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 RECAL PERFORMED SPEED CONTROL DEACTIVATION SWTIC
 PERFORM RECALL 99S15
 55385 RECALL WA PERFORM RECALL REPLACE SWITCH
 DOES NOT OPERATE PROPERLY ANTI-LOCK BRAKE SYSTEM - DIAGNOSIS
 PERFORMED RECALL 99S15
 REPL SWITCH PER RECALL 99S15
 PERFORM RECALL 99S15
 1 PERFORMED RECALL
 PERFORMED THE RECALL 99S15

PERFORM RECALL 99S15
 99S15 99S15 RECALL
 REPLACE SWITCH FOR SPEED CONTROL PER RECALL 99S1
 COMPLETE RECALL
 PERFORM RECAL
 REPLACED SPEED CONTROL SWITCH
 SPEED CONTROL DEACTIVATION SWITCH REPLACED DEACT. SWITCH AS DIRECTED
 RECALL PERFORMED RECALL, REPLACED DEACTIVATION SWITCH AND CONNECTOR
 RECALL REPLACE SWITCH M
 RECALL 99S15 99S15
 REPLACED SWITCH AND CONNECTER PER RECALL

RECALL COMPLETED
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTION
 RECALL COMPLETE
 REPLACED SC DEACTIVATION SWITCH 99S15
 PERFORMED RECALL 99S15
 99S15 REPLACE SWITCH
 99S34 RECALL 5 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15B
 RD TEST, RUN ELEC TRAN DIAG, NO CODES, R&R TRAN PAN, REPLACED EPC SOLENOID AND BRACKET, R&R V-B & O-H, FLUSHED SYSTEM, RD TEST OK
 REPLACED DEACTIVATION SWITCH AND HARD SHELL
 CRUISE SWITCH RECALL REMOVED AND REPLACED CRUISE SWITCH RECALL PART.
 PERFORMED RECALL AS PER INSTRUCTIONS
 RECALL 99S15 COMPLETED
 PERFORM RECALL
 REPLACE DEACTIVATION SWITCH AS PER 99S15
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.
 PERFORM RECALL 99S15

Box_Files

99S15E PERFORMED RECALL - SPEED CONTROL SWITCH
 OPEN RECALL PERFORM RECALL
 99S15 99S15
 PERFORMED 99S15 RECALL, REPLACED DEACTIVATOR SWITCH & CONNECTOR
 REPLACED SWITCH AND CONNECTOR
 91000 CC 42 99S15B 0.5- ADMIN 0.1 REPLACED SWITCH AND CONNECTOR
 SPEED CONTROL DEACTIVATION SWITCH REPLACED SWITCH
 PERFORMED RECALL PER FACTORY
 1 PERFORM RECALL
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 REPLACE DEACTIVATION SWITCH
 RECALL 99S15 INSTALLED SWITCH
 PERFORM RECALL 99S15
 99S15 99S15-REPLACE CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR ASSY
 PERFORM SAFETY RECALL
 116819 REPLACE SWITCH AND CONNECTOR
 49809 INSPECTED AND INSTALLED DEACTIVATION SWITCH AND PARTS PER RECALL
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.
 - MODIFY PER RECALL 99S15
 99S15 99S15 REPLACE THE CONN AND SWITCH
 99S15, REPLACED HARD SHELL CONN PER RECALL
 REPLACED DEACTIVATION SWITCH
 99S15 SPEED CONTROL RECALL
 REPLACE SW. PER RECALL
 RECALL 99S15 INSTALLED DEACTIVATION SWITCH PER RECALL
 RECALL 99S15 REPLACED CABLE
 RECALL RECALL
 42200 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15
 REPLACE DEACTIVATION SWITCH
 78520 RECALL WARR TECH 495 PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL, RECHECKED OK
 1 CAMPAIGN COMPLETED.
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 RECALL 99S15 RECALL 99S15 REPLACE SWITCH AND PLUG

 PERFORMED RECALL 99S15
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 COMPLETED RECALL 99S15B 1
 PERFORMED RECALL
 RECALL 99S15 REPLACE DEACTIVATOR SWITCH PER RECALL
 PERFORMED THE RECALL 99S15

 PERFORMED RECALL AS PER FORD SPECIFICATIONS
 RECALL 99S15. REPLACED SPEED CONTROL DEACTIVATION SWITCH IN AW RECALL 99S15.
 PERFORMED RECALL 99S15 SPEED CONTROL
 CABLE PERFORM RECALL 99S15
 APPLIED RECALL 99S15
 1 PER RECALL INSTALL CRUISE CANCEL SWITCH AND CONNECTOR RETEST OK
 PERFORMED RECALL

ES02-020-A 0305

Box_Files

SPD CTRL DEACTIVATION SW REPLCMT/PERFORMED RECALL 99S15
 RECALL PERFORMED RECALL
 99S15B .5 HRS ADMIN .1 HRS COMPLETED RECALL 99S
 PERFORMED RECALL 99S15

.9 RECALL
 71646 WARR REPLACE SWITCH AS PER RECALL 99S15

99S15 RECALL 99S15 REPAIR AS PER RECALL
 48914 REPLACE SPEED CONTROL SWITCH
 RECALL 99S15 REPLACE C-C SW
 SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD MOTOR CO. F
 99S15 INSTALL SWITCH AND CONN
 1 COMPLETED RECALL 99S15
 RECALL 99S15 COMPLETED RECALL 99S15 (SPEED CONTROL SWITCH) HAS BEEN COMPLETED
 RECALL 99S15 REPLACED PLUG AND SENSOR AS PER RECALL 99S15

DO THE RECALL
 REPLACE SPEED CONTROL SWITCH PER RECALL
 OPEN RECALL PERFORM RECALL
 RECALL 99S15 REPLACED CRUISE CONTROL SWITCH
 RECALL PERFORMED RECALL
 RECALL 99S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST,
 COMPLETED RECALL 99S15-REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 99S15 REPLACE SPEED CONTROL DEACTIVATION AND HARD-SHELL CONNECTOR
 REPLACED SPEED CONTROL SWITCH.
 PERFORM RECALL 99S15
 1 PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
 99S15-CRUISE RECALL 99S15-CRUISE RECALL

PERFORMED RECALL 99S15 CRUISE SWITCH
 99S15B .5 ADMIN .1 INSTALL CRUISE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.
 99S15, REPLACED CRUISE DE-ACTIVATION SW
 INSTALL SWITCH PER RECALL

PERFORMED RECALL

104095 PERFROM RECALL 99S 15
 REPLACED SC DEACTIVATION SWITCH 99S15

REPLACE CRUISE CONTROL SWITCH
 111358 PERFORM RECALL 99S15 INSTALL SWITCH-CONN KIT
 RECALL 99S15; PERFORM RECALL 99S15;REPL BRK-PRESS. SWITCH;
 REPLACE SPEED CONTROL SWITCH
 COMPLETED RECALL
 INSTALL SWITCH 99S15

Box_Files

PERFORMED RECALL 99S15

PERFORM RECALL PER FORD SPECS

REPLACE SWITCH AND CONNECTOR PER RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 99S15 REPLACED SWITCH.

RECALL 99S15 99S15 INSTALL CRUISE DEACTIVATION SWITCH PER RECALL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONN

99S15 R&R SPEED CONTROL DEACTIVATION SWITCH

49998 COMPLETED 99S15 CRUISE SWITCH

DEACTIVATION SWITCH AND CONNECTOR. REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

COMPLETED RECALL 99S15

1 COMPLETE RECALL 99S15

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

RECALL 99S15 REPLACED SWITCH AND CONNECTOR FOR CRUISE CONTROL

112963 REPLACE SWITCH AND CONNECTOR AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

99038 99S15 99S15E .3 PERFORMED 99S15 REPLACED DEACTIVATION SWITCH

RECALL 99S15 RECALL COMPLETE

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

89677 RECALL WARR TECH 495 PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH PER RECALL, REPLACED CONNECTOR PER RECALL RECHECKED OPERATION

99S15 RECALL 99S15 RECALL, REPLACED DEACTIVATION SWITCH AND CONNECTOR

SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE DEACTIVATION SWITCH PER 99S15

REPLACE SWITCH PER 99S15. BLEED BRAKE

R&R BRAKE SWITCH & HARD SHELL BLEED SYSTEM PER RECALL

71887 INSTALLED CRUISE SWITCH

R&R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S-15

1 REPLACE CRUISE CONTROL SWITCH 1

39870 REPLACE SWITCH AND CONNECTOR PER RECALL

COMPLETED RECALL AS PER LETTER

120243 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR

PERFORM RECALL

PERFORMED RECALL 99S15

RECALL 99S15 REPLACE SWITCH AND CONNECTOR

REPL SWITCH PER RECALL 99S15

COMPLETED RECALL 99S15

INSTALLED CRUISE DEACTIVATION SWITCH.

REPL SWITCH PER RECALL 99S15

SERVICED AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

PERFORMED RECALL

99S15 99S15 SPEED CONTROL SWITCH RECALL

RECALL 99S15 REPLACE SPEED CONTROL SWITCH

PERFORM RECALL AS PER NOTICE

Box_Files

F RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
A DONE
PERFORMED RECALL 98S15
RECALL COMPLETE

REPLACED THE SWITCH PER RECALL 98S15
RECALL COMPLETE
DEACTIVATION SWITCH 98S15
RECALL COMPLETE
COMPLETED RECALL AS PER LETTER
PERFORMED RECALL REPAIR
PERFORMED RECALL 98S15
REPLACED CRUISE KIT
98S15 PERFORM RECALL 98S15
PERFORMED RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 98S15B TIME .3 PERFORM RECALL 98S15 AS PER INSTRUCTIONS
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD MOTOR CO. F
OPEN RECALL PERFORM RECALL
98S15 98S15 RECALL
COMPLETED RECALL 98S15
WE PERFORMED RECALL 4237
INSTALL SWITCHBLEED AS PER RECALL 98S15

RECALL 98S15 - B - RECALL
1 INSTALL CRUISE CONTROL KIT, RECALL 98S15
REPLACED SWITCH CONNECTOR
RECALL COMPLETED
FD RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
PERFORM RECALL 98S15
1 REPLACED SWITCH

124802 98S15 PERFORMED RECALL AS PER INSTRUCTIONS REPLACED SWITCH
REPLACED SWITCH AND CONNECTOR
PERFORM RECALL

REPLACE SWITCH AND HARNESS PER RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
11583 RECALL 98S15 INSTALL NEW CONNECTOR AND SWITCH

PERFORMED RECALL
RECALL SPEED CONTROL DEACTIVATION SWITCH
PERFORM RECALL 98S15
114176 REPLACE SWITCH PER RECALL
RECALL 98S15 CRUISE CONTROL REPLACE SWITCH AND CONT. PER RECALL RECK OK
RECALL 98S15
51707 RECALL 98S15 DONE
REPLACE SPEED CONTROL CABLE

ER02-925-A-3386

REPLACE SWITCH

PERFORM RECALL AS PER NOTICE

PERFORMED RECALL 99S15

1 INSTALL SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

PERFORMED RECALL 99S15-INSTALL SWITCH

149993 RECALL REPLACE CRUISE CONTROL SWITCH AND CONNECTOR

PERFORMED 99S15 RECALL REPLACED SWITCH

REPLACED SWITCH ASSEMBLY PER RECALL

REPLACE SWITCH

RECALL SPEED CONTROL DEACC SWITCHREPLACE CRUISE SWITCH

COMPLETED RECALL 99S15-INSTALLED DEACTIVATION SWITCH.

INSTALL SWITCH PER RECALL

RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH INSTALL SWITCH AND CONNECTOR

SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD MOTOR CO. F

ONP RECALL 99S15

RECALL 99S15 INSTALL CRUISE DEACTIVATION SWITCH PER 99S15

PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15 CRUISE CONTROL SWITCH

COMPLETED RECALL PER INSTRUCTIONS

RECALL 99S15

RECALL 99S15 REPL SWITCH AND CONNECTOR

99S15B

REPLACE CRUISE DEACTIVATION SW

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

RECALL 99S15

RECALL 99S15

49929 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL

REPLACED SWITCH AND CONNECTOR

DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

RECALL 99S15

99S15

99S15 RECALL

99S15 REPLACED SWITCH AND CONNECTOR

RECALL

RECALL

RECALL

RECALL

113587 RECALL WARR REPLACE SPEED CONTROL DEACTIVATOR SWITCH AND CO NNECTOR PER RECALL

COMPLETE RECALL 99S15

99S15E

PERFORMED RECALL AS PER RECALL

COMPLETED RECALL

REPLACED LEAKING THERMASTAT AND GASKET COOLING F

SOP HERE REPLACE BRAKE SWITCH AND CONN PER RECA

99S15

99S15

PERFORMED RECALL

RECALL

99S15 COMPLETED

99S15

99S15

OPEN RECALL

PERFORM RECALL

REPL SWITCH PER RECALL 99S15

RECALL 99S15

INSTALL SWITCH

RECALL 99S15 PERFORMED RECALL 99S15

1 REPLACED CRUISE CONTROL SWITCH PER RECALL
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 PER RECALL REPL DEACTIVATOR SWITCH
 PERFORM RECALL INSTALL SWITCH
 116888 AS PER RECALL
 1 REPLACED CRUISE SWITCH AND CONNECTOR
 67984 REPLACE SWITCH AND WIRES PER RECALL AND BLEED BRAKES
 INSTALLED NEW SWITCH PER RECALL
 COMPLETE RECALL 99S15
 REPLACE SWITCH PER RECALL
 SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 99S15
 PERFORM RECALL
 RECALL PERFORM RECALL # 0636
 PERFORM RECALL
 PERFORMED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 99S15-INSTALL SWITCH
 REPLACE PARTS PER RECALL
 REPLACE SWITCH PER RECALL
 PERFORM RECALL 99S15 RECHECK OK 1
 COMPLETED RECALL PER NOTIFICATION.

REMOVE AND INSTALL RECALL 99S15 CRUISE CONTROL TECH.23856
 55802 REPLACED SPEED CONTROL SWITCH, S-2 8274
 REPLACED DEACTIVATION SWITCH PER RECALL
 99S15 99S15 PERFORM RECALL
 INSTALLED NEW DEACTIVATION SWITCH AND CONNECTOR
 PERFORMED RECALL HAD TO REPLACE PROPORTIONING VALVE REPLACED DUE TO BEING FROZEN IN SWITCH A TIME TO REPLACE VALVE
 PERFORM RECALL INSTALL SWITCH
 RECALL 99S15 RECALL 99S15
 REPLACE DEACTIVATION SWITCH 1
 REPLACE THE SPEED CONTROL SWITCH PER RECALL 99S1
 108801 REPLACED SPEED CONTROL SWITCH AS PER RECALL
 PERFORMED RECALL
 REPLACE SWITCH PER RECALL
 RECALL RECALL 99S15 REPLACE SPEED DEACTIVATION KIT
 PERFORMED RECALL 99S15-INSTALL SWITCH
 76747 RECALL 5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B
 REPLACE DEACTIVATION SWITCH AND CONNECTOR
 12 REPLACE CRUISE SWITCH PER RECALL
 73660 REPLACE DEACTIVATION SW AND CONNECTOR OK OF ALL OK
 RECALL 99S15 REPLACE C-C SW

VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK
 PERFORM RECALL
 COMPLETED RECALL INSTALLED DEACTIVATION SWITCH.

REPL SWITCH PER RECALL 99S15

Box_Files

REPLACED CRUISE SWITCH
 SPD CTRL DEACTIVATION SW REPLCMINTPERFORMED RECALL 99S15
 PERFORMED RECALL 99S15
 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACED CONTACT SWITCH AND SWITCH CONVERTER
 DEACTIVATION SWITCH 99S15
 99S15 PERFORM 99S15
 99S15 99S15

PERFORM RECALL 99S15
 99S15 RECALL 99S15 REPAIR AS PER RECALL
 PERFORM CAMPAIGN 99S15, SPEED CONTROL DEACTIVE SWITCH REPLACED SPEED CONTROL SWITCH
 1 REPLACE SWITCH
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 1 -REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL-
 102228 REPLACED SWITCH
 RECALL COMPLETE
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 41490 PERFORMED RECALL 99S15 3728
 84784 PERFORMED SPEED CONTROL SWITCH RECALL
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 99S15 RECALL 99S15 RECALL 99S15
 RECALL
 99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL
 PERFORMED CRUISE CONTROL SWITCH RECALL 99S15 .3, .1 ADMIN.
 91842 PERFORM 99S15 RECALL
 PERFORM RECALL
 PERFORM RECALL 99S15
 REPL CRUISE CONTROL SW AND WIRE CONNECTOR AND B L EED BRAKE FLUID. ROAD TEST OK PER RECALL
 PERFORMED RECALL
 REPLACE DE-ACTIVATION SWITCH PER RECALL 99S15
 1 PERFORMED RECALL 99S15
 99S15 RECALL 99S15 REPLACE CONNECTOR AND SWITCH AS PER RECALL
 RECALL RELACED DEACTIVATION SWITCH PER RECALL
 PERFORMED CRUISE CONTROL RECALL
 REPLACE DEACTIVATION SWT. PER RECALL
 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 99S15.
 99S15 RECALL
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
 PERFORM RECALL INSTALL SWITCH
 REPLACED DEACTIVATION SWITCH - PER RECALL
 1 99S15B .5 ADMIN .1
 RECALL 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 82933 PERFORM 99S15 RECALL REPLACE DEACTIVATION SWITCH.
 DO RECALL 99S15 PUT IN NEW SW AND COND

VERIFY VEHICLE FOR RECALL,INSTALL RECALL KIT

EP902-025-9 23971

Box_Files

PERFORM RECALL
RECALL COMPLETED
REPLACE CRUISE CONTROL SWITCHES PER RECALL 98S15
REPLACED DEACTIVATION SWITCH
1 TECH PERFORMED CRUISE DEACTIVATION SWITCH RECALL 98S15
1 REPLACED SPEED CONTROL SWITCH
34720 98S15 RECALL COMPLETED
PERFORM RECALL

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5
A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL PERFORMED 1
REPLACE DEACTIVATION SWITCH AS PER RECALL
PERFORM 98S15 RECALL

98S15 RECALL 98S15 RR BRAKE SWITCH AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL
COMPLETED REPLACED THE SPEED CONTROL DEACTIVATION SWITCH
57181 98S15

NA 98S15 INSTALLED SWITCH

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5
SAFETY RECALL 98S15 PERFORMED SAFETY RECALL 98S15 REPLACED CRUISE CONTROL
REPAIR PER RECALL

PERFORMED BY AND CLOSED BY ANOTHER DEALERSHIP BUT STILL OPEN WHEN WE HAD VEH

REMOVE TAPE AND SECURE LABOR OF 98S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 98S15B .5 REMOVED TAPED AND SECURED SPEED CONTROL
REPLACE SWITCH PER RECALL
RECALL SPEED CONTROL DEACTIVATION SWITCH

65251 RECALL 0.5 REPLACED BRAKE PRESSURE SWITCH AND CONNECTOR 98S15B

98S15 REPLACE DEACTIVATION SWITCH

PERFORM RECALL INSTALL SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

107063 RECALL 98S15B 0.5L PERFORMED RECALL REPLACED SWITCH AND CONNECTOR

INSTALLED SWITCH PER RECALL

1 REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15B

COMPLETE RECALL THIS IS NOT A REPEAT REPAIR WITH 035803 BECAUSE THAT REPAIR WAS FOR INSPECTION ONLY
RECALL PERFORMED

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH PERFORMED SWITCH CAMPAIGN

98S15B PERFORMED RECALL

RECALL 98S15 COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

98S15

98S15 RECALL COMPLETE RECALL

93502 REPLACE SWITCH AS PER RECALL

126387 RECALL 98S15 PERFORM RECALL 98S15 REPLACE SWITCH AND HARD SHELL CONNECTOR

Box_Files

99S15 REPLACE DEACTIVATION SWITCH
 OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15
 RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT
 TECH REPLACE SWITCH AS REQUIRED
 99S78 RECALL 99S15
 PERFORMED RECALL, SPEED CONTROL DEACTIVATION SWITCH
 UNKNOWN RECALL COMPLETE
 1 COMPLETED RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 INSTALLED DEACTIVATION SWITCH AS PER RECALL
 PERFORM SPEED CONTROL RECALL 99S15
 RECALL REPLACED DEACTIVATION SWITCH AND HARDSHELL PER RECALL

 108867 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS RECALL 99S15
 RECALL INSTALLED SPEED CONTROL DEACTIVATION SWITCH

 REPLACED SC DEACTIVATION SWITCH 99S15
 SERVICED AS PE RECALL E
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
 CK BRAKE SYSTEM BRAKE SWITCH IS LEAKING AT THREADS REPLACE SWITCH AND BLEED SYSTEM
 RECALL 99S15B RECALL 99S15B
 1 INSTALLED RECALL SWITCH
 RECALL PERFORM RECALL PER PROGRAM 99S15, DEACTIVATION SWITCH
 RECALL 99S15 PERFORMED RECALL AS PER FORD
 COMPLETED 99S15
 RECALL DID RECALL
 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH REPLACEMENT
 99S15 REPLACE SWITCH AND CONNECTOR PER RECALL
 PERFORM RECALL
 INSPECTED CRUISE CONTROL OPERATION AND REPLACED REAR BRAKE RELEASE KIT AS PER RECALL AS NEEDED FOR REPAIRS

 1 PERFORMED RECALL
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 COMPLETE RECALL 99S15
 NAC 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 99S15B RECALL 99S15B RECALL
 REPLACE SPEED DEACTIVATION SWITCH
 PERFORMED RECALL AS BY FACTORY PERFORMED RECALL
 PERFORM RECALL 99S15
 PERFORM RECALL 99S15
 RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL AS PER 99S15
 RECALL 99S15 COMPLETED
 71275 REPLACED SPEED CONTROL DEACTIVATION AS TO RECALL 99S15
 1 RECALL COMPLETE
 RECALL COMPLETED
 REPLACE CRUISE CONTROL SWITCH AND CONN, SHELL, BLEED REAR BRAKES
 COMPLETED 99S15

6982-625-9 2300

Box_Files

COMPLETED RECALL
RECALL COMPLETED
81788 SPEED CONTROL DEACT SWITCH RECALL WARR COMPLETED
PERFORMED RECALL
98S15 REPL SPEED CONTROL DEACTIVATION SWITCH
1 REPLACE SWITCH PER RECALL
INSTALL DEACTIVATION SWITCH PER RECALL 98S15 98S15B .50
98S15B 0.5, TOTAL HRS 0.5, PERFORMED RECALL 98S15, REPLACED SPEEDCONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR.
POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH INSPECTED VEHICLE - HAS ONLY VACUUM OPERATED SYSTEM
REPLACED CRUISE DEACTIVATION SWITCH
PERFORM RECALL 98S15.
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S
AS PER RECALL REPLACED SPEED CONTROL SWITCH
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
98S15 98S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
PERFORM RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH
INSTALL SWITCH AND HARD SHELL
RECALL 98S15
PERFORM RECALL
CHECKED OASIS INSTALLED HARDSHELL CONNECTOR AND SWITCH

98S15 RECALL SPEED CONTROL DEACTIVATION SWITCH
RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
INSTALLED SWITCH AND CONNECTOR
POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH PERFORMED RECALL REPLACE CRUISE CABLE
RECALL 98S15
PERFORMED RECALL 98S15 B
71704 RECALL PERFORM 98S15
PERFORMED SPEED CONTROL RECALL
1 REPLACED PART PER RECALL
PERFORM RECALL
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
17378 INSPECTED AND REPLACED THE SPEED DEACTIVATION SWITCH AS PER RECALL 98S15.
RECALL COMPLETE
1 PERFORMED SAFETY RECALL 98S15.
PERFORMED THE RECALL 98S15
PERFORMED 98S15 RECALL

125784 98S15 INSTALL CRUISE SWITCH AND CONNECTOR PER RECALL

PERFORM RECALL 98S15
RECALL 98S15 RENEW CRUISE DEACT SWITCH
1 98S15 RECALL INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.
PERFORMED RECALL PER SPECS
COMPLETED RECALL

SPEED CONTROL SWITCH 98S15 RECALL
UNKNOWN RECALL COMPLETE

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S
PERFORMED RECALL 98S15 SPEED CONTROL SWITCH
125046 98S15 W REPLACED DEACTIVATION SWITCH
98S15 REPLACE CRUISE CONTROL SWITCH PER RECALL
REPLACE CRUISE DEACTIVATION SWITCH AS PER RECALL
PERFORM RECALL 98S15
REPLACE DEACTIVATION SWITCH
INSTALLED DEACTIVATION SWITCH
R&R CRUISE SWITCH PER RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL
98S15
00 98S15
21165 PERFORMED RECALL
REPLACE SWITCH
REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
REPLACED SWITCH AND CONNECTOR
PERFORM RECALL...CAMPAIGN...
RECALL 98S15 RECALL REPLACE SWITCH
COMPLETE RECALL 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
RECALL INSTALLED BRAKE REPAIR KIT AS PER RECALL
98S15 RECALL 98S15 REPAIR AS PER RECALL
RECALL 98S15-DEACTIVE SWITCH 98S15
1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
COMPLETED RECALL PER INSTRUCTIONS
PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTOR
REPLACE SPEED CONTROL DEACTIVATION SWITCH 1

1 PERFORMED RECALL
REPAIRED AS PER RECALL
RECALL REPLACED SWITCH REPLACED SWITCH PER RECALL
98S15 COMPLETED RECALLS-CAMPAIGN 98S15
RECALL REPLACE SWITCH AND WIRE PLUG
COMPLETED RECALL
98S15 REPLACED SWITCH AND CONNECTOR
PERFORMED RECALL PERFORMED RECALL
R CRUISE CONTROL RECALL 98S15

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
FACTORY RECALL COMPLETED RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
84726 PERFORM RECALL 98S15
PERFORMED RECALL 98S15-INSTALL SWITCH
REPLACED BRAKE PRESSURE SWITCH & CONNECTOR PER RECALL 98S15
RECALL PERFORM RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH.

Box_Files

COMPLETE RECALL

RECALL _____ RECALL _____ PERMANENT REPAIR

RECALL _____ RECALL _____

RECALL 99815 99815 INSTALL CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

CHECKED OASIS. REPLACED BRAKE PRESSURE SWITCH

PERFORMED RECALL 99815-INSTALL SWITCH & PLUG CONNECTOR.

COMPLETE RECALL 99815

. INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 9985

REPLACE SPEED CONTROL SWITCH

PERFORM RECALL 99815

REPLACED SPEED CONTROL SWITCH

1 -REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL-

PERFORMED RECALL

PERFORMED RECALL

PERFORMED RECALL 99815-REPLACED CRUISE CONTROL DEACTIVATION SWITCH

PERFORMED RECALL AS PER INSTRUCTIONS

COMPLETED . REPLACED SWITCH

78544 REPLACED SPEED CONTROL SWITCH, 8-2 8274

COMPLETED RECALL 99815B

REPLACE SWITCH AND CONNECTOR

89417 INSTALL DEACTIVATION SWITCH PER RECALL

42779 PERFORM RECALL 99815 INSTALLED BRAKE REPAIR KIT JH

132885 PERFORMED RECALL

PERFORM RECALL

DEACTIVATION SWITCH 99815

REPLACE CRUISE CABLE

PERFORM RECALL

PERFORMED SPEED CTL DEACTIVATION SWITCH RECALL

1 PERFORMED RECALL

C RC 99815 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

OTHER RECOMMEND SERVICES: SERP BELT, ENGINE COOLING SYSTEM HOSES, COOLANT FLUSH, ENGINE FLUSH, POER STEERING FLUSH, BATTERY SERVICE, COMPLETE MAI

COMPLETE RECALL 99815

47787 REPLACED DEACTIVATION SWITCH

48081 RECALL 99815 REPLACED SPEED CONTROL DEACTIVATION SWY PER RECALL 99815. BLEED BRAKES AND TESTED OPERATION. OK

72088 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL REPLACED THE SWITCH AND CONNec TOR BLEED THE SYSTEM

RECALL PERFORMED RECAL

REMOVE TAPE AND SECURE LABOR OF 99815E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99815B .5 REMOVED TAPED AND SECURED SPEED CONTR

108- SPD CONTROL SWITCH RECALL - 99815 - REPLACE SPEED CONTROL ACTIVATION SWITCH PER RECALL

PERFORMED RECALL

REPLACE CRUISE CONTROL SWITCH

RECALL PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

78996 99815B 0.5 ADMIN 0.1

2002-02-01 13:00

Box Files

00815E REMOVE,TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED
 RECALL REPAIR SPEED CONTROL
 98815 PERFORMED RECALL 98815
 REPLACED CONTROL DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98815.
 REMOVED AND REPLACED SPEED CONTROL SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98815 - MILES OUT 88621
 REPLACED BRAKE SWITCH PER RECALL

PERFORMED RECALL
 PER RECALL REPL HEADLIGHT DEACTIVATOR SWITCH
 RECALL 98815 REPL SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL 98815 REPLACE C-C SW
 PERFORMED RECALL
 WARRANTY MILES OUT 90,110 PERFORMED RECALL 98815 DEACTIVATION SWITCHH.
 REPLACE SPEED CONTROL SWITCH PER RECALL 98815

CHECK AND REPAIR AS REQUIRED
 REPL SWITCH PER RECALL 98815
 PERFORMED RECALL REPLACED THE DEACTIVATION SWI TCH AND CONNECTOR BLEED THE SYSTEM
 REPLACED SPEED DEACTIVATION SWITCH RECALL 98815
 88348 WARR PERFORM RECALL 98815 SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SC DEACTIVATION SWITCH 98815
 134488 RECALL 98815 DID 98815
 INSTALLED SWITCH AND HARDSHELL PER RECALL 98815
 138827 RECALL 98815B REPLACE SWITCH AND CONICTOR TK372
 98815E REMOVE,TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED
 RECALL INSTALLED DEACTIVATION SWITCH PER RECALL

REPLACED SWITCH AS PER RECALL 98815
 RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
 REPL SWITCH PER RECALL 98815
 REPLACE DEACTIVATION SWITCH
 RECALL RECALL
 REPLACE SPEED CONTROL ADEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 RECALL SPEED CONTROL DEACT SWITCHPERFORM RECALL 98815 TECH 131 PERFORM WORK
 RECALL PERFORMED RECALL 98815
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 92114 RECALL REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL
 PERFORMED RECALL 98815-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 98815
 PROGRAM CODE 98815.
 PERFORMED RECALL
 COMPLETED RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 98815
 1 CAMPAIGN COMPLETED.

FM22-828-A 3397

Box_Files

REPLACED SPEED CONTROL SWITCH AS PER RECALL

RECALL COMPLETE

101-CRUISE CONTROL SWITCH RECALL-99S15 - CHECK AND REPLACE CC BRAKE SWITCH

PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

99S15 SPEED CONTROL DEACTIVATION REPLACED SWITCH AND CONNECTOR PER RECALL 99S15

REPLACE SWITCH

109S18 RECALL 99S15B 0.5 0.5 REPLACE DEACTIVATION SWITCH AND CONNECTOR

R&R SWITCH AND CONNECTOR

INSTALLED SWITCH KIT

RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.

RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO

99S15B .5 HRS ADMIN .1 HRS R&R SWITCH AND CONNECTOR

RECALL 99S15 RECALL 99S15

REPL BRK PRESSURE SWITCH

91380 RECALL REPLACE DEACTIVATION SWITCH PER RECALL(WP) 23

99S15 99S15 REPLACE SWITCH

RECALL 99S15 RECALL 99S15

PERFORMED RECALL

REPLACE DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL 99S15

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15-INSTALL SWITCH

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO

MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

1 INSTALL SWITCH AND CONNECTOR

COMPLETE RECALL 99S15

PERFORMED RECALL PERFORMED RECAL

RECALL 99S15

RECALL 99S15 PERFORM RECALL 99S15

RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

1 REPLACED SPEED CONTROL PER RECALL

RECALL COMPLETED

PERFORM 99S15 RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

RECALL INSTALL SWITCH

PERFORM RECALL.....

REPLACED CRUISE DEACTIVATION SWITCH

REPL SWITCH PER RECALL 99S15

REPL HARDSHELL CONNECTOR PER RECALL

PERFORMED RECALL 99S15-INSTALL SWITCH
 RECALL PERFORMED RECAL
 PERFORM RE-CALL
 RECALL COMPLETED
 PERFORMED RECALL 99S15
 COMPLETED RECALL
 REPLACE BRAKE SWITCH AND HARD SHELL CONNECTOR
 99S15 99S15 RECALL
 PERFORMED RECALL 99S15-INSTALL SWITCH
 RECALL RECALL
 1 OK REPLACED SWITCH BLEED BRAKES
 OPEN RECALL COMPLETE 99S15
 PERFORMED CRUISE CONTROL RECALL 99S15
 RECALL PERFORMED RECAL
 99S15 REPLACED SWITCH AND CONNECTOR
 RECALL 99S15
 100943 REPAIR AS PER RECALL 99S15
 PERFORM RECALL 99S15
 PERFORMED RECALL 99S15
 PERFORM RECALL 99S15 INSTALL SWITCH PER RECALL 99S15
 PERFORM RECALL 99S15
 PERFORM RECALL 99S15 REPLACE BRAKE PRESSURE SWITCH PER RECALL 99S15
 INSTALLED UPDATE SPEED CONTROL DEACTIVATION SWITCH ...TR5
 128045 MOD. 99S15 COMPLETE
 99S15 RECALL
 MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.
 COMPLETED RECALL 99S15 SPEED CONTROL
 REPAIR AS PER RECALL 99S15
 COMPLETE RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 1 REPLACED CABLE AND SWITCH ASSEMBLY.
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 PERFORM RECALL 99S15. INSTALL SPEED CONTROL DEACTIVATION SWITCH, RE-CHECK-OK
 COMPLETED 99S15 RECALL 1

 PERFORM RECALL
 REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER CAMPAIGN 99S15
 RECALL 99S15 99S15 COMPLETED RECALL
 99S15 SPEED CONTROL SWITCH 99S15
 RECALL 99S15

 PERFORMED RECALL 99S15
 REPLACE CRUISE DEACTIVATION SWITCH AS PER 99S15 RECALL
 92173 PERFORMED 99S15, REPLACED SWITCH & CONNECTO
 RECALL 99S15 RECALL COMPLETE
 PERFORM RECALL
 R AND R CRUISE CRT CONNECTOR AND SWITCH

 RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONT. PER RECALL RECK OK
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

Box_Files

PERFORM RECALL RENEW SWITCH AND CONNECTOR
REPLACE CC SWITCH AND CONNECTOR
DIAG AND PERFORMED RECALL 99S15 INSTALL NEW DEACTIVATION SWITCH OK NOW

RECALL 99S15
RECALL COMPLETED 99S15 SPEED CONTROL DEACT SWITCH
RECALL PERFORM RECALL 99S15
INSP AND RR CONNECTOR AND SWITCH

99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
RECALL - 99S15B
OPEN RECALL PERFORMED RECALL
REPLACE CRUISE CONTROL SWITCH AS PER RECALL 99S1
REPLACE DEACTIVATION SWITCH PER RECALL
37765 PERFORMED RECALL 99S15.
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND INSTALL HARD SHELL CONNECTOR, CPN, 99S15, 99S15B, 0.5, ADMIN, 0.1, CC RECAL
COMPLETED RECALL AS REQUIRED
SPD CNTRL DEACTIVATION SWITCH BAD REPLACED SPEED CONTROL DEACTIVATION SWITCH-HARDSHELL CONNECTOR
RECALL PERFORMED
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
71586 WF PERFORM RECALL AS INSTRUCTED
REPLACE SPEED CONTROL SWITCH
99S15 RECALL. SPEED CONTROL PERFORMED RECALL OF SPEED CONTROL
RECALL COMPLETED
REPL SWITCH PER RECALL.
56089 PERFORM RECALL
RENEW DEACTIVATION SWITCH
- 99S15 RECALL COMPLETED
99S15 SPEED CONTROL RECALL
PERFORMED RECALL 99S15

RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTION
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CHANGED HARD SHELL CONNECTOR
RECALL 99S15
1 PERFORMED RECALL 99S15.

PERFORMED RECALL
72068 99S15B 0.5 HRS. SPEED CONTROL RECALL
PERFORM RECALL 99S15- REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL
99S15 RECALL 99S15 RECALL PERFORMED
REPLACED DEACTIVATION SWITCH
PERFORM RECALL
CC RECALL PERFORM RECALL 99S15 REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
COMPLETE RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

ENR2-025-A 3400

Box_Files

99S16 COMPLETED
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
INSTALL CRUISE CABLE PER RECALL 99S15
PERFORMED RECALL 99S15
REPLACED SWITCH PER RECALL
58993 RECALL 99S16 REPLACED SPEED CONTROL SWITCH AS PER RECALL 99S15.
99S16 CC DE ACTIVATION SW RECAL 99S16 CC DE ACTIVATION SW RECALL

REPLACED SWITCH CONNECTOR PER RECALL 99S15
DIAG AND PERFORMED RECALL 99S15 INSTALLED NEW DEACTIVATION SWITCH OK NOW
REPLACE CONNECTOR AND SWITCH AS PER RECALL

43553 99S15 INSTALL BRAKE SW AND CONNECTOR
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR BLEED BRAKES.
COMPLETED RECALL 99S15
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SOLED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
58999 RECALL 99S15 XX OPERATION 99S15B REPLACE SWITCH AND ELECTRICLE CONNECTOR XX BLEAD BRAKE
REPLACE CRUISE CONTROL DEACTIVATION SWITCH
69004 REPLACED SPEED CONTROL SWITCH 99S15
PERFORM RECALL 99S15
99S15 RECALL 99S15 RECALL COMPLETE
RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS
23567 DO RECALL 99S15
PER RECALL REPLACE SWITCH CONNERTORS
RECALL 99S15
PERFORM RECALL
PERFORM RECALL
THE SHORT MAY DISABLE THE SPEED CONTROL SYSTEM OR CAUSE A FUSE TO OPEN AFTER INSPECTION,IF THE VEHICLE IS INVOLVED THE DEALER WILL REPLACE THE DEAC
99S15 MO 62988 REPLACED SPEED CONTROL DEACTIVATION SWITCH
78278 INSTALL DEACTIVATION SWITCH PER 99S15 7821 MILES AT 78278

70768 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
PERFORMED RECALL
REPLACED CONNECTOR AND SWITCH PER RECALL
A SHORT IN THE SPEED CONTROL SWITH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE,ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEAC
REPLACED SWITCH PER RECALL
PERFORM RECALL 99S15
RECALL 99S15
COMPLETED AS PER RECALL
RPL CRUISE DEACTIVATION SWITCH
PERFORM RECALL 99S15
PERFORM SAFETY RECALL
COMPLETED RECALL 99S15
99S15 RECALL 99S15 RECALL COMPLETE
RECALL COMPLETED
REPLACED SWITCH
REPALCE CC SWITCH AND CONNECTOR ASSEMBLY
107483 RECALL 99S15 WARR. PERFORMED DEACTIVATION SWITH RECALL 99S15.

2002-025-A-3401

Box_Files

COMPLETED RECALL ON SPEED CONTROL SWITCH

98S15 98S15 REPLACE S-C DEACTIVATION SWITCH AND CONNECTOR
REPLACE CRUISE SWITCH AND HARNESS CONNECTOR AS PER 98S15 RECALL
1 REPLACE BRAKE SWITCH AND CONN PER RECALL

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
RECALL RECALL

98S15 RECALL 98S15 RECALL

1 98S15B .3 ADMIN .1

RECALL INSPECT SPEED CONTROL CABLE

1 INSTALLED DEACTIVATION SWITCH

98S08 OK FOR RECALL 98S15 REPLACED CRUISE CONTROL SWITCH FOR RECALL 98S15

PERFORMED RECALL

PERFORM SPEED CONTROL DEACTIVATION PER RECALL

REPL SWITCH PER RECALL 98S15

PERFORMED RECALL RECALL COMPLETED

RECALL 98S15 REPLACED DEACTIVATION SWITCH PER RECALL

DID 98S15 RECALL

PERFORM RECALL

INSTALLED PINS IN NEW CONNECTER AND REMOVED OLSD SWITCH AND REPLACED WITH NEW BLEED SYSTEM OF AIR TEST DROVE GOOD

REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL

PERFORMED RECALL

98S15 98S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15

PERFORM RECALL 98S15

CAUSE=RECALL CORRECTION=PERFORM RECALL

80007 PERFORM RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL ACTIVATION SWITCH

100038 98S15 PERFORM RECALL REPLACE SWITCH AND CONNECTOR

REPLACED SWITCH

REPLACE SWITCH PER RECALL 98S15

SUPPLEMENT #1 5-98 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORM RECALL 98S15 REPLACE SWITCH

RECALL 98S15 RECALL COMPLETE

INSTALL SPEED CONTROL DEACTIVATION SWITCH PWER RECALL

98S15 RECALL 98S15 RECALL COMPLETE

RECALL 98S15 REPLACED DEACTIVATION SWITCH

RECALL 98S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH

RECALL PERFORMED

98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

90448 COMPLETED RECALL 98S15 245

REPL SWITCH PER RECALL 98S15

PERFORMED RECALL

INSTALLED SWITCH PER RECALL

83029 INSPECT AND REPLACE DEACTIVATOR SWITCH AND CON-NECTOR

Box_Files

REPLACE SWITCH
14547 RECALL W INSTALL CONECTOR GA
RECALL 99S15
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

RECALL COMPLETED
PERFORM RECALL
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

RECALL COMPLETED
RECALL COMPLETE,REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
99S15 RECALL PERFORM RECALL
PERFORMED RECALL 99S15
INSTALL SWITCH&CONNECTOR RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN. TIME
99S15 REPLACED SPEED CONTROL SWITCH RECALL PERFORMED
1 1 PERFORMED RECALL 99S15
INSPECT AND REPALCEV C CONNECTOR AND SWITCH
REPLACE CONNECTOR AND SWITCH
70032 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
PERFORM RECALL 99S15 RECHECK OK 1
RECALL 99S15B PERFORM RECALL 99S15B
COMPLETE RECALL REPAIRS

RECALL 99S15

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH
58668 INSTALL SWITCH PER RECALL
REPLACED SWITCH
99S15 SPEED CONTROL RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH..

99S15 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH
1 PERFORM RECALL
REPLACE KIT PER RECALL
PERFORMED RECALL

RECALL PERFORMED RECALL 99S15
CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.
RECALL REPLACE SWITCH PER RECALL
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL
RECALL 99S15

88380 DID RECALL 99S15B 0.5 HRS
PERFORM RECALL 99S15
1 REMOVE AND REPLACE CRUISE CONTROL SWITCH PER RECALL

Box_Files

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
PERFORMED RECALL 98S15

REPLACE SWITCH

83051 PERFORMED RECALL 98S15 AND RR SWITCH

98S15 98S16

REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH

1 RECALL 98S16

1 PERFORM RECALL

79201 98S16B 0.5 HRS. SPEED CONTROL RECALL

REPLACED DE-ACTIVATION SWITCH PER 98S15 RECALL

REPLACE SWITCH AND CONNECTOR

85579 INSTALL RECALL SWITCH AND CONNECTOR

182402 28 98S16 REPLACED SWITCH PER RECALL 98S1

INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B

COMPLETED RECALL

SPEED CONTROL DEACTIVATION SWITCH 98S15 REPAIR PER RECALL

RECALL COMPLETED

86320 PERFORMED SPEED CONTROL RECALL AND CONNECTOR Y

REPLACED SWITCH & CONNECTOR PER RECALL

SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD MOTOR CO. F

REPLACE CRUISE CONTROL CONNECTOR AND SWITCH

RNAD R SPD CRTL CONN AND SWITCH

98S15 RECALL COMPLETE

86808 RECALL DO RECALL 98S15

REPLACE SWITCH PER RECALL

PERFORMED RECALL 98S16

RECALL INSTALL SWITCH

180421 RECALL INSTALL SWITCH AND HARDSHELL CONNECTOR PER RECALL

PERFORMED RECALL 98S16

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR RECALL 98S15 BOX B

PERFORMED RECALL 98S15

70149 R-T OK CRUISE OPERATION PERF SPEED CONTROL TEST P-P TO RECALL NOT DONE HARNESS DISCONNECTED INST RECALL R-T OK

75050 REPLACED BRAKE SWITCH AND CONNECTOR PER RECALL

INSTALL SWITCH PER RECALL PER SPECS

RECALL REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL RECALL

1 PERFORM THE 98S15 RECALL AND REPLACED THE SWITCH

REPLACE CRUISE DEACTIVATION SWITCH

RECALL COMPLETE

REPLACE DEACTIVATION SWITCH

RECALL RECALL

76800 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15

RECALL 98S15 98S16

ENG2-825-A 2404

Box_Files

PERFORMED RECALL PER FACTORY SPEC
RECALL 99S15 - B - RECALL
REPLACE DEACTIVATION SWITCH PER RECALL 99S15 2 OF 2 ROS
INSTALL SWITCH AND HARD SHELL RD TEST
REPAIR AS PER 99S15 RECALL
PERFORMED RECALL
INSTALLED SWITCH PER RECALL

PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
99S15 RECALL REPLACE SPEED CONTROL SWITCH AND CONNECTOR
99S15 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
DIAG AND PERFORMED RECALL 99S15 INSTALLED A DEACTIVATION SWITCH OK NOW
REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL 99S15

INSPECT AND REPLACE SWITCH.
PERFORMED RECALL

1 COMPLETED RECALL 99S15
REPLACE SWITCH AND HARD SHELL
PERF RECALL 99S15

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR
99S15 RECALL COMPLETE

CHECK AND REPLACE CONNECTOR PER RECALL

F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
COMPLETE RECALL

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH.

97838 RECALL 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH
TYPE 2 PROGRAM 99S15 PERFORM RECALL PER GUIDELI

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER SAFETY RECALL 99S15.
PERFORMED RECALL 99S15

RECALL REPLACE SPEED CONT DEACT SWITCH PER RECALL

ABO 99S15
PERFORMED RECALL 99S15

PERFORM RECALL 99S15

99124 DO RECALL 99S15

PER RECALL REPLACED SWITCH.

RECALL 99S15 DONE- REPL CRUISE SW

PERFORMED 99S15B

REPL SWITCH PER RECALL

PER OASIS PERFORMED RECALL 99S15 B

REPLACED DEACTIVATION SWITCH AS PER RECALL 99S15
PERFORM RECALL 99S15B

INSTALL SWITCH

RECALL PERFORM RECALL

99488 RECALL 99S15 W PERFORMED RECALL 99S15; REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTING HARNESS, TEST DROVE AND VER
REMOVE AND REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
REPLACE SWITCH AND HARD SHELL

Box_Files

PER RECALL PERF RECALL
 PERFORMED RECALL
 97908 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR 5 WP
 1 REPLACED SWITCH
 REPLACED SC DEACTIVATION SWITCH 99S15
 117918 PERFORM SPEED CONTROL DEACTIVATION SWITCH AND CONNECTER REPLACEMENT RECALL
 REPLACE SWITCH PER RECALL
 48224 W REPLACE SWITCH GA
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 RECALL RECALL
 RECALL 99S15 REPLACED SPEED CONTROL SWITCH
 99S15 CRUISE DEACTIVATION SWITCH 99S15
 1 TECH 247 COMPLETE RECALL
 PER FCSD PERFORMED RECALL 99S15
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 RECALL 99S15

RECALL REPLACE DEACT SWITCH
 RELPALGE SPEED CONTROL CUT OFF SW FOR RECALL 99S15 BLEED BRAKES ROAD TEST OK..

PERFORMED RECALL 99S15

INSTALL NEW HARD SHELL AND SWITCH AS PER RECALL
 118231 99S15 WARR REPLACED SWITCH AND CONN
 99S15 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 70089 RECALL W 2071 CHANGED SPEED CONTROL DEACTIVATION SWITCH AND CONN.
 RECALL 99S15 99S15
 VERIFY CONCERN,INSTALL NEW SWITCH
 RECALL 99S15 RECALL
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 REPLACED THE SWITCH PER RECALL 99S15
 91191 REPLACE DEACTIVATION SWITCH WITH IMPROVED TYPE
 PERFORMED RECALL
 PERFORMED RECALL
 99S15 RECALL 99S15 COMPLETED RECALL
 1 RECALL COMPLETED BY TECH 1
 PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACE CRUISE DEACTIVATION SWITCH
 99S15 99S15
 1 REPLACE SWITCH
 TEST CRUISE, PINPOINT, REPL DEACTIVATION SWITCH, OPEN.
 90214 99S15 0.5HR RECALL COMPLETE
 024 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 RECALL 99S15 - B - RECALL
 1 PERFORMED 99S15 RECALL
 DIAG AND PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH OK NOW

15002-025-0 3400

Box_Files

COMPLETED 99S15 RECALL
REPLACED BRAKE DEACTIVATION SWITCH PER RECALL
RECALLED BY FORD PERFORMED RECALL

SWITCH 99S15

PERFORM RECALL
PERFORM RECALL 99S15
REPLACED DE-ACTIVATION SWITCH PER 99S15 RECALL

70830 99S15 REPL SWITCH

PERFORM RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH
PERFORM RECALL
COMPLETED RECALL
73210 COMPLETE
REPLACE AS PER RECALL 99S15
PERFORMED 99S15 RECALL
1 INSTALLED SWITCH
VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK

INSPECTED, REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
TESTED AND FOUND FUSE BLOWN TO BRAKE SWITCH, FOUND SPEED DEACTIVATION SWITCH BLOWING THE FUSE, PERFORMED RECALL 99S15
REPLACE DE-ACTIVATION SWITCH
F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
REPLACED SWITCH & HARD SHELL PER 99S15
PERFORMED RECALL 99S15

PERFORM SAFETY RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
INSTALL SPEED CONTROL SWITCH
REPLACE DEACTIVATION SWITCH
INSTALL CABLE PER RECALL 99S15
REPLACED DEACTIVATION SWITCH
PERFORM RECALL 99S15
RECALL 99S15

PERFORM RECALL 99S15- REPLACE CRUISE CONTROL DEACTIVATION SWITCH
99S15 RECALL 99S15 COMPLETED RECALL
RECALL
REPLACED BRAKE SWITCH AND CONNECTOR PER 99S15.
RECALL 99S15
PERFORMED RECALL 99S15
INSTALLED SWITCH PER RECALL
99S15 99S15
PERFORMED RECALL
COMPLETED RECALL 99S15

2002-02-11 14:07

Box_Files

98S15-RECALL 98S15-RECALL
 98S15 PERFORM RECALL 98S15
 1 REPLACED CRUISE CONTROL SWITCH PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 98S15. ALSO SEE JOB 1.
 INSPECT AND REPLACE SPEED DEACTIVATION SWITCH AND PLUG. BLEED BRAKES.
 RECALL COMPLETED
 RECALL PERFORMED
 49306 98S15B 0.5 HRS. SPEED CONTROL RECALL
 INSTALL SENDER & CONNECTOR
 INSTALLED SWITCH AND HARD SHELL
 RECALL PERFORM RECALL

98S15 98S15

98S15 98S15-REPLACE CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR ASSY

PERFORM RECALL 98S15
 98S15 PERFORM RECALL
 RECALL COMPLETED
 REPLACE DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.
 PERF RECALL 98S15
 PERFORMED RECALL
 SPEED CONTROL SWITCH REPL. SPEED CONTROL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 REPLACED SC DEACTIVATION SWITCH 98S15
 REPLACED CRUISE CONTROL CABLE
 43397 RECALL WARR PERFORM 98S15, REPLACED DEACTIVATION SWITCH AND HARDSHELL. TEST DROVE ALL OK.

RECALL 98S15
 ASDFADSFADSFADF
 RECALL 98S15 RECALL
 PERFORMED SPEED CONTROL RECALL
 INSTALL SWITCH AND HARD SHELL
 PERFORMED RECALL
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15 BOX B
 ASA PER RECALL AS PER RECALL
 RECALL 98S15
 RECALL 98S15 COMPLETED
 98S15 REPL. DEACTIVATION SWITCH
 98S15 98S15
 X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 98S15 RECALL 98S15 RECALL
 PERFORMED RECALL
 X REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR
 65856 98S15B 0.5 ADMIN 0.1
 PERFORMED RECALL

98S15-025-A 3411

Box_Files

99815 99S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.
REPLACE SWITCH PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.
23696 RECALL 99S15 RECALL 99S15
INSTALLED SPEED CONTROL TIE DOWN PER RECALL RET ESTED OK. NO OTHER CONCERN AREAS EVIDENT AT THIS TIME-
RECALL REPAIR PER RECA
REPLACE DEACTIVATION SWITCH AS PER RECALL
RECALL 99S15 PERFORM RECALL 99S15
COMPLETE RECALL
PERFORMED RECALL AS BY FACTORY PERFORMED RECALL
80111 PERFORM RECALL 99S15

PERFORMED 99S15 RECALL
REPLACED SPEED CONTROL CABLE AS PER RECALL

X REPLACED CLIP & SWITCH, RETEST, SYSTEM OK PER RECALL
PERFORMED 99S15 RECALL REPLACED REDUNDANT DEACTIVATOR SWITCH
RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
99S15 REPLACED CONNECTOR AND SWITCH
REPLACE DEACTIVATION SWITCH AS PER RECALL
106151 99S15B 0.5 HRS. SPEED CONTROL RECALL
RECALL 99S15 REPLACE C-C SW
1 PERFORM RECALL
107571 RECALL REPLACE DEACTIVATION SWITCH & CONN 94
40057 99S15 99S15 0.6 REPLACE SWITCH & CONNECTOR
40038 REPLACE SPEED DEACTIVATION SWITCH AND CONNECTOR AS PER 99S15B .5 +.1 ADMIN
REPLACED SPEED CONTROL SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS
RECALL RECALL
PERFORMED RECALL 99S15
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
RECALL 99S15 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
88788 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745
48477 COMPLETED 99S15
82008 RECALL REPLACED SPEED CONTROL SWITCH FOR RECALL 99S15
REPLACE CRUISE CONTROL CUT OFF SWITCH AS PER RECALL
REPL SWITCH PER RECALL 99S15
PERF. RECALL
PERFORMED RECALL
42 99S15
PERFORMED RECALL 99S15
COMPLETE RECALL 99S15
REPLACE SWITCH AND CONNECTOR
99S15-RECALL 99S15-RECALL
85346 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745
RECALL PERFORM RECALL

Box_Files

RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 . REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL AS PER INSTRUCTIONS
 REPLACE SWITCH AND CONNECTOR PER RECALL
 REPLACE SWITCH PER RECALL
 PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
 RECALL COMPLETE
 RECALL COMPLETED
 SPEED CONTROL DEACTIVATION SWITCH. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL
 REPLACED SWITCH AND CONNECTOR
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PERRECALL 99S15
 1 PERFORM RECALL 99S15 BRAKE SWITCH
 1 PERFORMED CRUISE CONTROL RECALL
 PERFORM BRAKE SWITCH RECALL WARR
 PERFORMED 99S15 RECALL

 REPLACED DEACTIVATION SWITCH AND HARD SHELL
 1 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH AND CONNECTOR
 RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 COMPLETE RECALL
 RECALL 99S15 PERFORM RECALL 99S15
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
 RECALLED BY FORD PERFORMED RECAL
 REPLACE SWITCH AS PER 99S15
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR -- 99S15B .5
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN TIME
 RECALL R-R DEAC SW, INSTALLED NEW CONNECTOR.... WHILE UNDER HOOD I REC-COMEND THAT THE BATTERY BE SERVICED
 REPAIR PER RECALL 1
 REPLACED DE-ACTIVATION SWITCH
 REPLACE CABLE PERFORM RECALL
 PERFORMED RECALL 99S15
 1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X5
 PERFORMED RECALL 99S15
 PERFORM RECALL 1
 REPLACED CRUISE CONTROL SWITCH PER RECALL 99S15
 RECALL 99S15 CRUISE CONTROL SWITCH
 1 PERFORM RECALL 99S15
 RECALL PERFORMED RECAL
 RECALL COMPLETE
 RECALL RECALL
 82138 RECALL INSTALL DEACTIVATION SWITCH
 AS PER RECALL 99S15 RECALL TO INSTALL HARDSHELL SWITCH CONNECTOR
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 RECALL 99S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
 45S15 RECALL 99S15 RECALL 99S15 R-R DEACTIVATION SWITCH
 RECALL 99S15 RECALL
 99S15 99S15
 RECALL - PERFORMED RECALL # 6176

5902-025-9 3410

Box_Files

REPAIR AS PER RECALL
50374 INSTALL NEW DEACTIVATION SWITCH
1 PERFORMED RECALL
RECALL INSTALL CRUISE CONTROL DEACTIVATION SWIT
RECALL COMPLETED ALL OK
REPLACE DEACTIVATION SWITCH AS PER RECALL
REPLACE AND INSPECT CRUISE CRL CONNECTOR
R AND R SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETED RECALL 99S15
COMPLETED RECALL
. PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN BULLETIN REPL DEACTIVATION SWITCH,PER 99S15
REPLACED DEACTIVATOR SWITCH
. REPLACED SWITCH AS PER RECALL 1
PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH

108428 PERFORM RECALL 99S15 INSTALL SWITCH
PERFORM RECALL PER INST
18109 RECALL WF PERFORMED RECALL AS INSTRUCTED
43122 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 99S15 RECALL I ALSO REPLACED CONNECTOR
RECALL #99S15; PERFORM RECALL #99S15;REPL BRK-PRESS. SWITCH;
REPLACE SWITCH PER RECALL
REPLACED SPEED CONTROL DEACTIVATOR SWITCH AND HARD-SHELL CONNECTOR AS PER RECALL 99S15. 99S15B 0
PERFORMED RECALL PERFORMED RECAL

PERFORM RECALL
MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEATIVATION SWITCH
PERFORMED 99S15B

99S15 INSTALL NEW SWITCH ASY.-NOTE-MASTER CLY WAS VERY LOW ON FLUID,HOIST VEHICLE AND CHECK ALL BRAKES AND FOUND ALL FOUR TO BE AT 5% OR LESS,REC.E
COMPLETE RECALL
1 INSTALLED SPEED CONTROL SWITCH
61458 99S15 PERFORM RECALL,REPLACE SWITCH AND CONNECTOR.
71048 DONE
RECALL COMPLETE
RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
44818 RECALL #99S15 PERFORM RECALL #99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND ITS CONNECTOR *5 WP
118930 99S15 PREFORMED 99S15 PER INSTRUCTIONS
RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
COMPLETED CAMPAIGN COMPLETED OP 99S15B
INSOECT FOR RECALL 99S13
RECALL RECALL
PERFORM SAFETY RECALL
PERFORMED RECALL 99S15 REPLACED SPEED SWITCH AND TERMINAL BLEED BRAKES
PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
PERFORM RECALL 99S15
54014 RECALL WF PERFORMED RECALL AS PER INSTRUCTIONS
48128 REPLACE CRUISE DEACTIVATE SWITCH AND CONNECTOR PER RECALL
99S15-1827 REPLACED SPEED COTNROL DEACTIVATION SWITCH
PERFORMED RECALL PERFORMED RECAL

2002-025-A 3411

Box_Files

PERFORM 99S15

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN

77878 RECALL 99S15 S W PERFORM RECALL 99S15

REPL BRAKE PRESSURE SWITCH

RECALL COMPLETED

COMPLETE RECALL 99S15

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

114528 REPLACED SPEED CONTROL SWITCH 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

188997 RECALL 99S15 PERFORM RECALL 99S15

REPLACE CRUISE SWITCH

44060 99S15 RECALL W RR DEACTIVATION SWITCH PER 99S15 RECALL
SWITCH 99S15

REPLACED DEACTIVATION SWITCH PER RECALL

PERFORM SUBFRAME SAFETY RECALL AS INSTRUCTED

99S15 99S15

REPLACE SWITCH AND HARNESS PER RECALL

PERFORM SAFETY RECALL

23108 99S15 C 0.5 HRS.

RECALL 99S15

99S15 REPLACE SPEED CONTROL SWITCH

PERFORM RECALL

PERFORM RECALL

99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

A DONE

SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15

REPLACED DEACTIVATION SWITCH PER RECALL 99S15

1 1 COMPLETED RECALL

50060 RECALL W REPLACE DEACTIVATION SWITCH AS PER RECALL 99S16 JH

REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER 99S15

68388 99S15 .6L RR CRUISE DEACTIVATION SWITCH

PERFORMED RECALL 99S15 B

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORMED RECALL 99S15

88368 RECALL RECALL COMPLETED

COMPLETED RECALL

REPLACE DEACTIVATION SWITCH AND HARDSHELL CONNECTOR 99S15B-60

PERFORM SPEED CONTROL SWITCH RECALL

REPLACE SWITCH PER RECALL

PERFORMED RECALL

99S15 99S15

REPLACED THE SPEED CONTROL SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

PERFORMED RECALL 99S15

PERFORM RECALL

99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

REPLACE BRAKE KIT PER RECALL

2003-025-A 2412

X REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15 REPLACE C-C SW

RECALL COMPLETED
 PERFORM RECALL
 REPLACED THE SPEED CONTROL SWITCH PER RECALL
 128495 RECALL 99S15 WVR RECALL 99S15 SPEED CONTR
 18385 RECALL REPLACE DEACTIVATION SW AND CONNECTOR
 REPLACE SWITCH
 REPLACED DEACTIVATION SWITCH AS PER RECALL
 REPLACE DEACTIVATION SWITCH FOR SPEED CONTROL 3
 PERFORM 99S15 AS INSTRUCTED
 REPLACE SWITCH AS DIRECTED BY RECALL
 PERFORMED RECALL 99S15, CRUISE CONTROL
 RECALL REPLACE SWITCH PER RECALL
 REPLACED SPEED CONTROL DEACTIVATOR SWITCH
 1 REPLACED SWITCH AND CONNECTOR
 REPLACE SWITCH PER RECALL
 REPL SWITCH PER RECALL 99S15
 PERFORM RECALL
 106298 INSTALLED RECALL
 PERFORMED RECALL
 INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 99 S 15 FOR CRUISE CONTROL
 99S15 PERFORMED RECALL
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 . REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL

DO RECALL 99S15
 . INSTALLED DEACTIVATION SWITCH AS PER RECALL 99S15
 REPLACED SWITCH AND CONNECTOR COMPLETED RECAL
 INSPECTED SPEED CONTROL OPERATION AND INSTALLED BRAKE REPAIR KIT AS NEEDED FOR RECALL REPAIRS
 RECALL REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
 REPLACED THE SWITCH PER RECALL 99S15

INSTALL SPEED SWITCH PER RECALL 99S15
 PERFORM SAFETY RECALL 99S15
 99S15 REPLACE DEACTIVATION SWITCH
 99S15 COMPLETE
 OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
 PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
 REPLACED SWITCH
 COMPLETED 99S15 RECALL
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 REPLACE SWITCH PER RECALL

Box_Files

REPLACE CRUISE CNTRL SWITCH AND CONNECTOR ASSEMB

99S15 RECALL

PERFORMED RECALL 99S15

RECALL 99S15 99S15 REPLACE SPEED CONTROL SENSOR AND CONNECTOR

COMPLETE RECALL 99S15

COMPLETED FACTORY RECALL

20281 99S15 DONE *28

122478 RECALL 99S15 W PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH.

75498 RECALL W/ PERFORM RECALL

99S15 PERFORM RECALL 99S15

54240 SWITCH RECALL REPLACE SWITCH AND CONNECTOR, RECALL JH

REPLACE DEACTIVATION SWITCH PER RECALL

REPLACED DEACTIVATION SWITCH AND CONNECTOR

RECALL COMPLETE

78610 RECALL 99S15B 0.5HRS REPLACE SWITCH AND CONECTOR TK372

COMPLETED RECALL.0

RECALL 99S15 99S15

DO RECALL 99S15

PER RECALL PERF RECALL

COMPLETE RECALL 99S15

PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS

RECALL 99S15 99S15

REPL SWITCH PER RECALL 99S15

53581 RECALL PERFORM RECALL 99S15. REPLACE SWITCH AND HARD SHELL CONNECTOR

PER FORD INSTALLED SWITCH

PERFORM RECALL 99S15 PERFORM RECALL 99S15

REPL SWITCH PER RECALL 99S15

45084 RECALL INSTALL DEACTIVATION SWITCH

125787 RECALL REPLACE SWITCH AND CONNECTOR AS PER RECALL

99S44 RECALL 99S15 PERFORMED RECALL 99S15.

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

148189 RECALL REPLACE CRUISE SWITCH AND CONNECTOR

PERFORM RECALL 99S15

RECALL 99S15 99S15 INSTALL CABLE PER RECALL

RPL SPEED CONTROL 99S15 RECALL

45766 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL, 5115

REPLACED SPEED CONTROL DEACTIVATION BRACKET.

RECALL COMPLETE

COMPLETE RECALL

RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL 99S15

PERFORMED RECALL 99S15

99S15 RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

118820 RECALL REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH

REPLACE DEACTIVATION SWITCH AS PER RECALL

1982-025-A 3414

PERFORM SPEED CONTROL RECALL
 204807 99S15C 0.5 HRS.
 RECALL RECALL

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
 RECALL 99S15 PERFORMED RECALL
 INSTALLED DEACTIVATION SWITCH PER RECALL

CHECK AND INSTALLED PARTS PER RECALL
 RECALL COMPLETED
 PERFORMED OPEN RECALL 99S15B
 97788 RECALL 99S15
 PERFORM RECALL 99S15
 PERFORM RECALL 99S15
 RECALL 99S15 INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL
 X 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 REPLACED DE-ACTIVATION SWITCH

PERFORM RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS
 PERFORMED RECALL
 INSTALL CRUISE CONTROL DEACTIVATION SWITCH & PLUG PER RECALL

VERIFY CRUISE CONTROL SWITCH
 INSTALL SWITCH AND PLUG AS PER RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 RECALL PERFORM RECALL
 PERFORM RECALL PER FORD NOTICE
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 99S15 99S15
 PERFORMED RECALL #99S15 SPEED CONTROL DEACTIVATION SWITCH
 23880 REPLACED CRUISE DEACT. SWITCH & CONNECTOR PER RECALL #99S15
 PERFORM RECALL
 PERFORM RECALL
 PERFORM RECALL
 PERFORM RECALL
 1 1 REPL SWITCH AND CONNECTOR
 PERFORM RECALL
 RECALL 99S15
 PERFORMED RECALL 99S15
 1 PERFORMED RECALL
 84381 PERFORM RECALL 99S15
 SWITCH 99S15

99S15 RECALL ON OASIS 99S15 RECALL REPLACED SWITCH & CONNECTOR
 99-S-15 99-S-15
 REPLACE BRAKE KIT PER RECALL
 99S15 RECALL

Box_Files

PERFORMED RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND INSTALL HARD SHELL CONNECTOR,CPN,99S15,99S15B,0.5,ADMIN,0.1,CC RECAL
REPL DEACTIVATION SWITCH PER RECALL
99S15 SWITCH-CONNECTOR 99S15
PERFORMED RECALL 99S15
PERFORMED RECALL 99S15
PERFORMED RECALL PERFORMED RECAL
PERFORM AS PER NOTIF
REPL SWITCH PER RECALL 99S15
9756 SPEEC CONTROL RECALL
RECALL 99S15 RECALL REPLACE SWITCH
99S15 INSTALL BRAKE SWITCH AND CONNECTOR PER RECALL
84: PERFORM 99S15 RECALL
REPLACED THE SWITCH PER RECALL 99S15
9977 RECALL W REPLACE SWITCH AND PLUG GA
PERFORM RECALL 99S15
PERFORM SPEED CONTROL RECALL
COMPLETE RECALL 99S15
RECALL 99S15 99S15
INSPECT AND PERFORM RECALL

RECALL INSTALL DEACTIVATION SWITCH AS DIRECTED
SPEED CONTROL SWITCH 99S15 RECALL
OPEN RECALL PERFORMED RECAL
RECALL COMPLETED
PERFORM SPEED CONTROL DEACTIVATION RECALL
1 PERFORMED RECALL 99S15
PERFORMED RECALL 99S15
INSPECTED AND REPLACED BRAKE REPAIRS KIT AS NEEDED FOR RECALL REPAIRS
COMPLETE RECALL 99S15
MANUFACTURE REQUIREMENT INSPECTED & INSTALLED DEACTIVATION SWITCH
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
PERFORM RECALL F
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
84143 RECALL W PERFORMED RECALL 99S15
DID RECALL 99S15 ON SPEED CONTROL
99S15 RECALL COMPLETE
PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION
REPLACED SWITCH AND HARD SHELL CONNECTOR. SPEED CONTROL IS INOP.
99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SH
1 INSTALLED'S CRUISE SWITCH AND HARD SHELL
RECALL 99S15B
1 COMPLETED RECALL 99S15
1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .6
COMPLETED RECALL
PERFORMED 99S15
PERFORM RECALL

2002-02-01 11:34:18

Box_Files

106000 INSTALL NEW SWITCH AND CONNECTOR PER RECALL
 PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
 RECALL - PERFORMED RECALL # 0036
 99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 154758 PREFORM MODIFICATIONS PER 99S15
 CAMPAIGN 99-S-15 COMPLETED AS PER RECALL INSTRUCTION.
 REPLACE CRUISE CONTROL BRAKE SWITCH PER RECALL.
 PERFORMED 99S15 RECALL 99S15
 COMPLETE RECALL
 PERFORM RECALL 99S15B
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 PERFORM RECALL
 RECALL 99S15
 RECALL 99S15 DEACTIVATION SWITCH FOR SPEED CONTROL REPLACED
 REPLACE BRAKE PRESSURE SWITCH PER RECALL
 80604 RECALL (#17)-REPLACE SWITCH AND HARD SHELL AS PER RECALL, BLEED BRAKES.
 76277 78 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST
 REPLACE SPEED CONTROL SWITCH PER RECALL
 PERFORM RECALL 99S15
 PERFORM RECALL
 INCORRECT CONNECTOR SHELL AND WIRE TERMINALS WERE INSTALLED AT A PREVIOUS REPAIR. SOLDER IN CORRECT TERMINAL ENDS.
 1 PERFORM RECALL 99S15
 99S15 99S15
 104000 RTECALL 99S15 COMPLETE RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 RECALL===== RECALL===== REPL CAB

 99S15 REPLACED DEACTIVATOR SWITCH
 1 RECALL COMPLETE
 SERVICE INSTALL KIT PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH, ETC.
 100891 COMPLETE RECALL 99S15 AS PER RECALL

 RECALL 99S15
 80604 W REPLACE SWITCH RAT.
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

 PERFORMED TSB 99S15
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 RECALL REPLACED DEACTIVATION SWITCH
 PERFORMED 99S15
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 PERFORM RECALL REPLACE SWITCH
 1 REPLACED SWITCH

 77039 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745
 9054 99S15 RECALL W PERFORM RECALL 99S15
 RECALL 99S15 SPEED CONTROL REPLACE SWITCH AND CONTOR PER RECALL RECK OK
 PERFORM RECALL 99S15 PERFORMED RECAL

Box_Files

38036 RECALL W PERFORM RECALL TECH # 988

RECALL COMPLETE,REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
REPLACE SPEED CONTROL DEAVTIVATION SWITCH
RECALL 98815
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

OPEN RECALL PERFORM RECALL
RECALL 98816 PERFORMED. REPLACED SPEED CONTROL ACTIVATION SWITCH, 1
PERFORMED RECALL 98815 WHEN REMOVING DEACTIVATION SWITCH THREADS OUT OF PROPORTIONING VALVE REPLACED HOOKED UP ABS ADAPTER
PERFORMED RECALL 98815
PERFORMED RECALL 98815
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 988
PERFORMED RECALL 98815 INSTALLED CRUISE SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

127741 DID RECALL AND BLED BRAKES--.8 HRS
RECALL 98815 REPLACED DEACTIVATION SWITCH.
PERFORM RECALL
OPEN RECALL PERFORM RECALL
75140 42 WP40 COMPLETE RECALL 98815 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
75140 42 WP40 COMPLETE RECALL 98815 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
PERFORM RECALL 98815
RECALL 98816 PERFORMED 1

INSTALL RECALL KIT.

RECALL 98815B NED TO PERFORM RECALL 98815B
MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEACTIVATION SWITCH
29884 98815 WARR PERFORM RECALL, TEST DRIVE TO OK OPERATION OF SPEED CONTROL, OK.
REPLACED CRUISE CONTROL SWITCH
34825 RECALL W REPLACE SWITCH GA
71786 PERFORMED RECALL 98816-SPEED CONTROL SWITCH.
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 98815

REPLACED CRUISE CONTROL DEACTIVATION SWITCH ASSEMBLY
FACTORY RECALL COMPLETED RECALL
REPLACE DEACTIVATION SWITCH PER RECALL
RECALL PERFORMED RECALL 98815
RECALL 98815 PERFORMED RECALL 98815 - REPLACED CRUISE CONTROL CUT OUT SWITCH
PERFORMED RECALL 98815-REPLACED SPEED CONTROL DEACTIVATION SWITCH
98707 98816B .5 HR REPLACE DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
RECALL DID RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.
DEFECTIVE REPLACED DEACTIVATION SWITCH AS PER RECALL
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
COMPLETE RECALL ON SPEED CONTROL SWITCH

ENG-025-4 3411

Box_Files

36767 99S15B 0.5- ADMIN 0.1 RECALL
 1 PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B .5
 FACTORY RECALL COMPLETED RECALL
 INSTALLED SWITCH PER RECALL
 NGS TESTED TESTED FUEL INJECTOR FOUND NOT CONTRIBUTING REPLACED INJECTOR AND RETESTED
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
 DIAGNOSIS AND INSPECT FOR CAMPAIGN PERFORM CAMPAIGN AS PER NOTICE REPLACED DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15
 REPLACE CRUISE DE-ACTIVATION SWITCH AS PER RECAL
 COMPLETED RECALL 99S15
 RECALL 99S15 RECALL COMPLETED
 1 RECALL COMPLETE
 PERFORM RECALL
 PERFORMED RECALL 99S15-INSTALL SWITCH
 99S15 99S15
 . COMPLETED RECALL
 PERFORMED RECALL 99S15
 PERFORMED RECALL 99S15
 106428 PERFORMED OPEN RECALL 99S15
 REPLACED CRUISE SWITCH
 PERFORM RECALL
 89412 INSTALL NEW SWITCH
 197499 99S15 WPC REPLACE DEACTIVATION SWITCH AND CONNECTOR
 INSTALLED KIT 99S15 RECALL PERFORMED
 RECALL 99S15
 COMPLETED RECALL 99S15
 75174 RECALL 99S15 5 W PERFORM RECALL 99S15
 PERFORMED RECALL
 REPLACED SPEED DEACTIVATION SWITCH
 99S15B 0.5, TOTAL HRS 0.5, PERFORMED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 REPLACE SWITCH
 99S15 99S15 RECALL COMPELTED
 1 PERFORMED RECALL
 PERFORMED RECALL 99S15
 PERFORM 99S15 RECALL
 99498 WARRANTY RECALL 99S15 REPLACE SWITCH AND WIRE PLUG
 CHECK AND REPAIR AS REQUIRED
 PERFORM SAFETY RECALL 99S15
 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15
 REPLACED SWITCH PER RECALL 99S15
 PERFORMED RECALL F
 99S15 99S15 RECALL,REPLACE CURISE CONTROLL DEACTIVATION SWITCH
 DO RECALL 99S15

 REPLACED BRAKE PRESSURE SWITCH AND CONNECTOR AS PER RECALL
 78288 99S15B .5 .5 RECALL
 RECALL 99S15 PERFORM RECALL 99S15
 99S15 99S15
 PERFORMED SPEED CONTROL DEACTIVATION SWITCH

EM2-025-0 3418

REPLACED SWITCH
INSTALL SPEED CONTROL SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
REPLACE SPEED CONTROL PER RECALL

99S15 REPLACE DEACTIVATION SWITCH
79 REMOVE AND REPLACE BRAKE SWITCH AND CONNECTOR PER RECALL
93280 99S15 INSPECT AND REPLACE SWITCH
RECALLED BY FORD MOTOR CO. REPAIR AS NEEDED
99S15 99S15
PERFORM RECALL 99S15
RECALL PERFORM RECALL
64014 PERFORM 99S15
REMOVED AND REPLACED SPEED CONTROL CABLE
REPLACED CRUISE DEACT SWITCH

REPLACED SWITCH AND CONNECTOR
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

WHEN DOING RECALL THREADS CAME OUT ORDERED DISTRIBUTION BLOCK R & R DISTRIBUTION BLOCK BLEED BRAKES TEST DROVE PERFORMED RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
COMPLETE RECALL 99S15
RECALL 99S15 RECALL PERFORME
REPLACE VALVE
119083 RECALL CRUISE DEACTIVATION SWITCH I DID REPLACE CONNECTOR AND SWITCH
1 REPLACED SPEED CONTROL SWITCH & CONNECTOR
PERFORMED RECALL 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
COMPLETED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL 99S15
RECALL 99S15 RECALL COMPLETED
143512 PERFORMED RECALL 99S15
93214 RECALL PERFORM RECALL
REPLACED BRAKE DEACT SWITCH PER RECALL
67830 99S15 W PERFORMED SERVICE 99S15

99S15 .3 SECURED SWITCH 99S15B .5 REPLACED SWITCH & CONNECTOR PERFORMED DEACTIVATION OF SWITCH
88703 RECALL 99S15B 0.5 HRS. NEC. TO PERFORM RECALL 99S15.
REPLACED THE SWITCH PER RECALL 99S15
SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15
INSTALL BRACKET
1 REPLACED SWITCH AND CONNECTOR
99S15B INSTALLED SPEED DEACTIVATION SWITCH AS PER RECALL 99S15.
RECALL 99S15 RECALL
REPLACE SWITCH PER RECALL

Box_Files

RECALL PERFORM RECALL PER PROGRAM 99S15, DEACT SWITCH
 REPLACED SWITCH TEST DRIVE WORKS FINE PER RECALL
 RECALL 99S15 RECALL
 REPLACED DEACTIVATION SWITCH
 71137 RECALL 99S15 PERFORMED LABOR OPERATION 99S15B-0.6 HRS.
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 INSTALLED NEW SWITCH.
 PERFORMED RECALL 99S15
 REPLACED SPEED CONTROL BRAKE SWITCH
 RECALL PERFORM RECALL AS PER BOOK.
 RECALL 99S15 PERFORM RECALL 99S15

RECALL PERFORMED SPEED CONTROL DE-ACTIVATION SWIT
 OPEN RECALL PERFORM RECALL
 INSTALLED CRUISE DEACTIVATION SWITCH
 77824 RECALL W/ REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15
 COMPLETED RECALL
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .5

RECALL REPLACE DEACTIVATION SWITCH PER RECALL
 77741 PERFORMED RECALL 99S15 SPEED CONTROL DEACTVATI SWITCH
 30087 99S15B 0.6 HRS. SPEED CONTROL RECAL
 REPLACE SPEED CONTROL SWITCH
 59854 RECALL INSPECT AND REPLACE SPEED SWITCH ASSY AND HARNESS S CONNECTOR JH

99S15 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL COMPLETE
 PERFORM RECALL PER MANUFACTURER PERFORMED RECAL
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
 . INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15
 RECALL COMPLETED
 INSTALL SWITCH BRKT
 RECALL COMPLETED REPLACED SW
 29334 RECALL 99S15 REPLACE DEACTIVATOR SWITCH AS PER RECALL
 PERFORM RECALL 99S15,
 COMPLETED RECALL
 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL
 PERFORMED RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 INSTALL RECALL SWITCH
 99S15 99S15
 PERFORM RECALL 99S15
 A DONE

REPLACE SPEED CONTROL SWITCH
 RECALL COMPLETE
 99S15 99S15

Box_Files

RECALL RECALL

RECALL 99S15

99348 INSTALL RECALL 99S15 WARRANTY INSTALL SWITCH AND WIREPLUG

REPLACED DEACTIVATION SWITCH

PERFORM RECALL

3 COMPLETED RECALL

REPLACED C CONTROL DEACTIVATION SWITCH PER RECALL 99S15

RECALL PERFORMED SPEED CONTROL DEACTIVATION SWT

RECALL 99S15

REPLACED SPEED CONTROL CABLE

02507 PERFORM RECALL REPLACE DEACTIVATION SWITCH

PERFORMED THE RECALL 99S15

PERFORMED RECALL 99S15

104578 RECALL 99S15, R&R DEACTIVATION SWITCH AND CONNECTOR, RETURNED PARTS

RECALL 99S15 RECALL DONE

80884 RECALL 99S15 WPC RECALL 99S15

R&R CRUISE CONTROL DEACTIVATION SWITCH AND HARNESSCONNECTOR PER RECALL 99S15

RECALL 99S15 RECALL

72708 RECALL INSPECT AND REPLACE SPEED SWITCH ASSY

REPLACED DEACTIVATION SWITCH.

1 COMPLETED RECALL AS NEEDED 1

99S15B REPLACED DEACTIVATION SWITCH

REPLACED CRUISE DEACT SWITCH

PERFORM RECALL 99S15 SPEED CONTROL CABLE

COMPLETE RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH

11278 INSPECT VEHICLE FOR DEACTIVATION SWITCH. REMOVE AND REPLACE SWITCH AND CONNECTOR. AS PER RECALL 99S15.

103888 REPLACE SWITCH PER 99S15

99S15-3511 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA

00889 RECALL R-R CRUISE SHUT-OFF SWITCH AS PER RECALL AND BLEED BRAKES

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

82188 PERFORMED RECALL

138548 REPLACED SW. AND CONECTOR.

OPEN RECALL COMPLETE RECALL

99S15B REPLACED SPEED CONTROL - CANCELLATION SWITCH & CONNECTOR SHELL AS

COMPLETE RECALL

PERFORM RECALL 99S15

02820 REPLACED SPEED CONTROL SWITCH, S-2 0274

PERFORM RECALL 99S15 --INSTALL SPEED CONTROL SWITCH

PERF. RECALL

99S15B RECALL 99S15B RECALL

REPLACE SWITCH

G RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

Box_Files

REPL SWITCH PER RECALL 99S15
99S15 99S15

REPLACE CRUISE SWITCH AS PER 99S15 RECALL 1

PERFORMED RECALL 99S16
88409 RECALL 99S15 8310 REPLACE SWITCH & PLUG G
2 99S15B .5 ADMIN .1 INSTALLED NEW SWITCH PER RECALL
REPLACE SPEED CONTROL CABLE AS PER RECALL 99S15
INSTALL SWITCH ANF PLUG CONN
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
RECALL RECALL
RECALL 99S15 INSTALLED MODIFICATION FOR CRUISE CONTROL
INSTALL BRAKE SWITCH AND CONNECTOR
PERFORM RECALL 99S16
50102 REPLACED SPEED CONTROL SWITCH, S-2 2874
99S15B .5 HR. REPLACE CRUISE CONTROL DEACTIVATION SWITCH.
REPLACE SWITCH PER RECALL
99S15 99S15
99S15 99S15
124068 RECALL 99S15 WR PERFORMED RECALL 99S15

PERFORM RECALL

— RECALL COMPLETED
REPLACED SPEED CONTROL SWITCH

COMPLETED RECALL 99S15
REPLACED DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
99S15 RECALL
OWNER NOTIFICATION: CRUISE CONTROL RECALL 99S15
88035 PERFORM RECALL 99S15
88177 LABOR OP 99S15B .5 HR
122409 RECALL 99S15 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15.
COMPLETED RECALL
PERFORM RECALL AS PER INSTRUCTIONS
81634 99S15B 0.5 ADMIN 0.1
99S15 99S15
INSTALLED CRUISE CONTROL CANCEL SWITCH PER RECALL 99S15
99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

1 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH
PERFORMED RECALL REPLACED THE SWITCH AND CONNECT OR
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
PERFORMED RECALL 99S15 INSPECTED AND REPLACED CRUISE DEACTIVATION SWITCH
REPLACE BRAKE SWITCH AS PER RECALL
REPLACED SWITCH & CONNECTOR PER RECALL
COMPLETED RECALL 99S15 REPLACEMENT OF SPEED CONTROL SWITCH-IDD 99S15B.
RECALL 99S15 28968 MILES RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

Box_Files

111570 00S15B 0.5 HRS. SPEED CONTROL RECALL
 RECALLED BY FORD PERFORMED RECALL
 00S01 00S15 W REPLACED SPD CTRL DEACTIVATE SW. 2745
 REPLACED SWITCH AND CONNECTOR.
 TECH 160 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND WIRING CONNECTOR AS PER RECALL 00S1
 PERFORM RECALL 00S15
 00S70 00S15 W REPLACED SWITCH
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL.
 INSTALL DEACTIVATION SWITCH
 PERFORM RECALL 1
 PERFORMED RECALL 00S15 PERFORMED RECALL 00S15B
 PERFORM RECALL
 PERFORM RECALL 00S15 A99
 REPL CONNECTOR 00S15
 RECALL IS REQUIRED COMPLETE RECALL
 REPLACED CRUISE SWITCH PER RECALL 00S15
 PERFORMED 00S15 RECALL
 REPLACED CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR BLEED BRAKES.
 RECALL REPLACE DEAC SWITCH PER RECALL
 DIAG AND PERFORMED RECALL 00S15 INSTALLED NEW DEACTIVATION SWITCH OK NOW
 REPLACE BRAKE SWITCH AS PER RECALL
 1 INSTALL UPDATED CRUISE RECALL SWITCH
 COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 PER NOTIFICATION RECALL 00S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 00S15 RECALL INSTRUCTIONS
 70678 RECALL & PERFORMED REPAIR PER RECALL
 PERFORM RECALL PER FORD NOTICE
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 00S15B 0.5, ADMIN 0.1
 44683 79 PERFORM 00S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH
 PERFORM RECALL 00S15 REPLACE SWITCH
 00S15 COMPLETED
 PERFORM RECALL 00S15
 REPLACED DEACTIVATION SWITCH.
 43316 .5 INSTALLED NEW DEACTIVATION SWITCH
 100525 RECALL 00S15 WVR RECALL 00S15
 REPLACED SWITCH AND CONNECTOR
 REPLACE CRUISE CONTROL SWITCH AND CONNECTORS AS PER RECALL
 REPLACE BRAKE LIGHT SWITCH
 PERFORMED RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 00S15
 SPEED CONT REPL CABLE
 RECALL 00S15 RECALL 00S15
 - MODIFY PER RECALL 00S15
 00S15 00S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 77517 REPLACE SPEED CONTROL SWITCH AND CONECTOR RECAL 00S15B
 04387 RECALL REPLACE DEACTIVATION SWITCH
 REPLACE SPEED CONTROL SWITCH AS PER RECALL 00S15
 PERFORM RECALL.....

1982-02-0 2424

Box_Files

132- SPD CONTROL SWITCH RECALL - 98S15-INSPECT & REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH
 32009 98S15 W PERFORMED SERVICE 98S15
 REPLACED SWITCH AND CONNECTOR
 REPLACE SPEED SWITCH AS PER RECALL
 REMOVED AND REPLACED SWITCH AND CONNECTOR AS PER RECALL
 INSPECT FOR RECALL INSTALL SPEED CNTRL DEACTIVATION SWITCH RECALL COMPLETE
 PERFORM RECALL
 REPLACE SWITCH
 98S15 RPL SPEED CONTROL DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH AND CONNECTOR

PERFORM RECALL 98S15
 134674 PERF RECALL
 REPL SPEED CONTROL DEACTIVATION SWITCH AND CONN
 RECALL PERFORMED RECALL
 REPLACE SWITCH RECALL 98S15
 DOES NOT OPERATE PROPERLY INSTALLED DEAVTIVATION AS PER RECALL
 PERFORM RECALL
 REPLACED SPEED CONTROL SWITCH AS PER RECALL
 REPLACED DISENGAGE SWITCH PER RECALL 98S15.

INSTALL CRUISE CONTROL DEACTIVATION SWITCH
 RECALL 98S15 REPLACE C-C SW
 46263 98S15 COMPLETED RECALL
 REPLACE SWITCH
 PERFORMED RECALL REPLACED CRUISE SWITCH
 REPL SWITCH PER RECALL 98S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH CONNECTOR AS PER RECALL 98S15
 PERFORM RECALL 98S15
 RNAD R CRUISE CNTRL SWITCH AND CONN
 R&R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL
 PERFORMED RECALL PERFORMED RECAL
 REPLACE SPEED CONTROL SWITCH
 62830 RECALL 98S15 98S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15.
 67094 RECALL INSTALL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
 INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 98S15
 PERFORM RECALL
 98S15 RECALL 98S15 RECALL COMPLETE
 REPLACED SPEED CONTROL SWITCH
 PERFORM RECALL 98S15
 112882 8 SPEED CONTROL DEACT. S-W REPLACED PER RECALL
 93282 98S15 W REPLACED SPD CTRL DEACTIVATE SW 2745

REPLACE SWITCH
 RECALL 98S15 RECALL
 RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT
 104650 RECALL CRUISE DEATERVATION SWITH I DID REPLACE SWITCH AND CONNECTOR TEST DROVE VEHECLE OK DRIVERS SEAT ON VEHECLE IS BROKEN AND ANTI LOCK I

EM62-625-A 3425

Box Files

134011 RECALL INSTALL SWITCH AND PLUG PER RECALL
 124356 .5 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 5582
 PERFORMED 99S15 RECALL
 RECALL PERFORMED RECALL
 AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL
 1 REPLACE SWITCH AS PER RECALL
 PERFORM RECALL 99S15
 PERFORM RECALL 99S15
 1 PERFORMED RECALL
 REPLACED BRAKE SWITCH PER RECALL BLEED REAR BRAK
 REPL SPEED CONTROL SWITCH

123316 PERFORM 99S15 RECALL DONE
 1 PERFORM RECALL AS OUTLINE
 12 REPLACED CONNECTOR AND DEACTIVATION SWITCH PER RECALL 99S15
 REPLACE SWITCH AS PER 99S15
 REPLACED SWITCH
 COMPLETED RECALL 99S15 PER PROGRAM.
 PERFORMED RECALL AS PER 99S15
 REPLACE SWITCH AND HARNESS PER RECALL
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
 RECALL 82073 REPLACE SWITCH AND CONNECTOR
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 1 COMPLETED RECALL
 APPLIED RECALL 99S15

PERF. RECALL
 CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA
 REPLACED SPEED CONTROL DEACTIVATION SWITCH.
 78121 RECALL AND STRIPPED SWITCH BLOCK REPLACED DEACTIVATION SWITCH AND HARDSHELL DURING SWITCH REPLACEMENT THREADS CAME OUT OF SWITCH BLOCK
 PERFORM RECALL-INSTALL SHIELDS
 99S15 RECALL SPEED CONTROL DEACT SWITCH PERFORMED 99S15 RECALL

123009 RECALL 99S15 PERFORM RECALL 99S15
 RECALL 99S15 COMPLETED RECALL
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
 REPL SPD CNTRL DEACTIVATION SW
 PERFORMED RECALL
 1 INSTALLED SWITCH

REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15B .5 REMOVED TAPED AND SECURED SPEED CONTR
 TECH 31 PERFORMED RECALL 99S16 INSTALLED SPEED CONTROL DEACTIVATION SWITCH
 1 PERFORMED A SAFETY RECALL AS TO REMOVE AND REPLACE THE DEACTIVATOR SWITCH FOR THE CRUISE CONTROL AND BRAKE SYSTEM

REPLACED SWITCH AS PER RECALL 99S16
 99909 RECALL REPLACED SWITCH AND WIRE PLUG PER RECALL 99S16
 99S16 99S16 REPLACED DEACTIVATION SWITCH

Box_Files

REPLACED SC DEACTIVATION SWITCH 98S15
 PERFORM RECALL 98S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 98S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 PERFORM RECALL
 A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 1
 70390 W REPLACE SWITCH GA
 RECALL 98S15 PERFORM RECALL 98S15
 RECALL 98S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15
 A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 TECH 33 PERFORMED RECALL 98S15 REPLACE SPEED CONTROL CABLE
 REPLACE SPEED CONTROL SWITCH #98S15
 REPLACED SC DEACTIVATION SWITCH 98S15
 RECALL RECALL
 94778 PERFORMED RECALL 98S15 REPLACEMENT OF SPEED CONTROL DEACTIVATION SWITCH AND SWITCH HARD SHELL PLUG.
 98S15 98S15
 98S15 RECALL 98S15 RECALL, REPLACE BRAKE SWITCH AND REWIRE CONNECTOR
 134908 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 31776 PERFORMED RECALL 98S15
 PERFORMED RECALL
 98S15 REPLACED SWITCH AND CONNECTOR
 PERFORM RECALL 98S15 COMMENT, GEAR SHIFT HARD TO MOVE BEFORE REPAIRS
 OPEN CONTROL ASSEMBLY-AIR CONDITIONER - REPLACE
 1 PERFORMED 98S15 RECALL
 PERFORM SPEED CONTROL SW RECALL 98S15
 REPLACED CRUISE CONTROL SWITCH FOR RECALL
 SUPPLEMENT #1 5-88 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 COMPLETED RECALL 98S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 PERFORMED 98S15
 RECALL 98S15 COMPLETED RECALL
 REPLACE PRESSURE SWITCH PER RECALL
 INSTALLED CRUISE RECALL 98S15
 INSTALLED SWITCH AND CONNECTOR
 REPLACED SPEED DEACTIVATION SWITCH
 RECALL COMPLETED
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 RECALL 98S15 INSTALLED SWITCH PER RECALL
 1 INSTALL KIT
 REPLACE SWITCH AND HARNESS PER RECALL
 98S15 98S15
 REP SPEED CONTROL CABLE AS PER RECALL
 REPAIR AS PER RECALL
 98S15 RECALL 98S15 RECALL COMPLETE
 97890 98S15 RECALL, REPLACE SW AND SHELL

0000-000-0 3427

1 REPLACED DEACTIVATION SWITCH PER VEHICLE RECALL

INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15

REPLACE SPEED CONTROL SWITCH AND PLUG

UNKNOWN INSTALL SWITCH AND CONNECTOR PER 99S15

RECALL RECALL

REPLACED DEACTIVATION SWITCH PER RECALL 99S15.

PERFORM RECALL 99S15

REPLACE SPEED CONTROL SWITCH

RECALL - - PERFORMED RECALL # 08375

REPLACE SPEED CONTROL DEACTIVATION SWITCH

DIAGNOSE AND REPLACED CRUISE CONTROL SWITCHES

RECALL LETTER PERFORMED RECALLS AS PER FACTORY INSTRUCTIONS

REPLACE DEACTIVATOR SWITCH PER RECALL

99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

INSTALLED KIT 99S15 RECALL PERFORMED

99S15 99S15 COMPLETED

PERFORM SPEED CONTROL DEACTIVATION RECALL

1 INSTALL KIT

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACED SPEED CONTROL SWITCH AND PLUG AS PER RECALL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

REPLACE CRUISE CONTROL SWITCH

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL

X PERFORMED RECALL

PERFORMED 99S15 RECALL

PERFORMED RECALL 99S15 CHECK AND REPLACED CRUISE CONTROL CABLE

PERFORMED RECALL 99S15 PER INSTRUCTIONS

RECALL DH R R DEACTIVATION SWITCH PER 99S15

R AND R SPD CRL CONNECTOR AND SWITCH ASSEMBLY

PERFORMED RECALL INSTALLED 80P PARTS

1 COMPLETED RECALL 99S15 SPEED CONTROL

48887 99S15 RECALL W RR DEACTIVATION SWITCH PER 99S15 RECALL

INSTALL NEW SWITCH

REPLACED SWITCH AND CONNECTOR PER RECALL

REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15

RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

99S15 PERFORMED 99S15 RECALL

REMOVED AND REPLACED CRUISE CONTROL DEACTIVATOR SWITCH AND CONNECTOR AS PER RECALL

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS NOTED IN RECALL 99S15 ALL OK TO RELEASE

RECALL 99S15

REPLACE SWITCH

RECALL RECALL

106402 RECALL 99S15 PERFORM RECALL 99S15

REPLACE SWITCH PER 99S15

99S15 99S15

Box Files

PERFORMED RECALL AS PER INSTRUCTIONS

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL

80281 PERFORM RECALL

PERFORM RECALL

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SECURED SPEED CONTR
PERFORMED RECALL

85186 RECALL 99S15 RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH

99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL

PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION

X

99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

PERFORMED RECALL 99S15 REPLACED CONTROL SWITCH AND CONNECTOR

FACTORY RECALL COMPLETED

82448 CC RECALL REPLACED SPED CONTROL DEACTIVATION SWITCH ROAD TEST ALL OK RECALL 99S15

INSTALL CRUISE SWITCH PER RECALL

RECALL 99S15 RECALL

R AND R CONNECTOR AND SWITCH AS PER RECALL

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SECURED SPEED CONTR

RECALL REPLACED SPEED CONTROL SWITCH AS PER RECALL

TYPE 2 PROGRAM 99S15 PERFORM RECALL PER GUIDEL

RECALL DH REPLACE DEACTIVATION SWITCH AND CONNECTOR

90181 99S16 RECALL 99S15 REPLACE DEACTIVATOR SWITCH

PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN RECALL BULLETIN REPL DEACTIVATION SWITCH, PER 99S15

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPL CRUISE CONTROL SWITCH

RECALL RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AND BLEED BRAKES PER RECALL

RECALL 99S15 INSTALLED MODIFICATION FOR CRUISE CONTROL

REPAIRED AS PER RECALL 99S15

PERFORMED RECALL

RECALL 99S15 PERFORM RECALL 99S15

RECALL 99S16 - B - RECALL

77472 RECALL 99S15 PERFORMED RECALL 99S15 AS PER FORD

PERFORMED RECALL 99S15

PERFORM RECALL

AS PER RECALL 99S15 RECALL TO REPLACE HARDSHELL CONNECTOR

INSTALLED MASTER CYLINDR SWTH

REPLACE SPEED CONTROL SWITCH

REPLACE BRAKE PRESSURE SWITCH PER RECALL

REPLACE SPEED CONTROL SWITCH

08720 INSTALL SPEED CONTRQ DEACTIVATION SWITCH

PERFORM RECALL

NA 99S15 REPLACED SWITCH

COMPLETE RECALL

29411 PERFORM RECALL 99S15

PER RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH

8902-025-9 3428

Box_Files

98S15B .5 ADMIN .1 PERFORM RECALL 98S15, INSTALL SWITCH AND CONNECTOR END
 98S15 RECALL
 PERFORM RECALL 98S15
 93243 PERFORMED RECALL 98S15
 85219 WARR PERF RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH
 UNKNOWN RECALL COMPLETE
 REPLACE SPEED CONTROL CABLE AS PER RECALL 98S165
 REPLACED DEACTIVATION SWITCH AND CONNECTOR
 REPLACED SPEED CONTROL DEACTIVATION SWITCH.
 PER FACTORY RECOMMENDATIONS INSPECTED AND FOUND VEHICLE HAS VACUUM OPERATED SPEED CONTROL SYSTEM
 1 PERFORMED RECALL
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 REPLACE BRAKE SWITCH AS PER RECALL
 REMOVE TAPE AND SECURE LABOR OP 98S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 98S15B .5 REMOVED TAPED AND SECURED SPEED CONTR
 REPL DEACTIVATION SWITCH 98S15
 98S15
 RECALL 98S16 INSTALLED SWITCH PER RECALL
 PERFORMED RECALL
 COMPLETE RECALL
 01 RECALL 98S15
 101785 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
 PERFORMED RECALL
 1 COMPLETED RECALL 98S15
 R&R SPEED CONTROL SWITCH AS PER 98S15
 PERFORM RECALL 98S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 TEST GEM REPL CTM PER 04S19
 CRUISE CONT 98S15 INST SWITCH
 REPLACED DEACTIVATION SWITCH
 98S15E PERFORMED RECALL-INSTALLED NEW CRUISE CONTROL DEACTIVATION SWITCH

 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL 98S15 INSTALL SWITCH
 RECALL 98S15 98S15 REPLACE SPEED CONTROL SWITCH
 OPEN RECALL PERFORMED RECAL
 INSTALL DEACTIVATION SWITCH 1
 98S15 98S15
 RECALL 98S15 REPLACED SWITCH
 REPLACE SWITCH
 PERFORM RECALL AND REPAIR RELATED DAMAGE. OPERATION CODES: 9818A & 14528A THESE ARE THE RELATED DAMAGE.
 COMPLETED 98S15 RECALL 98S15B .5 ADMIN .1 1
 INSTALL AS PER RECALL 98S15
 RECALL 98S15 RENEW CRUISE DEACT SWITCH AND CONN
 R AND R CRUISE SWITCH AND CONNECTOR ASSEMBLY
 PERFORMED RECALL
 86725 SAFETY RECALL INSPECTED AND REPLACED BRAKE SWITCH DEACTIVATOR AND CONNECTOR
 PERFORMED RECALL
 18035 COMPLETED RECALL 98S15
 DO THE RECALL
 INSTALL NEW SWITCH PER RECALL

5862-825-A 3438

Box_Files

57378 RECALL 98S15 RECALL 98S15
INSTALLED SPEED CONTROL CABLE AS PER RECALL
COMPLETED RECALL 98S15, SPEED CONTROL SWITCH
PERFORMED RECALL 98S15
77000 PERFORMED RECALL 98S16, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
CHECK AND REPLACE SWITCH PER RECALL
RECALL COMPLETED
40012 98S16B 0.5 ADMIN 0.1
PERFORMED RECALL 98S16
REPLACE AS PER RECALL 98S15
INSPECTED CRUISE CONTROL SWITCH OPERATION AND REPLACED BRAKE REPAIR KIT AS NEEDED FOR RECALL REPAIR
PERFORM RECALL 98S16 SPEED CONTROL

PERFORMED RECALL
REPLACE CRUISE CONTROL DEACTIVATION SWITCH
REPLACE CRUISE CONTROL DEACT SWITCH
71904 98S15B-.5 .5 REPLACE SPEED CONTROL SWITCH AS PER RECALL 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH
51158 PERFORMED RECALL 98S15
RECALL 98S15 INSTALL SWITCH
CK OUT FOUND DEACTIVATION SWITCH FAULTY REMOVE AND REPLACE SWITCH
INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD MOTOR CO. F
1 REPLACED CRUISE DEACTIVATION SWITCH PERFORMED RECALL 98S15B
98S15 98S15
PERFORMED RECALL
RECALL 98S15
PERFORM RECALL
PERFORMED RECALL
84582 RECALL 98S15 B .5
RECALL COMPLETED
PERFORMED RECALL 98S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION

RECALL 98S15

PERFORM RECALL 98S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH
COMPLETE RECALL 98S15
R&R CRUISE DEACTIVATOR
REPL DEACTIVATION SWITCH
PERFORMED RECALL 98S15
OPEN RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH
COMPLETE REPLACED SPEED CONTROL BRAKE DEACTIVATOR SWITCH & CONNECTOR AS PER RECALL
75201 MALFUNCTIONING DEACTIVATION SW R+R SW AND HARD SHELL CONNECTOR
RECALL 98S15 COMPLETED
REPLACED SPEED CONTROL SWITCH PER RECALL
PERFORMED RECALL 98S15
PERF RECALL 98S15

2002-02-09 09:34:51

Box_Files

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
RECALL COMPLETED

99-8-15 99-8-15 COMPLET
RECALL COMPLETED
RECALL 99S15 PERFORMED 1
RECALL 99S15 RECALL
REPLACED LIGHT SWITCH ASSEMBLY AND CONNECTOR AS PER RECALL
99S15 REPLACED SWITCH AND CONNECTOR
REPAIR PER 99S15 RECALL

RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

93845 99S16B 0.5 ADMIN 0.1

RECALL REPLACE SWITCH PER RECALL
77097 INSTALL KIT RETURN OLD PARTS TO NATE
REPLACED LIGHT SWITCH ASSEMBLY AND CONNECTOR AS PER RECALL
INSTALLED DEACTIVATION SWITCH
78291 RECALL 99S15 REPLACE SW AND ROAD TEST
PERFORMED RECALL
RECALL RECALL
INSPECTED, REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
PERFORMED SPEED CONTROL RECALL
COMPLETE RECALL 99S15
1 PERFORMED RECALL AS TO REMOVE AND REPLACE THE DEACTIVATOR SWITCH FOR THE CRUISE CONTROL AND BRAKE SYSTEM
99448 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL
RECALL COMPLETED
PERFORM RECALL 99S15
PERFORMED RECALL 99S15-INSPECTED AND REPLACED CRUISE DEACTIVATION SWITCH
RECALL 99S15 PERFORMED RECALL 99S15
1 INSTALLED SPEED CONTROL SWITCH
99S15 RECALL 99S15 COMPLETE
PERFORMED 99S15 RECALL

RECALL 99S15 REPLACE C-C SW
REPLACE SWITCH AND CONN PER PROGRAM
RECALLED BY FORD PERFORMED RECALL 99S15
99S15 REPLACE SWITCH
PERFORM RECALL 99S15 CRUISE SWITCH REPLACEMENT
COMPLETED RECALL 99S15, SPEED CONTROL SWITCH

PERFORMED CRUISE CONTROL RECALL
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACED SWITCH AND CONNECTOR PER RECALL 99S15
RECALL SPEED DEACT SWITCH MODIFICATION
INSTALL SPEED CONTROL DEACTIVATION SWITCH 1

2002-020-1 3432

Box_Files

REPLACED SENDER & CONNECTOR PER RECALL 98S15
 53885 PERFORM RECALL
 REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
 RECALL 98S15 PERFORMED RECALL 98S15
 PERFORM RECALL 98S15

RECALL 98S15 AE PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 1 PERFORMED RECALL 98S15

RECALL 98S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH
 RECOMMENDED REPAIR REPLACE SWITCH AND CONNECTOR
 RECALL 98S15
 98S15 98S15
 RECALL 98S15 PERFORMED RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

REPLACE SWITCH AND HARD SHELL
 REPLACED SPEED CONTROL SWITCH AS PER RECALL
 COMPLETE RECALL
 98S15 98S15 PERFORM RECALL
 OR RECALL RECALL
 RECALL 98S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
 SPEED CTRL DEACTIVATION SWITCH 98S15 REPAIR PER RECALL
 REPLACED THE SPEED CONTROL SWITCH PER RECALL
 SWITCH 98S15 DEACTIVATION SWITCH
 CHECKED AND VERIFIED CONCERN, RAN CIRCUIT TESTING, FOUND OPE N CIRCUIT AT SWITCH,, REMOVED AND REPLACED SWITCH
 COMPLETE REPLACED CRUISE DEASTIVATOR SWITCH & CONNECTOR
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98S15
 DO RECALL 98S15
 PERFORMED RECALL 98S15
 RECALL
 REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH AND REPLACE CONNECTOR END PER RECALL 98S15.
 COMPLETED RECALL
 PERFORMED RECALL
 RECALL 98S15, REPLACE DISINGAGEMENT SWITCH
 83754 RECALL REPLACE SWITCH AND CONNECTOR PER RECALL
 88868 RECALL W REPLACE SWITCH GA
 PERFORMED RECALL 98S15 REPLACE SPEED CONTROL DE ACTIVATION SWITCH
 RECALL 98S15 INSTALLED SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 1 REPLACE CRUISE CONTROL SWITCH.
 RECALL RECALL
 COMPLETED RECALL

8882-025-A 3435

Box_Files

OPEN RECALL PERFORMED RECALL
 PERFORM RECALL 99S15
 REPLACED DEACTIVATION SWITCH
 DO 99S15B
 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 99S20 RECALL 99S15 INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL INSTRUCTIONS
 . REMOVE TAPE AND SECURE DEACTIVATION SWITCH 99S15E.3
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH
 ? PERFORM RECALL 99S15 CRUISE CONTROL SWITCH REPL.
 RECALL 99S15 PERFORMED RECALL 99S15
 RECALL COMPLETED
 PERFORMED RECALL
 RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONNECTOR PER RECALL
 RECALL 99S15 REPLACED CRUISE CONTROL SWITCH
 INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15

 COMPLETE RECALL
 DO 99S15B
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 RECALL 99S15
 RECALL COMPLETED
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACE CONNECTOR AND SWITCH PER RECALL

 94717 INSTALL REVISED PRESSURE SWITCH (SPEED CONTROL DE-ACTIVATION SW.) KIT.
 REPLACED PER RECALL
 99S15 RECALL
 REFORMED RECALL 99S15
 99S16 RECALL REPLACE SWITCH AS PER RECALL
 INSTALL CRUISE CONTROL SWITCH PER RECALL
 PERFORM 99S15 RECALL REPLACE DEACTIVATION SWITCH
 RECALL RECALL
 RECALL 99S201 REPLACE SWITCH AND CONNECTOR
 22636 W REPLACE SWITCH GA
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.
 70189 W REPLACE SWITCH ME
 INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND WIRE CONNECTOR.
 1 COMPLETED RECALL 99S15 SPEED CONTROL RECALL
 INSTALLED DEACTIVATION SWITCH PER INSTRUCTIONS ON RECALL 99S15
 046 DIAGNOSIS AND REPLACED CRUISE DEACTIVATION SWITCH
 RECALL 99S15 INSTALLED SWITCH
 INSTALL NEW SWITCH
 REPLACED SPEED CONTROL CABLE PER RECALL 99S15
 1 PERFORM RECALL
 INSTALLED SWITCH PER RECALL
 SPEED CONTROL PERFORMED RECALL 99S15 R AND R DEACTIVATION SWITCH AND CONNE AND BLEED ALL FOUR BRAKES
 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 RECALL 99S15

8902-025-A 3434

Box_Files

PERFORMED RECALL 99S15
FACTORY RECALL COMPLETED RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETE RECALL 99S15
RECALL 99S15 - B - RECALL
RECALL 99S15 PERFORMED RECALL 99S15
PERFORMED SAFETY RECALL 99S15
REPLACE COMPLETED

1 ACCESS INSPECT & REPL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL 99S15

PERFORMED RECALL

PERFORMED RECALL

1 PERFORMED RECALL

REPLACED DISENGAGE SWITCH PER RECALL 99S15.

E RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACED SWITCH AS PER RECALL

DIAG AND PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH OK NOW DISABLED ON RO 28729 THIS ON RO 28729 VOIDED BECAUSE OF DATE

REPLACE SWITCH AND HARDSHELL PER RECALL.

99S15 99S15

RECALL - - PERFORMED RECALL # 0636

108728 RECALL WR RECALL 99S15

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

RECALL 99S15 COMPLETED

PERFORMED RECALL

PERFORM RECALL 99S15B REPLACE THE SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15 RECALL 99S15

RECALL 99S15 RECALL COMPLETED 99S16 RECALL COMPLETED

1 PERFORMED RECALL 99S15 - INSTALLED SWITCH

RECALL 99S15 INSTALLED SWITCH

TECH INSTALLED NEW CRUISE SWITCH PER FORD RECALL

TECH INSTALLED NEW CRUISE CONTROL SWITCH PER FORD RECALL

PERFORM RECALL

INSTALLED SWITC

UNKNOWN RECALL COMPLETE

PERFORMED SAFETY RECALL 99S15

08735 RECALL REPLACE DEACTIVATION SWITCH PER RECALL

REPLACE SWITCH AND CONNECTOR PER RECALL

102079 REPL SW.

PERFORMED RECALL

79985 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR TOAD TEST JH

127101 RECALL 99S15 WARR REPLACED DEACTIVATION SWITCH

00080 RECALL 99S15B J, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL

COMPLETED RECALL

RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

30330 RECALL WY REPLACE SWITCH GA

PERFORM RECALL 99S15

REPLACE DEACTIVATION SWITCH 1

47280 REPLACE BRAKE SWITCH AND CONNECTOR

Box_Files

INSTALLED SPEED DEACTIVATION SWITCH AS PER RECALL
RECALL DID RECALL

PERFORM RECALL 99S15- REPLACE CRUISE CONTROL SWITCH

PERFORMED RECALL

70960 99S16B 0.5 ADMIN 0.1

66983 RECALL W 99S15 REPLACED DEACTIVATION SWIT

COMPLETE INSTALLED SWITCH AS PER RECALL

INSTALL SWITCH AND HARD SHELL

21448 99S15 W REPLACED-CONTROL-DEACTIVATION-SWITCH-99S152

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 99S15

1 ACCESS & REPL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL 99S15

89015 PERFORMED RECALL 99S15

REPLD CRUISE DEACTIVATION SWITCH 99S15

INSTALLED DEACTIVATION SWITCH AS PER RECALL

99S15 SPEED CONTROL DEACTIVATION 99S15 SPEED CONTROL DEACTIVATION

PERFORM RECALL

RECALL DID RECALL

REPLACE SWITCH AS PER 99S15

99S16B 99S15B

REPLACE SWITCH AS PER RECALL

75969 REPLACE SPEED CONTROL DEACTIVATION SWITCH

1 OK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG

RPL SPEED CONTROL DEACTIVATION SWITCH AND CONNECT

83988 RECALL RECALL 99S15

99S15 99S15 PERFORMED RECALL

PERFORMED RECALL

PERFORM RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

RECALL 99S15 COMPLETED

DIH INSTALL DEACTIVATION SWITCH PER RECALL 99S15

REPAIRED AS PER RECALL

INSTALL SWITCH PER INSTRUCTIONS ON RECALL 99S15

PERFORM RECALL

OTHER 99S15 PERFORM RECALL

REPLACE DEACTIVATION SWITCH-WARRANTY-RECALL-BILL

118267 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

REPLACED THE SPEED CONTROL SWITCH PER RECALL

PERFORM RECALL 99S15

PERFORM RECALL 99S15 REPLACE SWITCH

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPL SWITCH PER RECALL

PERFORMED RECALL 99S15

Box_Files

RECALL 99S16 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH CONNECTOR
99S15 R&R DEACTIVATION SWITCH

99S15 99S16 RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD MOTOR CO. F
PERFORMED RECALL

179996 RECALL 99S15 PERFORM RECALL 99S15 REPLACING CRUISE CONTROL DEACTIVATION SWITCH *5 WP

1 DO 99S15 RECALL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR

PERFORMED RECALL

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

RECALL 99S15 PERFORMED RECALL 99S15

PERFORMED RECALL 99S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

REPLACE DEACTIVATION SWITCH PER RECALL 99S15

52252 RECALL 99S16 REPLACE CRUISE CONTROL SWITCH AND PLUG

RECALL 99S15

PERFORMED RECALL AS NEEDED ALL OK

105933 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUS

76882 INSTALLED NEW DEAC SW AND HARDSHELL CONN AS PER RECALL

PERFORMED RECALL

RECALL RECALL

INSTALLED NEW ACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL 99S15

94786 99S15 COMPLETED DEACTIVATION SWITCH RECALL

106253 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH.

REPL SWITCH

SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15

- MODIFY PER RECALL 99S15

PER NOTIFICATION 99S16 INSTALLED BRAKE REPAIR KIT PER RECALL INSTRUCTIONS

VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT

REPLACED DEACTIVATION SWITCH

COMPLETED RECALL

OTHER 99S16 PERFORM RECALL

REMOVE & REPLACE CRUISE DEACTIVATION SWITCH

REPLACED SWITCH AND CONNECTOR

INSTALL DEACTIVATION SWITCH AND CONNECTOR

126215 99S15 WARR REPLACED SWITCH

REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S16 RECALL

COMPLETED RECALL

REPLACED DEACTIVATION SWITCH.

RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL

49819 RECALL W REPL CRUISE SWITCH PER RECALL 99S16

99S16

99S16

Box_Files

RECALL 99S15
PERFORM RECALL
120777 INSTALLED DEACTIVATION SW AS PER RECALL 99S15
RECALL 99S15 COMPLETED
RECALL DONE
RECALL 99S15 REPLACED SWITCH
RENEW SPEED CONTROL DEACTIVATION SWITCH
PERFORMED RECALL AS REQUESTED
INSTALLED DEACTIVATION SWITCH AS PER RECALL

94548 COMPLETE RECALL 99S15
99565 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
1 PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH CRUISE CONTROL AND CONNECTOR

51320 PERFORM RECALL SPEED CONTROL SWITCH
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD MOTOR CO. F
INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL INSTRUCTIONS
99S15 99S15
INSTALL SPEED CONTROL
REPL DEACTIVATION SWITCH
120936 RECALL REPLACED CRUISE SWITCH 99S15B—.5 HRL
99S15 99S15
105089 OPEN RECALL 99S15 REPLACE SWITCH DONE
RECALL 99S15 COMPLETED

RECALL 99X15
RECALL 99S15 INSTALL RECALL KIT
PERFORMED RECALL
REPLACE BRAKE PRESSURE SWITCH PER RECALL
REPLACED SWITCH AND BLEED
REPLACED DEACTIVATION SWITCH
PERFORMED RECALL 99S15
71847 RECALLED REPLACED SWITCH AND WIRE PER RECALL
RECALL PERFORM RECALL 99S15
PERFORM RECALL 99S15

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B XS
UNKNOWN INSTALL CRUISE SWITCH AND CONNECTOR PER 99S15
RECALL 99S15 REPLACE DEACTIVATION SW
REPLACED BRAKE DEACTIVATION SWITCH PER RECALL
99S15 RECALL SPEED CONTROL DEACT SWITCH
RECALLED BY FORD PERFORMED RECALL
72396 99S15 W REPLACED SPEED CONTROL SW 2745
REPLACE SPEED CONTROL CABLE PER RECALL 99S15
REPLACED SPEED CONTROL SWITCH PER RECALL
REPLACED DEACTIVATION SWITCH
88830 INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL
RECALL ADD ON
RECALL RECALL

DN02-025-A 3438

Box Files

RECALL PERFORM RECALL PER PROGRAM 99S15, DEAC SWITCH
 1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X5
 99S30 RECALL WT DONE
 PER FACTORY RECOMMENDATIONS INSPECTED AND FOUND VEHICLE HAS VACUUM OPERATED SPEED CONTROL SYSTEM
 99S15 RECALL 99S15 RECALL COMPLETE
 99S15 99S15
 99S15 RECALL
 RECALL 99S15 - COMPLET
 1 COMPLETED RECALL 99S15
 INSTALL NEW SWITCH AND WIRE CONNECTOR
 PERFORM SAFETY RECALL
 99S15B RECALL
 99S15 RECALL 99S15 RECALL COMPLETE
 PERFORMED RECALL 99S15
 AS PER RECALL 99S15 RECALL TO SECURE DEACTIVATION SWITCH
 PERFORMED RECALL 99S15-INSTALL SWITCH
 FORD RECALL PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL
 E RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 BOX B REPLACED SPECIAL ORDEREDX CABLE FOR RECALL AND BLEED SYSTEM LN 51 CUT CABLE
 COMPLETED RECALL
 RECALL 99S15 COMPLETED
 REPLACED SWITC AND CONNECTOR PER RECALL
 REPAIR AS PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 RNR ACTIVATION SWITCH PERFORM RECALL 99S15
 RNR SWITCH PERFORM RECALL 99S15
 RECALL 99S15
 PERFORMED RECALL # 99S15
 REPLACE SWITCH PER RECALL LETTER
 REPLACED DEACTIVATION SWITCH
 99S15 99S15
 DID RECALL 99S15
 REPLACED DEACTIVATION SWITCH
 PERFORM RECALL
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 113444 RECALL INSTALLED RECALL ON BRAKE SWITCH
 RECALL IS REQUIRED COMPLETE RECALL
 COMPLETED RECALL
 RECALL 99S15 INSTALLED SWITCH
 PERFORMED RECALL E
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR (99S15B .5) COMPLETED
 PERFORMED RECALL 99S15
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
 55803 RECALL INSTALLED SPEED CONTROL RECALL
 UNKNOWN INSTALL SWITCH AND CONNECTOR PER 99S15
 REPLACE SWITCH AND CONNECTOR PER RECALL
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
 PERFORM RECALL REPLACE DEACTIVATION SWITCH

2002-02-04 3408

Box_Files

PERFORM RECALL
 DID RECALL 99S15
 REPLACED SPEED CONTROL SWITCH PER RECALL
 REPLACED DISENGAGE SWITCH PER RECALL 99S15
 RECALL INSTALL NEW CRUISE CONTROL DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15.
 RECALL CRUISE CONTROL RECALL 99S15
 99S15 99S15
 SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S
 PERFORMED RECALL 99S15 - REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 99S15 99S15
 INSTALL SW AND CONN
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 RECALL COMPLETED
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 REPL SWITCH PER RECALL 99S15
 1 PERFORMED RECALL 1
 REPLACED DEACTIVATION SWITCH
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
 OPEN RECALL PERFORM RECALL
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 PERFORMED RECALL
 PERFORMED RECALL 99S15
 77282 W RNR SPEED DEACTIVATION SWITCH AND CONNECTOR
 PERFORME 99S15
 PERFORM RECALL.....
 99S15 99S15 W REPLACE SPEED CTRL DEACTIVATE SW 2745
 117478 INSTALLED NEW ACTIVATION SWITCH AND CONNECTOR
 RECALL 99S15 99S15
 93018 PERFORM RECALL 99S15
 99S15 RECALL 99S15 RECALL REPLACED DEACTIVATION SPEED CONTROL SWITCH AND CONNE
 REPLACE SPEED CONTROL SWITCH
 COMPLETED RECALL
 99S15 99S15 REPLACE CRUISE SWITCH PER RECALL
 CHECK AND PERFORMED RECALL 99S15
 RECALL 99S15
 RECALL 99S15 RECALL 99S15
 PERFORMED RECALL

 INSTALLED CRUISE SWITCH AS TO RECALL
 PERFORMED RECALL 99S15 INSTALL CRUISE DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH
 PERFORM CRUISE SWITCH RECALL PER INSTRUCTIONS
 PERFORM RECALL 99S15

 REPLACE SWITCH & CONN
 RECALL COMPLETED
 REPLACE SWITCH PER RECALL

ENG-025-R 3446

Box_Files

RECALL
98815 RECALL
1 DB REPLACED SWITCH

REPLACE DEACT SWITCH
98815 RECALL

DEACTIVATION SWITCH OUT OF RANGE.
5999 W 98815 REPLACE SWITCH AND CONNECTOR PER RECALL GA
PERFORM RECALL 98815 CRUISE DEACTIVATION SWITCH
RNR DEACTIVATION SWITCH PERFORM RECALL 98815
REPLACE SPEED CONTROL CONTROL DEACTIVATION SWITCH PER RECALL 98815
98815
OPEN RECALL
REPLACED SAFETY SWITCH AND REPLACED WTRIS
PERFORM RECALL

47820 79 PERFORM 98815 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH

RECALL 98815
60780 98815B 0.5 0.5 PERFORM 98815
PERFORMED RECALL
SPEED CONTROL SWITCH 98815 REPLACE SWITCH
RECALL 98815 RECALL 98815
PERFORMED RECALL REPLACED THE SWITCH AND CONNEC TOR
X PERFORMED RECALL
37490 RC98815 PERF RC98815
87000 RECALL INSTALL DEACTIVATE SWITCH AND HARDSHELL CONNECTOR RETURN ORIGINAL PART IN TO PARTS DEPT
RECALL PERFORM RECALL PER PROGRAM 98815, DEAC SWITCH

RECALL 98815 RECALL
CRUISE RECALL COMPLETED AS PER RECALL 98815
CRUISE SWITCH 98815 INSTALL CRUISE SWITCH AND CONNECTOR
PERFORMED RECALL 98815-INSTALL SWITCH
98815 REPLACED SWITCH & CONECTOR PER RECALL
APPLIED RECALL 98815
PERFORMED RECALL 98815
INSTALLED DEACTIVATION SWITCH PER RECALL
PERFORM RECALL 98815
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98815
PERFORM SPEED CONTROL RECALL
REPAIR AS PER RECALL
1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98815B X5

76382 RECALL 98815 PERFORM RECALL 98815
RNR DEACTIVATION SWITCH PERFORM RECALL 98815
UNKNOWN INSTALL SWITCH AND CONNECTOR PER 98815
PERFORMED RECALL REPLACE SENSOR AS PER RECALL 9 8815
PERFORMED RECALL 98815
RECALL RECALL
111216 DEACTIVATION RECALL WT DONE
COMPLETED CAMPAIGN COMPLETED OF 98815B

5882-825-A 3441

Box_Files

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S16.
 REPL SWITCH PER RECALL 99S16
 ONP 99S16 ONP 99S16 SPEED CONTROL DEACTIVATION SWITCH
 REPLACED PARTS PER RECALL
 X COMPLETED
 99S16 99S16
 99S16 RECALL
 REPL SWITCH PER RECALL 99S16
 RECALL PERFORMED 1
 99S16B REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL
 REPLACED DEACTIVATION SWITCH AND CONNECTOR
 100446 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B
 REPL SWITCH PER RECALL 99S16
 1 RECALL COMPLETE
 INSTALL NEW SPEED DEACTIVATION SWITCH REPLACE W/ IRE AND BLEED BRAKES AS PER RECALL 99S16
 COMPLETED AS PER RECALL
 RECALL COMPLETED
 118108 RECALL 99S16 W/ PERFORM RECALL 99S16 REPLACE THE CONECTOR
 RECALLED BY FORD MOTOR CO REPAIR AS NEEDED
 PERFORMED RECALL 99S16 FOR CRUISE SWITCH
 REPLACE SWITCH
 118178 DO RECALL 99S16
 INSTALL SWITCH AND NEW HARD SHELL CONNECTOR AS OUTLINED IN RECALL
 99S16 RECALL
 REPLACED SPEED CONTROL SWITCH
 INSTALLED NEW SWITCH PER RECALL
 RECALL 99S16 COMPLETED
 RECALL 99S16
 RECALL COMPLETED
 NOTE: EST \$ 610 SEAT TRACK ASSY
 SWITCH 99S16

PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION
 86500 REPLACE SWITCH AND CONNECTOR PER RECALL
 RECALL 99S16 99S16
 PERFORMED RECALL 99S16
 82852 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR. SWITCH WAS SEIZED IN LINE BLOCK.
 1 PERFORMED RECALL 99S16 INSTALL BRAKES SW. CONNECTOR 99S15B
 1 PERFORMED RECALL 99S16
 PERFORMED RECALL 99S16
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S16
 RECALL 99S16 RECALL
 83487 INSTALLED CONNECTOR AND SWITCH
 99S16 99S16
 REPL SWITCH PER RECALL 99S16
 RECALL 99S16 PERFORM RECALL 99S16
 PERFORM 99S16 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT RECALL
 RPLC SPEED CTRL DEACTIVATION SWITCH PER 99S16
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S16

2002-02-01 11:34:42

Box_Files

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 PERFORM RECALL 99S15
 SPD CTRL DEACTIVATION SW REPLCMINTPERFORMED RECALL 99S15
 REPLACE SPEED CONTROL ACTIVATION SWITCH AS PER RECALL 99S15
 PERFORMED RECALL
 COMPLETED RECALL
 84392 99S15 W REPLACED SPEED CONTROL 2745
 INSTALLED SPEED DEACTIVATION SWITCH AS PER RECAL
 PERFORM PER RECALL 99S15
 PREFORM 99S15 AS INSTRUCTED
 REPLACED DEACTVATER SWITCH-WARANTY-RECALL--BILL NOTE--CHECK ENGINE LIGHT IS ON
 PERFORMED RECALL 99S15
 REPLACE BRAKE SWITCH AND CONECTOR
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
 REPLACED DEACTIVATION SWITCH
 PERFORM RECALL 99S15
 REPLACE SWITCH PER RECALL
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 INSTALL SPEED ACTIVATION SWITCH

RECALL 99S15 RECALL COMPLETE
 REPLACE PRESSURE SWITCH AND CONNECTOR
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL
 RECALL REPLACED THE DEACTIVATION SWITCH AND CONNECTOR, RETEST OK AT THIS TIME
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
 PRFORM RECALL
 REPL SWITCH PER RECALL 99S15
 PERFORMED RECALL REPLACED THE SWITCH AND CONNec OR
 RECALL 99S15 PERFORMED RECALL 99S15
 INSTALL SWITCH AND CONN
 99S15 REPLAE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 1 REPLACED SWITCH AS PER 99S15 1
 RECALL 99S15 INSTALL SWITCH
 99000 COMPLETED SPEED CONTROL DISABLE SWITCH RECALL INSTALLED NEW UPDATED SPEED CONTROL DISABLE SWITCH AND CONNECTOR TO VEHICLE TYPO ON MILAGE
 X INSTALLED CRUISE DEACTIVATION SWITCH

 99S34 REPLACE SWITCH AND CONNECTOR PER RECALL
 COMPLETE RECALL

REPLACED SPEED CONTROL SWITCH
 RECALL 99S15 REPLACED CRUISE CONTROL DEACTIVATION SW
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL
 RECALL 99S15 RECALL 99S15S

Box_Files

PERFORM RECALL 99S15

- MODIFY PER RECALL 99S15

1 PERFORM RECALL

PERFORM 99S15 RECALL AS INSTRUCTED

A DONE

PERFORM RECALL

PERFORM RECALL

A DONE

RECALLED BY FORD PERFORMED BY FD

57956 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH

COMPLETED RECALL

1 PERFORMED RECALL

RECALL 99S15 RECALL 99S15

COMPLETED AS PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL 99S15 COMPLETED

UNKNOWN INSTALL CRUISE DEACTIVATION SWITCH AND CONNECTOR PER 99S15

REPLACE CRUISE CONTROL SWITCH

85228 RECALL WARRANTY PERFORMED RECALL 99S15

APPLIED RECALL 99S15

PERFORM RECALL

REPAIR AS PER RECALL 99S15.

RECALL 99S15 REPLACED SWITCH

REPLACE BRAKE PRESSURE SWITCH PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RNR DEACTIVATION SWITCH PERFORM RECALL

TECH INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS INSTRUCTED IN RECALL 99S15

INSPECT & REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONN

PERFORMED RECALL 99S15 - CHECK AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

REPLACED DEACTIVATION SWITCH

REPLACED CONTROL DEACTIVATION SWITCH

RECALL 99S15

REPLACED DISENGAGE SWITCH PER RECALL 99S15

90818 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

SAFETY RECALL 99S15 - REPAIR PER RECALL

RECALL 99S15 PERFORM RECALL 99S15

99S15 RECALL

99S15 SPEED CONTROL DEACTIVATION SWITCH

REPLACE CRUISE CONTROL SWITCH

Box_Files

COMPLETED RECALL RECALL 99S15

88838 REPLACED DEACTIVATION SWITCH,CONNECTOR PER RECALL
REPLACE SPEED CONTROL SWITCH AND CONNECTOR
PERFORMED RECALL 99S15, INSTALLED NEW SPEED CONTROL DEAC. SWITCH AND CONECTOR.
COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
REPLACED SPEED CONTROL CABLE AS PER RECALL
58481 RECAL REPLAC BRKE SWITCH AND HARDSHELL CONNECTOR 5383,2843

108824 99S15 RECALL 99S15 REPLACE DEACTVATOR SWITCH
101474 INSTALLED RECALL 99S15, BRAKE PRESSURE SWITCH
PREFORM 99S15 AS INSTRUCTED
ONP 99S15 ONP 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHEL
82581 COMPLETED RECALL NUM 99S15
PERFORM RECALL
97882 RECALLED REPLACED SWITCH AND WIRE CONNECTOR PER RECALL
PERFORM RECALL 99S15
REPAIR PER RECALL
RECALL 99S15 REPLACED SWITCH.

REPLACED THE SWITCH PER RECALL 99S15
PERFORME 99S15
REPLACED SWITCH AS PER RECALL 99S15

REPLACE DEACTIVATION SWITCH RECALL 99S15.
80778 REPLACE SWITCH AND CONNECTOR PER RECALL
99S15 RECALL 99S15 REPAIR AS PER RECALL
RECALL 99S15 99S15

RECALL COMPLETED
REPAIR AS PER 99S15

A SHORT IN THE SPEED CONTROL SWITH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE ALSO A FIRE COULD DEVOPE. REMOVE TAPE AND SECURE THI
TECH INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS INSTRUCTED IN RECALL 99S15

PERFORME 99S15
RNR CRUISE SWITCH PERFORM RECALL 99S15
RECALLED BY FORD PERFORMED RECAL
99S15B PERFORMED RECAL
UNKNOWN INSTALL CRUISE SWITCH AND CONNECTOR PER 99S15
99S15B REPLACED
99S15,RNR CONNECTOR AND DEACTIVATION SWITCH
REPLACED SWITCH
CUSTOMER PAID REPAIRS 1
PERFORM RECALL PER MANUFACTURER PERFORMED RECAL
REPLACED SPEED CONTROL DEACTIVATIONM SWITCH AS PERRECALL 99S15
REPLACE SPEED CONTROL SWITCH
RECALL 99S15 COMPLETED
REPL DEACTIVATION SWITCH PER RECALL
99S15 RNR DEACTIVATION SWITCH

Box_Files

PERFORMED RECALL 99S15
INSTALLED NEW SWITCH PER RECALL
56214 RECALL INSTAL SWITCH AND CONNECTER AS PER RECALL 99S15
REPLACE SPEED CTRL DECT SWITCH AND SHELL CONNECTOR
RECALL 99S15
PERFORMED RECALL # 99S15
RECALL 99S15
PERFORM RECALL 99S15

1 PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS PERFORM RECALL 99S15-B
JH REPLACE SWITCH AND CONNECTOR PER RECALL
RECALL 99S15
COMPLETED AS PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
PERFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH BLEED BRAKES
RECALL COMPLETED COMPLETED RECALL 99S15B FOR .5 AND .1 FOR ADMIN. TIME
REPLACE CRUISE CONTROL CABLE
REPLACED KIT PER RECALL T
99S15 RECALL PERFORMED

REPLACE SWITCH AND CONNECTOR PER RECALL
REPLACED DEACTIVATION SWITCH
78109 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH
1 PERFORM RECALL
1 PERFORM RECALL 99S15 BRAKE SWITCH

99S15 99S15
1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
PERFORMED RECALL 99S15
RECALL 99S15 99S15
REPLACE SPEED CONTROL SWITCH
COMPLETED AS PER RECALL
COMPLETED RECALL 99S15 DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH
RNR DEACTIVATION SWITCH PERFORM RECALL
1 COMPLETED RECALL 99S15 SPEED CONTROL
REPL SWITCH PER RECALL 99S15
REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SECURED SPEED CONTR
RECALL REPLACE DEAC SWITCH PER RECALL
57692 RECALL INSTALLED NEW BRAKE SWITCH AND CONNECTOR TEST DROVE, CRUISE WORKS OK
REPLACE SPEED CONTROL CABLE AS PER RECALL
RECALL 99S15. REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15.

COMPLETED RECALL
REPLACED DEACTIVATION SWITCH

REPLACED SPEED CONTROL SWITCH AS PER RECALL
PERFORM RECALL
RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

Box_Files

23712 REPLACE SPEED CONTROL DEACTIVATION SWITCH TEST DRIVE OK
99S15 RECALL 99S15 RECALL PERFORMED
RECALL INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
INSTALLED SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15
RECALL 99S15 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL
RECALL 99S15
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.
REPLACE SWITCH AND CONNECTOR
PERFORM 99S15
PERFORMED RECALL 99S15
99S15 99S15 PERFORM RECALL
RECALL REPLACE DEACT SWITCH PER RECALL
99S15 99S15 COMPLETED DEACTIVATION SWITCH RECALL
PERFORM 99S15

REPLACE CONNECTOR AND SWITCH
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

REPAIR AS PER RECALL
COMPLETED RECALL
RECALL RECALL
78573 RECALL REPLACED SPEED CONTROL DE-ACTIVATION SWITCH AND TEST DROVE WORKS NORMAL
REPLACE SWITCH AND CONNECTOR
REPLACE BRAKE PRESSURE SWITCH PER RECALL
82373 RECALL INSPECT AND PERFORM RECALL
RECALL REPLACE DEACT SWITCH PER RECALL
RECALL 99S15 COMPLETED

THE SHORT MAY DISABLE THE SPEED CONTROL SYSTEM OR CAUSE A FUSE TO OPEN. AFTER INSPECTION, IF THE VEHICLE IS INVOLVED THE DEALER WILL REPLACE THE DEAC
99S15 RECALL SPEED CONTROL SWITCH
99S15
1 PERFORMED SWITCH AND CONNECTOR RECALL
SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.
REPAIR AS PER RECALL 99S15.
PERFORMED RECALL 99S15
REPAIR AS PER RECALL
INSTALL SWITCH AND CONNECTOR
53789 RECALL 99S15 W REPLACED DEACTIVATION SWIT
RECALL 99S15 REPLACED CRUISE DEACTIVATION SWITCH
RECALL 99S15 RECALL 99S15
REPLACED SPEED CONTROL CABLE PER RECALL
PERFORM RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
PERFORMED RECALL 99S15 BRAKE RELEASE
55664 RECALL WPB30 PERFORM 99S15 CRUISE SWITCH REPLACEMENT
REPLACED SWITCH PER RECALL
PERFORM RECALL 99S15
99S15B RECALL REPLACED DEACTIVAT. 99S15B RECALL REPLACED DEACTIVATION SWITCH

Box_Files

REPLACE SWITCH AND CONNECTOR PER RECALL 98S15 1
PERFORM RECALL 98S15. INSTALL CRUISE DEACTIVATION SWITCH
VEHICLE HAS AN OPEN RECALL. PERFORM RECALL

SPEED CONTROL DEACTIVATOR TECH REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 98S15
REPLACED BRAKE DEACTIVATION SWITCH
98S15 REPLACED SWITCH
INSTALLED SWITCH PER RECALL
REPLACED SWITCH PER RECALL
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
REPLACED C CONTROL DEACTIVATION SWITCH PER 98S15 RECALL
PERFORMED RECALL
PERFORM RECALL-INSTALL SPEED CONTROL DEACTIVATION SWITCH
INSTALL SWITCH AND CONNECTOR PER RECALL

PERFORMED 98S15B

98S15 RECALL
101112 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15
REPLACE SPEED CONTROL CANCEL SWITCH PER RECALL
COMPLETE RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.

INSTALL SPEED CONTROL SWITCH
1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5
007 COMPLETED RECALL 98S15
PERFORM RECALL
1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .B
67279 PERFORMED RECALL-INSTALLED PRESSURE SWITCH
44782 WARR REPLACED 98S15 SPEED CONTROL SWITCH
COMPLETE RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACED SWITCH FOR RECALL
PERFORMED RECALL 98S15
X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
1 PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH
REPLACE DEACTIVATION SWITCH PER RECALL
PERF RECALL 98S15
70880 WARR INSTALL CRUISE DEACTIVATION SWITCH
PERFORM RECALL
94090 REPLACE SPEED CONTROL SWITCH PER RECALL

RECALL 98S15 PERFORMED RECALL 98S15
66280 COMPLETED SPEED CONTROL DISABLE SWITCH. INSTALLED NEW UPDATED SPEED CONTROL DISABLE SWITCH
107439 RECALL 98S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH

1 PERFORMED RECALL
RECALL PERFORM RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL. WAITN

Box_Files

AS PER RECALL 99S15 RECALL TO REPLACE SPEED CONTROL CABLE
 COMPLETED OPEN RECALL 99S15
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .6
 OPEN RECALL COMPLETED
 99S15 RECALL PERFORMED
 RECALLED 99S15 PERFORMED
 99S15 99S15 PERFORM RECALL
 RECALL 99S15
 PERFORMED RECALL
 COMPLETED RECALL REPLACED BRAKE SWITCH PER CAMPAIGN
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR...PERMANENT REPAIR
 78107 99S15 RECALL W PERFORMED 99S15 RECALL. INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH.
 OPEN RECALL COMPLETE RECALL
 SPEED CNTRL DEACTVTN SWITCH RPLCMTPRF SAFETY RECALL 99S15
 99S15 99S15
 RECALL 99S15 SPEED CONTROL DEACTREPLACE DEACTIVATION SWITCH AND CONNECTOR, RECALL PERFORMED.
 1 PERFORMED RECALL
 REPLACED DEACTIVATION SWITCH PER RECALL 99S15

 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 INSTALLED SWITCH & CONNECTOR
 PERFORM RECALL ON SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL
 PERFORMED CRUISE CONTROL SWITCH RECALL 99S15
 204240 RECALL PERFORMED RECALL 99S15 - REPLACED DEACTIVATOR SWITCH AND CONNECTOR
 RECALL RECALL
 RECALL 99S15 PERFORMED RECALL 99S15
 PERFORM RECALL
 142484 RECALL WARR RECALL 99S15 REPLACE CONTROL DEACTIVATION - SWITCH
 NAC PERFORMED RECALL
 87923 1 REPLACED THE CRUISE DEACTIVATION SWITCH AND PLUG PER RECALL 99S15
 RECALL COMPLETED
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
 PERF RECALL 99S15
 REPLACE SWITCH
 RECALL COMPLETED
 0 99S15 PROGRAM
 RECALL 99S15 99S15 PERFORMED RECALL
 PERFORM RECALL 99S15B
 57475 RECALL W REPLACE SWITCH AND PLUG GA
 RECALL RECALL
 RECALL 99S15 COMPLETED
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 1 JOB COMPLETED
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL
 PERF RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 OPEN RECALL PERFORM 99S15 RECALL

Box_Files

PERFORMED RECALL
78858 INSTALLED BRAKE SWITCH RECALL
RECALL 99S15B
SPEED CONTROL STICKING PERFORMED 99S15 RECALL

INSTALLED SWITCH PER RECALL
1 PERFORMED RECALL 99S15, INSTALLED CRUISE CONTROL SWITCH AS PER RECALL
RPL CRUISE DEACTIVATION SWITCH
99S15 99S15
99S15 SWITCH CONNECTOR 99S15
1 PERFORMED RECALL
REPLACED SWITCH PER RECALL
PERFORMED RECALL
RECALL 99S15 COMPLETED
PERFORMED RECALL
20395 PERFORMED RECALL 99S15 3
INSTALL BRAKE REPAIR CONN KIT
PERF RECALL
PERFORMED RECALL 99S19
1 COMPLETED RECALL 99S15
REPLACE DEACTIVATION SWITCH AS PER RECALL

RECALL DONE
PERFORM DEACTIVATION SWT.
REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15
INSTALLED DEACTIVATION SWITCH AS PER RECALL
99S15 99S15 REFORMED
X RECALL
1 REPL DEACTIVATION SWITCH. 1
41385 DID RECALL 99S15 TECH 3213
99S15 RECALL 99S15 RECALL COMPLETE
REPLACE CRUISE SWITCH
24487 99S15 RECALL 99S15 REPLACE DEACTIVATOR SWITCH
RECALL 99S15 COMPLETED
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15
113082 99S15 99S15 5 COMPLETED RECALL AS PER 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH K
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
PERFORMED RECALL
PERFORM RECALL 99S15 DEACTIVATION SWITCH RECHECK OPERATION SYSTEM OK 99S15B 5 ADMIN 1
FACTORY RECALL COMPLETED RECALL
INSTALLED KIT 99S15 RECALL PERFORMED
87940 INSTALL SWITCH AND CONNECTOR
REPLACE SWITCH AS PER RECALL
RECALL 99S15 REPLACE SWITCH AND CONNECTOR
PER NOTIFICATION 99S15 REPLACE SWITCH AND HARNESS CONNECTOR PER RECALL INSTRUCTIONS
77779 REPLACED DEACTIVATION SWITCH AND CONNECTOR
21625 RECALL REPLACE CRUISE CONTROL SWITCH
RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

Box_Files

98S15 98S15
98078 98S15 PERF 98S15, .5+1=.8
DIAGNOSIS AND INSPECT FOR CAMPAIGN INSTALLED SWITCH PERFORM CAMPAIGN AS PER NOTICE
98S15 98S15
PERFORM RECALL
RECALL 98S15 CRUISE CONTROL REPLACE SWITCH AND CONNECTOR PER RECALL
83706 98S15B OLS- ADMIN 0.1 RECALL
COMPLETED CAMPAIGN REPLACED SWITCH

RECALL 98S15 REPLACE SWITCH AND CONNECTOR
98S15 98S15
X REPLACE CRUISE CONTROL DEACTIVATION SWITCH
RECALL 98S15 INSTALLED SWITCH PER RECALL
98406 RECALL 98S15 WARR REPLACED DEACTIVATOR SWITCH AND CONNECTOR PER RECALL 98S15
1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
REPLACE SPEED CONTROL SWITCH AND CONNECTOR

PERFORMED RECALL PER SPECS
FACTORY RECALL COMPLETED RECALL

VEHICLE HAS AN OPEN RECALL PERFORM RECALL
PERFORMED RECALL RENEW SWITCH AND HARDSHELL CONNECTOR
74012 RECALL REPLACE DEACTIVATION SWITCH
CRUISE RECALL 98S15 INSTALL CRUISE SWITCH AND CONNECTOR
1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
1 INSTALL SPEED CONTROL MODIFICATIONS
REPLACE SWITCH
REPLACE DEACTIVATION SWITCH
RECALL 98S15 - SPEED CONTROL DEACTIVATION SWITCH INSPECTED SWITCH. REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL
PERFORMED RECALL PERFORMED RECALL

REPLACED SPEED CONTROL SWITCH & CONNECTOR
REPLACED CRUISE CONTROL DEACTIVATION SWITCH

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH REPLACED SPEED CONTROL DE-ACTIVATION SWITCH AND CONNECTOR
53036 98S15 REPAIR ACCORDING TO 98S15
PERFORM 98S15 RECALL CRUISE CONTROL

CAMPAIGN 98-8-15 COMPLETED AS PER RECALL INSTRUCTION.
COMPLETE RECALL
COMPLETED OPEN RECALL 98S15
REPLACE SWITCH
1 RECALL 98S15 PERFORMED
PERFORM RECALL

RECALL COMPLETED. REPLACED CONNECTOR AND SWITCH. ROAD TEST.

98S15 RECALL

PERFORMED OPEN RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL RECALL

REPLACE SWITCH AND HARD SHELL

REPAIR AS PER RECALL 98S15

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

REPAIR AS PER RECALL 98S15

42 98S15

1 REPLACE DEACTIVATION SWITCH AND CONNECTOR

98S15 98S15

98S15 98S15

RECALL PERFORMED RECALL 98S15

134420 RECALL 98S15, REPLACE SWITCH AND CONNECTOR

INSTALL DEACTIVATION SWITCH

98S15E PERFORMED RECALL. INSTALLED NEW CRUISE

81201 REPLACED SWITCH 0.5

SPEED CONTROL SWITCH 98S15 RECALL

RECALL DONE

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACED CRUISE DEACTIVATION SWITCH

INSTALL SPEED CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

COMPLETED RECALL 98S15

67545 RECALL 98S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RNR SWITCH PERFORM RECALL 98S15

1 PERFORMED RECALL

PERFORMED RECALL 98S15

40044 COMPLETED 98S15 REPL SWITCH

REPLACED SWITCH AND CONN

REPLACED DEACTIVATION SWITCH AND HARD SHELL

R-R SPEED CONTROL DEACTIVATION SWITCH

RECALL 98S15 RECALL REPLACE SWITCH

RNR DEACTIVATION SWITCH PERFORM RECALL 98S15

REPLACE CRUISE DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

PERFORM RECALL

RECALL DONE

RECALL PERFORMED RECALL

REPLACE SWITCH AND HARD SHELL

SWITCH MAY DEVELOP A RESISTIVE SHORT CIRCUIT. REPLACED CONNECTOR AND SWITCH

98S15 REPL DEACTIVATION SWITCH

COMPLETED RECALL

104888 RECALL 98S15 WR PERFORM RECALL 98S15

Box_Files

PERFORMED RECALL PERFORMED RECALL
 RECALL 98S15 REPLACE DEACTIVATOR SWITCH
 98S15B PERFORMED RECALL - REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL 98S15
 PERFORMED.
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
 RECALL RECALL
 98001 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH
 78700 REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 98S15
 RPL CRUISE DEACTIVATION SWITCH
 PERFORM RECALL 98S15B

 97349 PERFORM RECALL 98S15
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 S #98S15
 REPAIR AS PER RECALL
 PERFORM RECALL
 PERFORMED RECALL AS PER INSTRUCTIONS
 PERFORMED RECALL CODE 42

 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL
 PERFORMED RECALL 98S15 INSTALLED CRUISE CONTROL SWITCH AND CONNECTOR
 111000 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR AS PER 98S15
 98S15 SPEED CONTROL DEACTIVATION REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 REPLACED SC DEACTIVATION SWITCH 98S15
 REPLACED SWITCH AND PLUG

 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 98S15 PERFORM RECALL 98S15
 PERFORMED RECALL 98S15 - REPLACED PART
 PERFORM RECALL
 RECALL RECALL
 RECALL COMPLETED -DID 98S15B.
 PERFORM RECALL 98S15
 RECALL 98S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG PER RECALL
 98021 PERFORMED RECALL REPLACED SWITCH AND CONN
 PERFORMED RECALL REPLACED SPEED CONTROL SWITCH
 X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 98S15 SPEED CONTROL SWITCH 98S15 REPLACED SPEED CONTROL SWITCH
 INSTALL DEACTIVATION SWITCH
 PERFORM RECALL
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
 REPLACED DEACTIVATION SWITCH 98S15 REPAIRED PER RECALL
 98S15 98S15
 PERFORMED RECALL
 PERFORMED RECALL 98S15

2002-023-9 3403

Page 585

PERFORM 99811 DEACTIVATED CRUIZ CONTROL
PERFORM DIAGNOSIS,ROAD TEST,SWITCH DEFECTIC? REPLACE SWITCH
48247 REPLACED DEACTIVATION SWITCH AND CONNECTOR, PER RECALL
PERFORM RECALL 99815

88S16 COMPLETED

88615 COMPLETED

88614 RECALL COMPLETE

10645 PERFORMED RECALL

RECALL COMPLETED

84842 REPL CRUISE BRAKE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

X 98315 DONE REPLACE 8 SPEED CONTROL SWITCH AND CONNECTOR

1. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - B9S15B .5

RECALL COMPLETE

PERF RECALL 99\$15

1 PERFORMED RECALL PR\$16

COMPLETED RECALL 98815

REPLACED SC DEACTIVATION SWITCH 90S15

00S16 PERFORMED REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNEC

REPLACE CRUISE DEACTIVATION SWITCH. RECALL

92S15 REPLACE CRUISE DEACTIVATION SWITCH

99915 RECALL COMPLETED

OL SWITCH

RECALL 88S15 RECALL INSTALL CONNECTOR & SWITCH

INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS OUTLINED IN REC ASLL 99815 ALL OK TO RELEASE

PERFORMED RECALL

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

COMPELTED 88815 RECALL

88315

Box_Files

104979 PERFORM RECALL 99S15 OF 99S15B
 INSTALL CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15
 REPLACED THE SWITCH PER RECALL 99S15
 PERFORM RECALL 99S15
 RECALL 99S15 COMPLETED
 REPLACED SPEED CONTROL SWITCH
 024 REPLACE CRUISE DEACTIVATOR SWITCH
 PERFORMED RECALL 99S15
 SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH
 1 INSTALLED SPEED CONTROL SWITCH & CONNECTOR

DO RECALL 99S15
 DID CRUISE RECALL
 99S15 99S15
 99S15 99S15
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
 RECALL
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL 1
 FACTORY RECALL COMPLETED RECALL
 79858 RECALL 99S15 PERFORMED RECALL 99S15
 66806 RECALL 99S15 PERFORMED RECALL 99S15
 REPLACED SWITCH AND CONNECTOR
 INSTALLED SWITCH
 71184 RECALL 99S15 WIR PERFORM RECALL 99S14 SPEED CONTROL INSTALL NEW ONE AND REPAIR WIRE FOUND THAT ABS LIGHT ON AND BRAKE LIGHT ON
 PERFORMED RECALL
 INSTALLED DEACTIVATION SWITCH AS PER RECALL, REPAIRED WIRE HARNESS TO SWITCH, HAD AFTERMARKET CONNECTOR. INSTALLED
 72877 CAMPAIGN 99S15 SPEED CONTROL DEACTIVATION SWITC 99S15E .3HRS .3HRS REPLACED SPEED CONTROL DEACTIVATION SWITCH

99S15 99S15
 SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S

RECALL 99S15 COMPLETED
 82588 RECALL PERFORM RECALL 99S15 REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR
 RECALL 99S15
 PERF RECALL 99S15
 PERFORM RECALL
 REPL DEACTIVATION SWITCH PER RECALL
 POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH PERFORMED RECALL 99S15 FOR SPEED CONTROL DE-ACTIVATION
 99S15 99S15-INSTALL SWITCH AND CONNECTOR
 PERFORMED RECALL 99S15
 RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH
 -- REPLACED SWITCH
 99S15 RECALL
 DO RECALL 99S15 CK ONLY IS OK
 99S15 RECALL 99S15 RECALL COMPLETE
 88710 RECALL R-R CRUISE SWITCH AND BLEED BRAKES AS PER RECAL
 99S15 DO RECALL
 1 INSTALLED BRAKE DEACTIVATION SWITCH AS PER RECALL 99S15.
 PERFORMED RECALL

Box_Files

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .6
REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
REPLACED SWITCH AND CONNECTOR PER RECALL 99S15
RECALL 99S15 RECALL 99S15
RECALL 99S15 PERFORMED RECALL 99S15B

REPLACE SWITCH AND CONNECTOR
INSTALL CRUISE CONTROL DEACTIVATION SWITCH

PERFORM RECALL 99S15 RECALL 99S15, REPLACE DEACTIVATION SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
RECALL REPLACED BRAKE SWITCH
RECALL 99S15 COMPLETE
78391 PERFORMED RECALL ADDED BRAKE FLUID AND FR STR FLUID WASHED ENGINE
PERFORMED RECALL 99S15
COMPLETE RECALL
PERFORMED 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
125829 PERFORM RECALL 99S15 C-C SWITCH
INSTALL SWITCH PER RECALL
167985 PERFORMED RECALL AS PER LETTER. INSTALLED SWITCH AND CONNECTOR, 99S15B 0.5 HR LABOR
DID RECALL 99S15, SPEED CONTROL DEACTIVATION SWITCH

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
PERFORMED RECALL
REPLACED SWITCH AND CONNECTOR
R AND R SWITCH PER RECALL
RECALL 99S15 INSTALLED SWITCH
REPAIRED AS PER PROGRAM
R&R SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER RECALL

114408 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
COMPLETED RECALL 99S15
PERFORMED SAFETY RECALL 99S15
PERFORM 99S15 RECALL CRUISE SWITCHES
RECALL PERFORM RECALL
X COMPLETED COMPLETED
OPEN RECALL, PERFORM RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 BOX B
REPLACED CRUISE CONTROL SWITCH
REPLACED BRAKE SWITCH FOR SPEED CONTROL AS PER RECALL
REPL SWITCH PER RECALL

COMPLETE RECALL 99S15

Box_Files

REPLACED CONTROL SWITCH

110888 RECALL 99S15 W PERFORMED RECALL INSTALLED UPDTE SWITCH AND TEST OK SEE OTHER LINE FOR REPAIRS NEEDED TO TEST SYSTEM FOUND TERMINALS CORP

PERFORM RECALL PER MANUFACTURER RECALL PERFORME

PERFORM RECALL

99S15 99S15 RECALL

PERFORMED RECALL

COMPLETE RECALL 99S15

PERFORMED RECALL

RECALL

PERFORM RECALL

99-8-15

99-8-15 COMPLET

OK REPL SWITCH

PERFORM RECALL

INSTALL SWITCH

NEC TO REPLACE DEACTIVATION SWITCH

REPLACED SC DEACTIVATION SWITCH 99S15

INERTIA SWITCH PER RECALL 99S15

PER RECALL

99S15

99S15

REPL DEACTIVATION SWITCH

1 COMPLETE RECALL

99S15

99S15

REPLACED SWITCH PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

PERFORM RECALL

INSTALLED DEACTIVATION SWITCH

RECALL

PERFORMED RECALL 99S15B SPEED CONTROL DEACTIVATION

PER THE OASIS PERFORM RECALL 99S15.

RECALL COMPLETED ALL OK

REPLACE SPEED CONTROL DEACTIVATION SWITCH

RECALL

99S15

COMPLETED 99S15

RECALL 99S15

PERFORM RECALL 99S15

REPLACED DEACTIVATION SWITCH

99S15 RECALL

99S15 RECALL COMPLETE

105533 REPLACED SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDBELL CONNECTOR...

RECALL 97031 REPLACE SWITCH AND CONNECTOR

OPEN RECALL

COMPLETE RECALL 99S15

PERFORMED 99S15

99S15

99S15 RECALL DO

RECALL 99S15

RECALL COMPLETE

RNR DEACTIVATION SWITCH

PERFORM RECALL 99S15

REPL SWITCH PER RECALL 99S15

129522 99S15 INSTALLED CONNECTOR AND CRUISE SWITCH AS OUTLINED IN 99S15

Box_Files

103250 REMOVED OLD SPEED SWITCH AND REPLACED IT WITH THE NEW SPEED DEACTIVATION SWITCH
REPLACED CRUISE SHUT OFF SWITCH

09142 RECALL REPL- SPEED CONTROL DEACT SWITCH & PLUG 99S158 0.5
REPLACED SPEED CONTROL DEACTIVATION SWITCH
52574 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
REPLACE DEACTIVATION SWITCH, RECALL
REPL CRUISE SWITCH 99S15
99S15 RECALL 99S15 REPAIRED AS PER RECALL
99S78 REPLACED SWITCH
99S15 99S15
PERFORM RECALL
REPLACED SWITCH AND CONNECTOR
PERFORMED RECALL PERFORMED RECALL
1 INSTALL DEACTIVATION SWITCH 1
99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
RECALL REPLACE CRUISE SWITCH
PERFORM RECALL
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15
PERFORM RECALL REPL DEACTIVATION SWITCH
REPLACED C CONTROL DEACTIVATION SWITCH PER 99S15 RECALL
COMPLETED 99S15 RECALL

PERFORM RECALL 99S15 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
REPLACE AS PER RECALL 99S15
PERFORM RECALL INSTALL SWITCH
99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
1 COMPLETED RECALL 99S15
REPL SWITCH PER RECALL
99S15 RECALL
REPLACED CRUISE SWITCH

1 INSTALL SPEED CONTROL DEACTIVATION SWITCH 1
99S15 RECALL
RECALL PERFORMED RECALL
54008 INSTALLED A NEW SWITCH PER RECALL NOTICE
J8 PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
SPEED CNTRL DEACTVTN SWITCH RPLCMITPERF SAFETY RECALL 99S15
PERFORM RECALL 99S15
23858 99S15 REPLACE SWITCH AND CONNECTOR PER RECALL GA
INSTALL NEW CRUISE CONTROL BRAKE SWITCH PER RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORM RECALL
REPLACE SWITCH AND HARD SHELL

74819 PERFORM RECALL, REPLACE SWITCH 99S158 .5

ENR-825-A 3458

Box_Files

REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
ONP 99S15 ONP 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHEL
1 PERFORMED RECALL 99S15 1
REPLACE SPEED CONTROL PER RECALL

RECALL REPLACESWITCHAND CONNECTOR
99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
FACTORY RECALL COMPLETED RECALL
99S15 99S15B
RECALL COMPLETED

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
99S15 99S15B
INSTALLED CRUISE KIT PER RECALL
PERFORM RECALL 99S15
99S15 RECALL 99S15 REPAIRED A PER RECALL

INSTALLED NEW DEACTIVATION
44381 PERFORMED SPEED CONTROL DEACTIVATION SW. RECALL
RECALL COMPLETE
INSTALL DEACTIVATION SWITCH
PERFORM RECALL REPLACE SWITCH AND CONNECTOR 99S15 BLEED AND ROAD TEST VERIFY REPAIRS
X PERFORMED RECAL
99293 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
PERFORM RECALL 99S15 INSTALL SWITCH AND CONNETOR END
REPL SWITCH PER RECALL 99S15
RECALL 99S15 PERFORM RECALL 99S15
REPLACE DEACTIVATION SWITCH AS PER RECALL
PERFORM RECALL 99S15 PERFORM RECALL 99S15
COMPLETE RECALL 99S15
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
D RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
26428 REPLACE SWITCH AND CONNECTOR PER 99S15 87
99S15 RECALL PERFORMED
99S15 RECALL 99S15 RECALL COMPLETE
REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
INSTALL CRUISE DEACTIVATIONL SWITCH
RECALL PERFORMED RECALL 99S15
1 PERFORMED RECALL
91403 INSTALLED A NEW SPEED CONTROL PRESSURE SWITCH PER RECALL NOTICE
RECALL 99S15
RECALL 99S15 RECALL

RECALL RECALL
DID RECALL 99S15

REPLACE DEACTIVATION SWITCH
38902 REPLACED THE DEACTIVATION SWITCH ALONG WITH THE PROPORTIONING VALVE BECAUSE THE VALVE WAS DAMAGED WHEN THE SWITCH WAS REMOVED, THE BRAKE
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15

Box_Files

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN
 RECALL 98S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH
 RECALL COMPLETED
 1 RECALL COMPLETE
 REPLACE SPEED CONTROL DEACTIVE SWITCH.
 APPLIED RECALL 98S15
 RECALL 98S15 REPLACE CRUISE SWITCH
 W DISCONNECTED SPEED CONTROL AND ORDERED NEW DEACTIVATION SWITCH.
 COMPLETED RECALL 98S15, SPEED CONTROL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ASSY AS PER 98S15 RECALL
 RECALL 98S15
 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 REPL SWITCH PER RECALL 98S15
 RECALL COMPLETE
 RECALL 98S15 98S15 REPLACE SPEED CONTROL SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 REPL SWITCH & CONNECTOR PER RECALL 98S15
 70862 PERFORMED RECALL 98S15
 REPLACED DEACTIVATION SWITCH
 RECALL #98S15 RECALL #98S15
 PER RECALL 98S15 OASIS DOWN INSTALL NEW DEACTIVATION SWITCH PER RECALL 98S15
 98S15 REPLACE CRUISE CONTROL BRAKE SWITCH
 FACTORY RECALL COMPLETED RECALL
 PERFORM RECALL ON SPEED CONTROL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PERFORM RECALL SENT BY WPI
 PERFORM RECALL 98S15
 RECALL 98S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 98S15
 110152 DID RECALL 98S15 REPLACED CONNECTOR AND SWITCH
 COMPLETED RECALL 98S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR 98S15B .5 + .1
 PERFORM RECALL
 PERFORMED RECALL
 REPAIR AS PER RECALL
 ADD 98S15B 82 98S15B - 810 - LABOR .3 ADMIN .1 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.
 98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 DEACT SWITCH #70862
 PERFORM RECALL 98S15
 PERFORM RECALL 98S15
 98S15 98S15
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 60117 98S15 W INSPECTED AND REPLACED SPEED CONTROL RECALL PER 98S15. 6115
 REPLACE SWITCH & CONNECTOR
 RECALL 98S15 RECALL- REPLACED SPEED CONTROL DEACTIVATION SWITCH
 98S15B REPLACE SWITCH RECALL
 INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL

0902-825-A 3488

Box_Files

PERFORMED RECALL
RECALL 98S15 - B - RECALL
PERFORMED RECALL
98S37 RECALL 98S15 RECALL 98S15 JH

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTIONS
01901 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
98S15 R&R DEACTIVATION SWITCH
COMPLETED 98S15 RECALL
REPLACED DEACTIVATION SWITCH AND CONNECTOR
REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH
COMPLETE RECALL 98S15
PERFORM RECALL 98S15

98S15 RECALL 98S15 RECALL COMPLETE
1 PERMANENT FIX - REPLACE DEACTIVATION SWITCH AND CONNECTOR. 98S15B 0.5 HRS
REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL REPAIR AS PER RECALL 98S15 SPEED DEACTIVATION SWITCH REPLACEMENT
98S15 RECALL 98S15 RECALL COMPLETED
REPAIR PER FOMOCO
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

98S15 98S15 PERFORM RECALL
98S15B RECALL 98S15B REPLACED CRUISE ACTIVATION SWITCH
58138 REPLACED SWITCH
PERFORMED RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND CHECK OK
INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER 98S15 RECALL
RECALL COMPLETE
98S15
98S15B RECALL 98S15B RECALL REPLACED CRUISE DEACTIVATION SWITCH
30277 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH
REPLACED DEACTIVATION SWITCH
FACTORY RECALL COMPLETED RECALL
RECALL PERFORM RECALL
PERFORM 98S15
RECALL COMPLETE
FACTORY RECALL COMPLETED RECALL
COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH E
COMPLETED FACTORY RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER 98S15 CAMPAIGN
1 REPLACE CRUISE SWITCH AND BLEED BRAKES
INSTALL DEACTIVATION SWITCH
PERFORM RECALL
PERFORMED RECALL

30761 PERFORMED RECALL 98S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR BLEED BRAKES AND TEST DROVE ALL OK
PERFORM RECALL
PERFORMED RECALL 98S15

Box_Files

AS PER RECALL # 99S15
OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15
99S15 99S15
1 INSPECTED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15.
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
COMPLETE RECALL 99S15
PERFORMED RECALL
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
RECALL REPLACED DEACTIVATION SWITCH PER RECALL
99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SH
110089 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
PERFORM RECALL AS PER LETTER
REPLACE DEACTIVATION SWITCH PER RECALL
RECALL 99S15 MIL 21821 DID RECALL 99S15 REPLACE SWITCH & CONECTOR
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
REPL SPEED CONTROL SWITCH 99S15 RECALL
PERFORM RECALL 99S15
50788 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15
REPLACE CRUISE SWITCH PER RECALL
INSTALLED SPEED CONTROL DEACTIVATION SWITCH
99S15 99S15
REPL SWITCH PER RECALL
PERFORMED RECALL 99S15
REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SECURED SPEED CONTR
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
AE PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
RECALL REPAIR
99790 RECALL 99S15 INSTALL NEW SWITCH AND CONNECTOR
PERFORMED RECALL 99S15
PERFORMED RECALL 99S15
72365 RECALL 99S15B 0.50 INSTALL NEW BRAKE DEACTIVATION SWITCH
99S15 99S15 PERFORM RECALL
1 PERFORMED 99S15 RECALL
RECALL COMPLETE
COMPLETED RECALL 99S15
PERFORMED RECALL 99S15
99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
REPLACED PARTS PER RECALL
REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR

PERFORM RECALL 99S15 RECHECK OK 1
PERFORM RECALL 99S15
PERFORMED RECALL AS PER INSTRUCTIONS
RECALL INSPECT AND REPLACE SWITCH PER RECALL
PERFORMED RECALL PER BULLETIN
INSTLL NEW DEACTIVATION SWITCH AND HARNESS PER RECALL
INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
99380 INSTALLED RECALL

2002-025-A 2482

Box_Files

COMPLETE 99S15
 REPLACED DEACTIVATION SWITCH
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER 99S19
 PERFORMED RECALL
 INSTALL KIT FOR DEACTIVATION SWITCH
 REPLACED CRUISE SWITCH
 99S15 RECALL
 RENEW DEACTIVATION SWITCH
 PERFORM SPEED CONTROL MODIFICATION PER RECALL
 PERFORMED RECALL 99S15

99S15B RECALL COMPLETE
 RECALL COMPLETE
 RECALL 99S15 99S15
 REPLACED CRUISE CONTROL BRAKE SWITCH AND CONNECTOR PER RECALL
 99S15 R/R SWITCH
 COMPLETED RECALL

PERFORM RECALL 99S16
 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15
 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
 99S15 99S15 REPLACED SWITCH AND CONNECTOR
 C INSTALL SWITCH AS PER RECALL
 PERFORMED RECALL
 31823 PERFORMED RECALL 99S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND TEST DROVE ALL O
 REPL CRUISE CONTROL SWITCH ASY
 PERFORMED RECALL AS BY FACTORY PERFORMED RECALL
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.
 DIAG AND PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH ALL OK WITH CRUISE NOW
 PERFORM RECALL 99S15
 44458 PERFORMED RECALL 99S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND TEST DROVE OK
 SWITCH AND CONNECTOR INSTALLED

COMPLETED
 SPEED CNTRL DEACTVTN SWITCH RPLCMT PER F SAFETY RECALL 99S15
 REPLACE DEACTIVATION SWITCH 1
 71705 99S15 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND PLUG IN CONNECTOR
 RECALL 99S15
 REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 RECALL SPEED CONTROL DEACTIVATION SWITCH
 109862 RECALL 99S15 INSPECTED AND INSTALLED CRUISE DEACTIVATION SW. SEE LINE D.
 99S15B .5 HRS ADMIN .1 HRS COMPLETED RECALL 99S
 REPLACE SPEED CONTROL PER RECALL
 RECALL COMPLETED
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL CABLE PER RECALL

RECALL 99S16

ENR2-425-A 3463

Box_Files

1 PERFORMED RECALL 99S15 REPLACED CRUISE CONTROL SWITCH
PERFORMED RECALL
99S15 99S15 REPLACE CRUISE SWITCH PER RECALL 99S15

PERFORM RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15
INSTALL SWITCH PER RECALL
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
PERFORM RECALL AS PER FACTORY REQUIREMENTS
99S15 RECALL, PERFORMED
99S15 99S15
RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH
99S15 REPLACED CRUISE CONTROL SWITCH 99S15

RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
37308 RECALL REPLACED DEACTIVATION SWITCH 150
REPLACED DEACTIVATION SWITCH

67721 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH PERMANENT REPAIR
RECALL 99S15 RECALL COMPLETE
REPLACE DEACTIVATION SWITCH, RECALL
99S15 99S15
99S01 PERFORMED RECALL 99S15
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
AS PER RECALL 99S15 RECALL TO REPLACED DEACTIVATION SWITCH

RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
REPL DEACTIVATION SWITCH PER RECALL
PERFORM RECALL 99S15
1 TECH REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15 T
PERFORM SAFETY RECALL 99S15

94521 REPLACED SPEED CONTROL DEACTIVATOR SWITCH AND HARD-SHELL AND BLEED BRAKES AS PER RECALL
INSPECTED ALREADY DISCONNECTED REPLACED SWITCH PER RECALL
1 REPLACE CRUISE CONTROL SWITCH AS NEEDED
PERFORMED RECALL 99S15

30252 PERFORMED 99S15 RECALL
PERFORMED SPEED CONTROL RECALL TECH 9206
PERFORM RECALL 99S15B PERFORM RECALL 99S15B
RPLC CRUISE DEACTIVATION SWITCH PER 99S15
REPL SPEED CONTROL SWITCHES
REPLACE AS PER RECALL 99S15
81280 RECALL TECH 8177 PERFORM RECALL 99S15 INSTALL SWITCH AND CONNECTOR
REPLACE AS PER RECALL REMOVE AND REPLACE AS PER RECALL (99S15B)
43157 PERFORM RECALL AS PER RECALL

5982-025-A 3464

Box_Files

REPLACE DEACTIVATION SWITCH 99S16 RECALL PER FORD INSTRUCTIONS
 REPLACED DEACTIVATION SWITCH
 99S15 REPL SPEED CONTROL DEACTIVATION SWITCH
 1 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
 COMPLETED 99S15
 REPL CRUISE DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 99S15 REPL DEACTIVATION SWITCH 99S15 COMPLETED - REPLACED DEACTIVATION SWITCH
 PERFORM RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 COMPLETED RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 99S15
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 PERFORMED RECALL 99S15 AND CHECKS OK
 REPLACED CRUISE SWITCH
 55858 99S15B 0.5 ADMIN 0.1
 INSTALLED DEACTIVATION SWITCH
 PERF RECALL
 REPLACED SWITCH PER RECALL
 . REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR 99S16B .5
 . MODIFY PER RECALL 99S15
 RECALL COMPLETE
 TECH CHECK AND REPLACED AS REQUIRED
 REPLACED CRUISE BRAKE KIT .F
 OPEN CAMPAIGN 99S15 REMOVE AND REPLACE SPEED CONTROL SWITCH AS PER CAMPAIGN, PERFORM LABOR OPERATION 99S15B
 INSTALL SPEED CONTROL PART PER RECALL
 99S15 PERFORMED RECALL
 99S15 RECALL 99S15E 0.3L PERFORMED RECALL
 RECALL COMPLETED

 99S15 REPLACE SWITCH AND CONNECTOR PER RECALL
 COMPLETED RECALL 99S15
 110449 RECALL REPLACE DEACTIVATION SWITCH PER RECALL 99S15
 99S15 PERFORMED CRUISE RECALL WHEN REPLACING SWITCH THREADS PULLED OUT OF BLOCK ORDERED PRESURE BLOCK REMOVED FUSE BLOCK ,PS BOTTLE ,CRUISE 81
 1 PERFORM RECALL
 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL

 RECALL RECALL
 PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 99S15B INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
 COMPLETED RECALL
 RECALL COMPLETED 99S15 RECALL

 PERFORMED RECALL 99S16

 FACTORY RECALL COMPLETED RECALL

5982-828-9 3485

Box_Files

REPLACE CRUISE SWITCH PER RECALL

PERFORMED RECALL 98S15

REPLACED PER RECALL

PERFORMED INSPECTION AND REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

PERFORM RECALL

REPLACE SWITCH PER RECALL

??

89142 RECALL 0.5 INSTALLED BRAKE PRESSURE SWITCH AND HARDSHELL CONNECTOR 98S15B

88224 RECALL .5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B

THE CAR NEEDS A NEW FAN BELT AT \$30.00. CUST AWARE THE COOLANT BOTTLE IS EMPTY. BATTERY NEEDS SERVICE.

98S15 98S15

CERTAIN 1982 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION SWITCH AS:

INSPECTED AND REPLACED CRUISE SWITCH PER RECALL NOTICE

102089 RECALL 98S15 W RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR TOP OFF BRAKE FLUID AND BLEED BRAKES

REPLACE SPEED CONTROL SWITCH PER RECALL

PERFORMED RECALL 98S15: REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

80000 RECALL WPG40 INSTALLED NEW SWITCH & WIRE CONNECTOR PER RECALL L 98S15 FINISHED

REPLACED SWITCH AND PLUG AS PER RECALL 98S15

INSTALLED CRUISE CONTROL KIT AS PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 98S15

91768 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

F RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

PERFORM RECALL

PERFORMED RECALL 98S15-INSTALL SWITCH

88248 REPLACED SWITCH AND CONECTOR

PERFORM RECALL 98S15 PERFORM RECALL

77541 DO RECALL 98S15

PERFORM RECALL 98S15 REPLACE CRUISE DEACTIVATION SWITCH

SPEED CONTROL DEACTIVATION SWITCH REPLACE 98S15B PERFORMED RECALL 98S15B

REPLACED DEACTIVATION SWITCH AS PER RECALL

157323 RECALL REPLACED SWITCH AND CONNECTOR RECALL 98S15B

1 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH 98S15B

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S

REPL SWITCH PER RECALL 98S15

PERFORM RECALL

PERFORM RECALL

RECALL 98S15 PERFORM RECALL 98S15

CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.

SPEED CNTRL DEACTVTN SWITCH REPLCMTPRF SAFETY RECALL 98S15

88889 PERFORMED RECALL 98S15

COMPLETED OPEN RECALL 98S15

INSTALLED CRUISE SWITCH

33852 RECALL R+R DEACTIVATION SW AND REWIRED HARD SHELL CONN

80427 MAINT DID RECALL REPLACED SWITCH AND WIRES TECH 10

158868 98S15 SPEED CONTROL DEACTIVATION SWITCH PERFORM INSPECTION AND REPLACE SWITCH AND CONECTOR AS PER RECALL

Box_Files

RECALL PERFORM RECALL 99S15
 PERFORM RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 FACTORY RECALL COMPLETED RECALL
 99S15 SP-SWITCH INST
 REPLACED THE SPEED CONTROL SWITCH PER RECALL
 PERFORMED SPEED CONTROL RECALL
 80158 RECALL 99S15B 0.5HRS REPLACE SWITCH AND CONECTOR TK372
 PERFORM RECALL
 A SHORT IN THE SPEED CONTROL SWTH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE.ALSO A FIRE COULD DEVOPE. REMOVE TAPE AND SECURE TH
 RECALL REPAIRED AS PER RECALL
 99S15 99S15
 99S15 RECALL NOTIFICATION 99S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL
 REPLACE BRAKES PRESSURE SWITCH PER RECALL 99S15
 RECALL 99S15 PERFORM RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL TECH 876 WAYNE WP REPLACED CRUISE CUT OFF SWITCH AS PER RECALL CAR ON DRIVE
 NAC 99S15
 RECALL 99S15 INSTALL KIT PER 99S15
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.
 REPLACE SPEED CONTROL DEACTIVATION SW RECALL 99S
 RECALL PERFORMED
 INSTALL SWITCH.
 PERFORMED RECALL
 INSTALL SWITCH AS PER RECALL
 1 REPACE SWITCH & CONNECTOR BLEED BRAKES
 RECALL 99S15 99S15B .5 ADMIN .1 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 RECALL 99S15
 RECALL 99S15
 88784 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR
 X 99S15
 RECALL 99S15 REPLACE SWITCH & CONNECTOR
 85820 99S15B .5 INSTALL SWITCH PER RECALL
 80987 PERFORMED RECALL 99S15
 115532 RECALL 0.5 99S15B INSTALLED RECALL
 80883 RECALL REPLACED SPEED CONTROL DEATVATER SWITCH AND CONNECTER CODE 42 TK674 SUGGESTED EGR TUBE,INJECTOR SERV,CLEAN IAB VALVE,DECARBON SE
 99S15 SPEED CONTROL RECALL

 REPLACED SPEED DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15B
 114104 RECALL REPLACED SWITCH AS PER RECALL
 REPLACED SPEED CONTROL CABLE AS PER RECALL
 RECALL 99S15 COMPLETED
 1 08 REPLACED SWITCH
 CHECK AND REPLACE CRUISE CONTROL SWITCH PER RECALL
 99S15 RECALL 99S15 RECALL
 50216 PERFORM RECALL 99S15B, REPLACE SPEED CONTROL SWITCH.
 88924 RECALL REPLACE DEACTIVATION SW AND CONNECTOR
 PERFORMED RECALL 99S15
 RECALL 99S15 SWITCH

0082-828-9 3467

Box Files

40430 RECALL 98S15 COMPLETED

RECALL 98S15 98S15

RECALL

98S15 COMPLETED

RECALL PERFORMED

RECALL 98S15 COMPLETED

RECALLED 98S15 PERFORMED

CHECK AND REPAIR AS REQUIRED

INSPECTED SYSTEM, REPAIRED IF NECESSARY PER RECA

90152 REPL CRUISE DEACTIVATION SWITCH PER RECAL

PERFORMED RECALL 98S15 1

PERFORM RECALL 98S15

PERFORMED RECALL 98S15

RECALL 98S15 INSTALLED SWITCH

INSTALL NEW BRAKE SWITCH CONNECTOR PER RECALL CK OP OK

100808 98S15 WARR REPLACED SWITCH AND CONN

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15.

SPEED CONTROL SWITCHJ 98S15 RECALL

60580 RECALL 98S15B 0.5 HRS. NEC TO PERFORM RECALL 98S15.

RECALL REPLACE SWITCH AND HARD SHELL CONNECTOR

COMPLETED RECALL

INSPECTED AND REPLACED DEACTIVATION SWITCH AS PER RECALL

97000 COMPLETED SPEED CONTROL DISABLE SWITCH RECALL INSTALLE DNEW SPEED DISABLE SWITCH TO VEHICL

REPLACE SPEED SWITCH AS PER RECALL

RECALL 98S15

PERFORM RECALL INSTALL SWITCH

98S15B 0.5

COMPLETE RECALL 98S15

102098 REPLACED SWITCH AND CONNECTOR PER RECALL

RECALL PERFORMED RECAL

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15.

SERVICE DIAG AND REPLACED SERVO ACCUMULATOR

PERFORMED RECALL 98S15. REPLACED CRUISE DE-ACTIVATION SWITCH. 98S15B .5

AS PER RECALL 98S15 RECALL TO INSTALL DEACTIVATION SWITCH

101431 RECALL DEACTIVATION SWITCH INSTALLED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 98S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

REPLACED DEACTIVATION SWITCH AND CONNECTOR AND BLEED BRAKES 3 COMPLETED

124205 RECALL 98S15 COMPLETED

PERFORMED 98S15 RECALL

1 PERFORM SERVICE

PERFORMED RECALL AS NEEDED REPLACED SWITCH

PERFORM RECALL SPEED CONTROL SWITCH

PERFORM RECALL 98S15

RECALL 98S15 RECALL 98S15

98S15 98S15 RECALL

RECALL 98S15

EMERGENCY-25-2 2458

Box_Files

47148 RECALL W 7206 REPLACED SPEED CONTROL DEACTIVATE PER RECALL 99S15
 RECALL 99S15 DONE
 99S15 SPEED CONTROL RECALL
 99S15 - PERFORMED RECALL REPLACED SWITCH & CONNECTOR & RD TEST.
 99077 99S15 PERFORM RECALL FALLS INTO AFFECTED DATE REPLACE SWITCH AND CONNECTOR BLEED SYSTEM.
 INSTALL SENDER & CONNECTOR PER RECALL 99S15
 RECALL 99S15 RECALL
 REMOVE AND REPLACE SPEED CONTROL SWITCH
 RECALL REPAIR AS PER RECALL 99S15 CRUISE CONTROL CABLE REPLACEMENT
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 REPAIRED PER RECALL
 DO 99S15
 99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SH
 REPAIRED AS PER RECALL SPEED CONTROL
 RECALL PERFORMED CAMPAIGN 99 S 15 CRUISE DEACTIVATION SWITCH
 PROGRAM CODE 99S15
 COMPLETED RECALL 99S15
 RECALL 99S15 COMPLETED RECALL 99S15
 74945 RECALL 99S15 COMPLETED SPEED CONTROL DEACTIVATION SWITCH RECALL
 REPLACE DEACTIVATION SWITCH
 RECALL COMPLETED
 REPLACED SWITCH & CONNECTOR
 RECALL RECALL
 117936 REPLACED SWITCH & CONNECTOR PER RECALL
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .B
 99S15 REPLACED SWITCH PER RECALL
 REPLACE DEACTIVATION SWITCH PER RECALL

 PERFORM RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS
 91189 RECALL 99S15 COMPLETED SPEED CONTROL DEACTIVATION SWITCH RECALL
 PERFORMED RECALL
 RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 VERIFY R&R CABLE PER RECALL
 RECALL COMPLETED

 REPLACE CRUISE SWITCH PER RECALL 99S15
 RECALL 99S15 E REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
 TECH 241 PERFORMED 99S15 RECALL
 102560 PERFORM 99S15 RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
 1 REPLACE CRUISE CONTROL SWITCH
 REPLACE SWITCH PER RECALL
 DIAGNOSIS AND INSPECT FOR CAMPAIGN PERFORM CAMPAIGN AS PER NOTICE INSTALLED SWITCH
 REPL SWITCH PER RECALL 99S15
 - MODIFY PER RECALL 99S15
 COMPLETE RECALL AS DIRECTED

2002-025-A 3488

99S15 REPL SWITCH
 REPLACED BRAKE DEACTIVATION SWITCH
 RECALL 99S15 COMPLETED RECALL 99S15

RECALL REPAIR AS PER RECALL 99S15
 CPN,99S52,99S16B,0.5,ADMIN,0.1,CC RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL
 4370-PROGRAM CODE 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH WITH UPDATED PART - PER INSTRUCTIONS
 RECALL 99S14 RECALL
 PERFORMED RECALL 99S15
 REPLACED SWITCH ASSEMBLY PER RECALL

COMPLETED RECALL
 RECALL 99S15
 RECALLED 99S15 PERFORMED
 INSPECT AND SECURE SWITCH PER RECALL
 CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION SWITCH AS
 129271 RECALL 99S16E,MOX,14200A 1.5L PERFORMED RECALL WIRING REPAIR DO TO NEW CONNECTOR PUT ON AND SWITCH REPLACED BEFORE. HAD TO INSTALL RECALL CO
 RECALL 99S15 COMPLETED
 PERFORM RECALL 99S15
 0 99S15 PROGRAM
 RECALLED BY FORD PERFORMED RECAL
 PERFORMED RECALL

PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
 115297 RECALL REPLACED C C DEACTIVATOR SWITCH AND CONECTOR X99 RECALL
 TECH 812 PERFORMED RECALL SPEED CONTROL DEACTIVATION SWITCH 1
 INSPECT,REPLACE CONNECTOR PER 99S15
 1 TECH REPLACED DEACTIVATION SWITCH AS PER RECALL 99S15
 99S15 RECALL PERFORMED
 RECALL 99S15 PERFORM RECALL 99S15
 RECALL 99S15
 PERFORMED RECALL
 100222 INSTALLED THE NEW SWITCH AND CONNECTOR PER RECALL
 1 REPLACED DEACTIVATOR SWITCH AND CONNECTOR
 RECALL 99S15 RECALL
 04899 PERFORMED CRUISE SWITCH RECALL
 99S15 SPEED CONTROL RECALL
 99S15 99S15
 INSTALL NEW DEACTIVATION SWITCH AND HARNESS PER RECALL
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 PERFORMED RECALL 99S15 SPEED CONTROL PER FACTORY
 RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
 RECALL 99S15 REPL SWITCH PER RECALL

1 INSTALL KIT
 99S15 COMPLETED SECURED SWITCH
 99S15
 COMPLETED RECALL PER INSTRUCTIONS

Box_Files

98720 RECALL 98S15 98S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15.
 98S15 REPLACE SWITCH
 98S15 98S15 RECALL DO

RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.

RECALL COMPLETED

RECALL REPAIR

98S15 RECALL

PERFORM RECALL

1 1 COMPLETED RECALL

RECALL COMPLETED

RECALL 98S15 COMPLETED RECALL 98S15

REPLACED BRAKE DEACTIVATION SWITCH AND CONNECTOR

REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR

RECALL 98S15 DONE

RECALL 98S15 REMOVED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY AS PER RECALL 98S15

RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO

FACTORY RECALL COMPLETED RECALL

RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS REPLACED DEACTIVATOR SWITCH

47998 INSTALLED KIT

COMPLETED RECALL

INSTALLED SWITCH PER RECALL

REPLACE DEACTIVATION SWITCH

DID RECALL 98S15

127882 RECALL REPLACED CRUISE DEACTIVATION SWITCH AND BLEED REAR BRAKES AS PER RECALL

REPLACED DEACTIVATION SWITCH AS PER RECALL

1 PERFORMED RECALL 98S15

1 INSTALL DEACTIVATION SWITCH PER RECALL

INSTALLED DEACTIVATION SWITCH AND CONNECTOR

COMPLETED RECALL

AS PER RECALL, REPLACED CRUISE DEACTIVATION SWITCH

RECALL 98S15 PERFORMED 98S15

PERFORM RECALL 98S15

98S15 RECALL

135842 REPLACED SPEED DEACTIVATION SW- AND CONNECTOR PER RECALL 98S15.

REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

C 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

PERFORM RECALL

RECALL 98S15 COMPLETED REPLACE SENSOR AND HARD-SHELL CONNECTOR WIRE WAS MANGLED

83302 98S15 W PERFORMED SERVICE 98S15

RECALL PERFORMED RECALL

1 PERFORMED RECALL 98S15 REPLACED CRUISE CONTROL SWITCH AND CONNECTOR

98S15B 0.5

RECALL

98S15 COMPLETED

Box_Files

RECALL 99S15
COMPLETED 99S15 RECALL

RECALL 99S15 PERFORM RECALL 99S15
REPLACED SENDER & CONNECTOR PER RECALL 99S15
REPLACE CRUISE CONTROL
PERFORMED RECALL
SERVICE PUBLICATION 99S15 REPLACED SWITCH
REPLACE DEACTIVATION SWITCH PER RECALL
99S15 99S15
PERFORMED RECALL PER FACTORY
99S15 99S15 REPLACE SWITCH
38465 REPLACED CRUISE DEACTIVATION SW AND CONNECTOR PER RECALL 99S15.
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
. INSTALL SWITCH AS PER RECALL
99S15 RECALL 99S15 RECALL COMPLETE
PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
RECALL SPEED CONTROL DEACTIVATIONREPLACE SWITCH
83284 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH. INSTALLED DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15.
CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.
RECALL 99S15 INSTALLED SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
REPLACED DEACTIVATION SWITCH
1 1 REPL SWITCH AND CONNECTOR
X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
76240 REPLACE SPEED CONTROL DEACTIVATE SWITCH AND CONNECTOR PER RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
OPEN RECALL PERFORMED RECALL
REPLACED SWITCH AND CONNECTOR
REPLACED THE CRUISE DEACTIVATION SWITCH COMPLETED RECALL
REPLACE SWITCH AS PER RECALL
CHECK AND REPAIR AS REQUIRED
PERFORM RECALL

RECALL 99S15 PREFORMED RECALL 99S15
PERFORMED RECALL
REPLACED SWITCH AND CONENCTOR
RECALL RECALL
RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH. RETESTED OK.
COMPLETED RECALL 99S15, REMOVED DEACTIVATION SWITCH AND OLD CONNECTOR, REPLACED BOTH PARTS AND ALL TESTED FINE.
REPLACED SWITCH AND CONNECTOR PER RECALL 99S15
RECALL 99S15 RECALL 99S15
RECALL 99S15

RECALL 99S15 RECALL 99S15

RECALL 99S15 COMPLETED
4238 RECALL 99S15 REPLACED VACUUM SWITCH FOR CRUISE CONTROL

ENG-925-A 2472

Box_Files

REPLACE BRAKE PRESSURE SWITCH PER RECALL
REPLACE SPEED CONTROL SWITCH

RECALL PERFORM RECALL
RECALL 99S15
RECALL 99S15 NOTICE RECALL 99S15 PERFORMED
INSTALLED KIT 99S15 RECALL PERFORMED

99059 99S15 WPC REPLACE DEACTIVATION SWITCH AND CONNECTOR.
RECALL 99S15

1 1 REPL SWITCH.

53596 RECALL 99S15 PERFORMED RECALL 99S15 CRUISE CONTROL

RECOMMENDATIONS AIR & FUEL FILTERS...\$ 78.00...TRANSMISSION SERVICE...\$ 170.00...SERPENTINE BELT...\$ 96.00...COOLANT SERVICE...\$ 65.00+TAX

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

RECALL PERFORM RECALL 99S15

RECALL REPAIR AS PER RECALL 99S15 REPLACE DEACTIVATION SWITCH

99S11 REPLACED DEACTIVATOR SWITCH

PERFORMED RECALL

PERFORMED RECALL 99S15

RECALL REPAIR PER FORD

PERFORMED RECALL 99S15

1 PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACED SWITCH AND CONNECTOR

1 PERFORMED RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE,ALSO A FIRE COULD DEVOPE. REMOVE,TAPE AND SECURE TH

REPLACED THE SPEED CONTROL SWITCH PER RECALL

71068 RECALL .5 REPLACE SWITCH AND HARDSHELL CONNECTOR PER RECALL.

99S15 SPEED CONTROL RECALL

RECALL 99S15 NOTICE RECALL 99S15 PERFORMED

RECALL COMPLETED

RECALL 99S15 COMPLETED RECALL 99S15

INSPECTED INSTALLED KIT TO COMPLETE

RECALL COMPLETED.

83775 W 99S15 REPLACE SPEED CONTROL DEACTIVATE SWITCH PER RECALL 99S15B .5

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

1 PERFORMED RECALL

RECALL 99S15 COMPLETED RECALL 99S15

REPLACE SPEED CONTROL SWITCH

X PERFORM RECALL- SPEED CONTROL SWITCH

PERFORM RECALL 99S15 R&R SWITCH PER RECALL 99S15

99984 REPLACED SWITCH & CONNECTOR PER RECALL

R&R SPEED CONTROL SWITCH,TEST DROVE TO VERIFY & REPAIR

RECALL

PERFORMED RECALL 99S15

2002-02-01 14:73

Box_Files

PERFORMED RECALL 98S15.
COMPLETED CAMPAIGN COMPLETED OF 98S15B
1 COMPLETED RECALL 98S15

RECALL 98S15
REPLACE DEACTIVATION SWITCH, RECALL
REPLACE SPEED CONTROL SWITCH AND CONNECTOR
RECALL 98S15 REPLACED SWITCH
SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 98S15
98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
1 PERFORMED LATEST REPAIR PROCESSES PERTAINING TO 98S15 PER RECALL INSTRUCTIONS
REPLACE SWITCH AND HARD SHELL

PERFORMED RECALL
98S16 RECALL 98S15 RECALL
PERFORM RECALL 98S15 PER INSTRUCTIONS
REPLACE CRUISE CONTROL SWITCH
RECALL 98S15 COMPLETED RECALL 98S15
RECALL 98S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 98S15
REPLACED SWITCH AND CONNECTOR PER RECALL
RECALL 98S15 NOTICE RECALL 98S15 PERFORMED
98712 98S15 98S15B .5 98S15B REPLACE SPEED CONTROL SWITCH, CONNECTOR
PERFORMED RECALL
98284 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B
98S15 RECALL REPLACE CRUISE DEACTIVATION SWITCH PER RECALL
PERFORMED RECALL 98S15
PERFORM RECALL PER FACTORY, INSTALL UPDATED CRUISE CONTROL DEACTIVATION SWITCH, RE-CK OK.
98S15B .5 PERFORM RECALL
98934 0.5 OPERATION 98S15B REPLACED SPEED CONTROL DEACTIVATION SWITCH TEST DROVE AND CHECKED SPEED CONTROL OPERATION OK

RECALL 98S15
98S15 SPEED CONTROL RECALL
PERFORM RECALL
98S15 RECALL REPLACE CRUISE DEACTIVATION SWITCH
REPL SWITCH PER RECALL 98S15
114813 RECALL 0.5 RECALL
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
NAC 98S15
RECALL 98S15. PERFORMED RECALL 98S15.

REPLACE SWITCH PER RECALL

98S15 REPLACED DEACTIVATION SWITCH AS PER RECALL
RECALL PERFORMED RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH
INSTALLED SWITCH PER RECALL
REMOVE TAPE AND SECURE LABOR OF 98S15B 0.5 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 98S15B .5 REMOVED TAPED AND SECURED SPEED CONTR
CHECK AND REPAIR AS REQUIRED
REPLACE SWITCH AND HARD SHELL

Box Files

55108 RECALL .50 .10ADWD 98S15-B UPDATED DEACTIVATION SWITCH N CONNECTOR
CRUISE CONTROL 98S15 PERFORM RECALL

98S15 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
RECALL 98S15 PERFORMED RECALL

98S15B 0.5
INSTALLED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
FACTORY RECALL COMPLETED RECALL
REPLACE BRAKE DEACTIVATION SWITCH AND CONNECTOR
PERFORMED RECALL

165577 RECALL WARR. RECALL 98S15 PERFORMED.
PERFORMED RECALL
RECALL 98S15
RECALL COMPLETED.
REPLACE SPEED CONTROL DEACTIVATION SWITCH
98S15 98S15 SPEED CONTROL

REPLACE DEACTIVATION SWITCH
115980 W REPLACE SPEED CONTROL SWITCH AND CONNECTOR 98S15B RECALL

98S15 98S15
152322 RECALL 98S15 PERFORM RECALL 98S15, REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR 5 WP
98S15B 98S15B

98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTIONS
SPEED CONTROL DEACTIVATION SWITCHES MAY DEVELOP RESISTIVE SHORT IN ELECTRICAL CIRCUIT THAT MAY CAUSE UNDERHOOD FIRE. REPLACED SWITCH
PERFORM RECALL

REPLACE KIT PER RECALL
RECALL 98S15
COMPLETED RECALL 98S15

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 98S15

118276 PERFORMED RECALL AND DURING DEACTIVATION SWITCH REPLACEMENT BRAKE VALVE BLOCK WAS DAMAGED REPLACED SWITCH AND CONNECTOR AND REFER TO
PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTOR

98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
REMOVED AND REPLACED SWITCH PERFORMED RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL JS 1
98S15 COMPLETED

RECALL COMPLETED.
98S15 98S15

REPLACE KIT PER RECALL
REPLACE CRUISE SWITCH PER RECALL 98S15

PERFORM RECALL 98S15
F PERFORM SAFETY RECALL

PERFORM RECALL INSTALL SWITCH
98S15 98S15

78044 RECALL 98S15 WARR INSTALL CRUISE DEACTIVATION SWITCH

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.
105699 RECALL 98S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL

Box_Files

EEC TEST PASS NOS PID MONITOR AND RECORD. CHECK OASIS FOR TSB-SSM LONG FUEL TRIM GO NEGATIVE AT HIGHWAY SPEEDS REPLACE MAF SENSOR RESET PCM EXTEN
 1 REMOVE, TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH - 99S15E .3
 RECALL TECH 997 MILES OUT 25050 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 1 08 REPLACED SWITCH
 INSTALLED DEACTIVATION SWITCH
 99S15 RECALL 99S15 COMPLETED RECALL
 REPLACE SWITCH AND CONNECTOR
 PERFORMED RECALL 99S15 INSTALLED SWITCH AND CONNECTOR PER RECALL 99S15
 COMPLETED RECALL 99S15-INSTALLED SPEED CONTROL DEACTIVATION SWITCH.
 99S15B 0.3
 REPLACED SWITCH AND CONNECTOR
 PERFORM RECALL PER MANUFACTURER DID RECALL
 PERFORM 99S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
 99S15 99S15 REPLACED SWITCH
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH
 RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
 PERFORM RECALL 99S15
 97917 RECALL REPLACE DEACTIVATION SWITCH
 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
 RECALL 99S15
 120434 RECALL 99S15 REPLACE SPEED CONTROL SWITCH PER RECALL
 99S15 RECALL 99S15 REPAIRED AS PER RECALL
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 99S15 REPLACE DEACTIVATION SWITCH
 RECALL COMPLETED
 REPLACED CRUISE CONTROL CABLE PER RECALL 99S15
 PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15
 PERF RECALL 99S15
 PERFORM RECALL 99S15
 INSTALLED DEACTIVATION SWITCH RECALL 99S15
 RECALL 99S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
 99S15 DID RECALL 99S15B 0.8 HRS
 99S15 RECALL INSTALL DEACTIVATION SWITCH
 G RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 99S15 RECALL 99S15 RECALL COMPLETE
 INSTALL KIT PER RECALL 99S15
 PERFORMED RECALL
 INSTALL DEACTIVATION SWITCH
 AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL SWITCH
 RECALL COMPLETED 99S-
 SPEED CONTROL DEACTIVATION SWITCH, REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15.
 X PERFORMED RECAL
 PERFORMED RECALL 99S15
 99S15B-0.5 ADMIN-0.1 CHANGED SPEED CONTROL DEACTIVATION SWITCH AS OUTLINED IN RECALL 99S15
 PERFORM RECALL 99S15 TEST DRIVE TO CHECK OK 1

EN02-925-A 2478

Box_Files

INSTALLED DISENGAGE SWITCH PER RECALL 99S15.
 REPLACED CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL
 129942 RECALL WP40 PERFORMED RECALL, REPLACE BRAKE PRESSURE SWITCH
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACE SWITCH AND CONNECTOR PER RECALL
 PERFORMED RECALL 99S15
 REPLACED DEACTIVATION SWITCH AND BLEED BRAKES PER RECALL
 PERFORM RECALL
 1 INSTALL SWITCH AS PER RECALL
 RECALL PERFORMED RECALL
 REPL SPD CNTRL DEACTIVATION SW
 PERFORMED RECALL
 PERFORM RECALL 99S15. REPLACE CRUISE DEACTIVATION SWITCH.
 SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH
 OPEN RECALL PERFORMED RECALL
 PERFORM 99S15 RECALL
 99S15 RECALL ON OASIS 99S15 RECALL REPLACED SWITCH & CONNECTOR
 1 PERFORM RECALL
 99S15 RECALL INSTALL SWITCH AS PER RECALL
 REPLACED SPEED CONTROL SWITCH AND CONECTOR
 COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR 99S15B .5 + .1
 AS PER RECALL 99S15 RECALL ON SPEED CONTROL SWITCH
 REPLACE SWITCH RECALL 99S15
 RECALL 99S15 - B - RECALL
 CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECALL
 RECALL RECALL
 FACTORY RECALL COMPLETED FACTORY RECALL
 COMPLETE RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 PERFORM RECALL
 99S15 REPLACED SWITCH AND CONNECTOR PER RECALL
 99S15 RECALL 99S15 RECALL
 REPLACE SWITCH AS PER RECALL
 PERFORM RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

40679 99S15 B .5 .5 RECALL
 REPLACED SPEED CONTROL DEACT SWITCH AND HARD SHELL CONN AS PER RECALL 99S15
 CHECK AND REPAIR AS REQUIRED
 REPLACED SWITCH AS PER RECALL
 COMPLETE 99S15
 TECHNICIAN COMPLETED RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH
 99S15E .3 SECURED SWITCH 99S15B .5 REPLACED SWITCH AND CONNECTOR PERFORMED DEACTIVATION OF SWITCH

1 REPLACED SPEED CONTROL SWITCH & CONNECTOR

COMP.RECALL 99S15

CORRE.INSTALL DEACTIVATION SW.

APRX TIME.0.5

PERFORM RECALL
 RECALL COMPLETED

Box_Files

RECALL REPLACE SWITCH AND CONNECTOR

PERFORM RECALL

COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99S15B .5 + .1

RECALL 99S15

INSTALLED DEACTIVATION SWITCH.

RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15

INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15

REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15B .5 REMOVED TAPED AND SECURED SPEED CONTR

1 COMPLETED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL

MODIFY SPEED CONTROL DEACTIVATION SWITCH PER CAMPAIGN.

116832 RECALL WARR, 99S15 DONE

PERFORMED RECALL

99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACE SWITCH PER RECALL

PERFORM RECALL 99S15

108168 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH NOTE PRIOR TO REPAIRS AIR BAG LIGHT FLASHING NO HORN ANTI LOCK LAMP ON CUSTOMER DECLINED AT

PERFORM RECALL AND REPLACE THE SWITCH

1 99S15B .5 ADMIN .1

REPLACE SWITCH AND CONNECTOR

99S15 99S15 RECALL

COMPLETE RECALL 99S15

99S15 99S15 REPLACED SWITCH AND CONNECTOR

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

RECALL PROFORMED RECALL PER LETTER

REPLACE DEACTIVATION SWITCH PER RECALL

99S15 99S15

RECALL COMPLETE

78702 RECALL 99S15 WARR REPLACED SPEED CONTROL DEACTIVATION SWITCH RD TEST AFTER

REPLACED SWITCH AND PLUG IN PER RECALL

OPEN RECALL PERFORMED RECALL

1 PERFORMED RECALL

REPLACE AS PER RECALL 99S15

INSTALL DEACTIVATION SWITCH PER 99S15

PERFORMED RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL 99S15B PERFORMED RECALL

RECALL RECALL

64768 PERFORMED RECALL 99S15 REPLACEMENT OF SPEED CONTROL DEACT. SWITCH AND HARDSHELL CONN.

PERFORMED RECALL

REPLACE SPEED CONTROL SWITCH

INSTALLED DEACTIVATION SWITCH

79 REPLACE BRAKE SWITCH AND CONECTOR PER RECALL

RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

DN2-020-A 3478

SPEED CONTROL SWITCH 99S15 RECALL
 99S15 99S15 PERFORM RECALL
 PERFORMED RECALL

PERFORMED RECALL

PERFORMED RECALL INSTALLED SWITCH
 REPLACED DEACTIVATION SWITCH PER RECALL 99S15
 REPLACE SWITCH
 82792 W REPLACE SWITCH AND CONNECTOR PER RECALL 99S15 GA
 PERFORMED RECALL 99S15, 99S15B .5HRS LABOR
 84705 RECALL TECH 9177 PERFORM RECALL 99S15 INSTALL SWITCH AND CONNECTOR
 RC RC
 REPAIR PER 99S15 RECALL
 SWITCH 99S15 PERFORM RECALL 99S15
 RECALL 99S15 OTHER REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER FORD RECALL
 AS PER RECALL 99S15 RECALL TO REPLACE SPEED CONTROL SWITCH
 REPLACED DEACTIVATION SWITCH,

97183 PERFORM 99S15 RECALL , REPLACED DEACTIVATION SWITCH

PERFORMED RECALL

78058 REPLACED SPEED CONTROL RECALL SWITCH 99S15.
 1 PERFORM RECALL
 PERFORM RECALL
 PERFORMED RECALL
 PERFORM RECALL 99S15 RECHECK OK 99S15B .5 ADMIN .1 1
 121442 TECH 113 99S15B 0.5 REPLACE SWITCH AND CONNECTOR PER FORD
 REPLACED SWITCH AND HARNESS
 82846 PERF. RECALL 99S15 W PERF. RECALL 99S15. REPLACE SWITCH. BLEED SYSTEM ROAD TEST PASSED
 PERFORMED RECALL 99S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH
 31362 99S15 W REPLACED SPEED CONTROL SWITCH AND CONETOR
 1 99S15B .5 ADMIN .1
 REPLACED DISENGAGE SWITCH PER RECALL 99S15.
 99S16E REMOVE TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED
 PERFORM RECALL
 RECALL PERFORMED RECALL
 . REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL AND PICK TAIL CONN
 RECALL COMPLETED
 REPLACED SPEED CONTROL SWITCH AND CONECTOR
 RECALL 99S15 RECALL 99S15
 TECHNICIAN COMPLETED RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL
 99S15 RECALL PERFORMED

RWRECALL RECALL 99S15 SPEED CONTROL COMPLETED
 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 99S15.

Box_Files

RECALL 98S15 RECALL
PERFORMED RECALL

REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH & PLUG IN PERFORMED RECALL 98S15

PERFORMED RECALL 98S15

PERFORM RECALL 98S15
REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER RECALL
REPLACE DEACTIVATION SWITCH
PER NOTIFICATION 98S15 INSTALLED BRAKE REPAIR KIT AS PER RECALL INSTRUCTIONS
PERFORMED RECALL
37711 REPLACE SWITCH AS PER RECALL.

INSPECT SPEED CONTROL SYSTEM AND COMPLETE LABOR OPERATION ACCORDINGLY COMPLETED SPEED CONTROL DEACTIVATION CAMPAIGN
REPLACED PARTS PER RECALL

90081 TECH 1084 REMOVED AND REPLACED DEACTIVATION SWITCH AS PER RECALL
PERFORMED RECALL DEACTIVATION SWITCH AND CONNECT
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CO NNECTOR
PERFORM RECALL 98S15
PERFORM RECALL
PERFORMED RECALL

RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 98S15B .5- ADMIN .1
INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN
1 PERFORMED RECALL 98S15

94758 RECALL 98S15 WRT PERFORMED RECALL 98S15
113331 TECH 101=RECALL=98S15B=0.5 REPLACE PRESURE SWITCH & CONECTOR
REPLACED RECALLED BRAKE SWITCH.

X REPLACE SPEED CONTROL DEACTIVATION SWITCH
PERFORM RECALL AND REPLACE THE SWITCH
INSTALLED CRUISE SWITCH AND CONNECTOR PER RECALL
RECALL DONE

98S15 RECALL COMPLETED
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

98S15 98S15
RECALL 98S15 REPLACE SWITCH AND CONNECTOR
PERFORM RECALL INSTALL SWITCH
RECALL RECALL

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REMOVE TAPE AND SECURE THI

RECALL 98S15 REPLACE SWITCH AND CONNECTOR
98S15 98S15
REPLACE CONNECTOR SHELL AND SWITCH AS PER RECALL 98S15...KS
REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL COMPLETE
RECALL COMPLETE
INSTALLED SWITCH PER RECALL
PERFORMED RECALL 98S15. 98S15B .5HRS LABOR
CRUISE RECALL 98S15 INSTALL SWITCH AND CONNECTOR

2002-025-A 3449

Box_Files

REPL BRK PRESS SWITCH
 PERFORM RECALL 99S15B
 SPEED CONTROL SWITCH 99S15 RECALL
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN TIME
 PERFORM RECALL REPLACE SWITCH
 RECALL REPLACE SWITCH & HARDSHELL CONNECTOR & BLEED BRAKES
 REPLACED DEACTIVATION SWITCH AND CONNECTOR
 99S15 99S15 REPLACED CRUISE SWITCH
 123121 REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL, BLEED SYSTEM AS PER RECALL
 REPLACE SPEED CONTROL REPAIR KIT AS PER RECALL
 RECALL 99S15 DONE
 1. PERFORMED RECALL AS PER OASIS
 COMPLETE RECALL
 X REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR
 102685 REPLACED CRUISE CONNECTOR AND SWITCH AS PER RECALL
 99S15
 PERFORMED RECALL
 INSTALLED SWITCH PER RECALL
 99S15 RECALL 99S15 COMPLETED RECALL
 INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 RECALL R-R DEAC SW, INSTALLED NEW CONN, RECKD O
 1 4301 INSPECT AND NECESSARY TO INSTALL CRUISE CONTROL CABLE AS PE RRECALL
 INSTALL NEW SWITCH
 COMPLETE RECALL

78203 99S15 99S15 .5 REPLACE SPEED CONTROL SWITCH & CONNECTOR, BLEED BRAKES
 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 1 PERFORM CRUISE RECALL
 RECALL NEEDED REPLACE CRUISE SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNE CTOR AS PER THE TECHNICAL INSTRUCTION
 PERFORM RECALL 99S15
 REPL SWITCH PER RECALL 99S15
 99S15 99S15
 99S15 PERFORM RECALL 99S15
 99S15 99S15
 RECALL 99S15 PERFORM RECALL 99S15
 PERFORMED RECALL
 RECALL PERFORMED RECAL
 PERFORMED RECALL ACCORDING TO INSTRUCTIONS
 RECALL 99S15
 RECALL 99S15 COMPLETED RECALL 99S15
 RECALL DID RECALL
 99S15 99S15
 PERFORM RECALL PER MANUFACTURER PERFORMED RECAL
 COMPLETE RECALL 99S15
 70985 RECALL REPL- SPEED CONTROLE DEACTIVATION SWITCH & PLUG - 99S15B 0.5
 RECALL 99S15 SPEED CONTROL SWITCHREPLACE SWITCH AND HARDSHELL CONNECTOR
 PERFORMED RECALL
 RECALL 99S15B NEC TO PERFORM RECALL 99S15B

ES022-025-R 3461

Box_Files

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 RECALL COMPLETE
 RPL SPEED CONTROL SWITCH PER 99S15
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 PERFORMED RECALL
 RECALL 99S15
 INSTALL CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACED SWITCH AND PLUG.
 SPEED CYRL DEACTIVATION SW RECALL 99S15 REPAIR PER RECALL
 99S15 99S15
 PERFORMED RECALL 99S15
 RECALL PERFORM RECALL AS REQUIRED
 INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH
 1 99S15SJS ADMIN .1
 45067 RECALL W REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 PERFORMED RECALL
 RELPACED DEACTIVATION SWITCH
 REPLACED SWITCH AND CONECTOR
 DID RECALL AS PRE INSTRUCTED
 RECALL R-R DEAC SW, INSTALLED NEW, CONN. RECKD OK.
 PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
 PERFORMED RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PER RECALL 99S15 -RECALLED
 REPL HARD SHELL CONNECTOR PER 99S15
 RECALL RECALL

 RECALL COMPLETE
 REPLACE SWITCH AND HARD SHELL
 INSTALL CRUISE SWITCH AND CONNECTOR
 124361 DUE RECALL 99S15
 99S15 99S15
 REPLACE DEACTIVATION SWITCH AS PER 99S15
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.
 PERFORMED RECALL
 RECALL 99S15
 PERFORM RECALL REPLACE SWITCH
 INSTALL SPEED CONTROL DEACTIVATION SWITCH
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR
 INSTALL SWITCH
 PERFORM RECALL
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 PERFORM RECALL
 REPLACE SPEED CONTROL SWITCH PER RECALL

 RECALL R-R DEAC SW, INSTALLED NEW CONN, RECKD O
 109711 PERFORMED RECALL *****NOTE: BRAKES PULSATE*****
 PERFORMED RECALL 99S15.

Box_Files

INSTALL CRUISE SWITCH AND CONNECTOR

PERFORM RECALL 99S15

99S15 RECALL 99S15B REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR FOR RECALL 99S15B

RECALL SPEED CONTROL SWITCH PERFORM RECALL 99S15, REPLACE SPEED CONTROL SWITCH

107503 RECALL 99S15B.5 PERFORM RECALL INSTALL CONN. AND SWITCH DISPATCH ERROR ON TIME RAN

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACE SWITCH AND CONNECTOR

99S15 99S15

RECALL COMPLETE

REPLACED DEACTIVATION SWITCH

113201 PERFORMED RECALL

PERFORMED RECAL

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

SWITCH REPL SPEED CONTROL DEACTIVATION SWITCH

OPEN RECALL PERFORMED 99S15 RECALL

PERFORMED RECALL

99S15 99S15 REPLACED CRUISE SWITCH

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

PERFORME 99S15

INSTALL NEW SWITCH AND CONNECTOR 99S15

RECALL INSTALLED SWITCH

COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR 99S15B .5 + .1

1 -COMPLETED SPEED CONTROL RECALL

0 99S15 PROGRAM

PERFORM RECALL 99S15

REMOVE & REPLACE CRUISE DEACTIVATION SWITCH

72067 DID RECALL REPLACED SWITCH

RECALL 99S15

1 COMPLETED RECALL 99S15

— RECALL COMPLETED

COMPLETED RECALL 99S15

RECALL 99S15B PERFORM RECALL 99S15B

INSPECT AND REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

1 REPLACED DEACTIVATOR SWITCH AND PLUG PER RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR. 5

REPLACED SPEED CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH 99S15

IPR AND EBP OUT OF SPEC FOLLOWED PERFORMANCE SHEET 1-14 REPLACED IPR AND TEST DROVE CODE 470 PID DIAG EBP 30 PSI OUT OF RANGE REPLACED EBP CLEAR

FACTORY RECALL COMPLETED RECALL

REPLACED SPEED CONTROL BRAKE KIT

99S15 99S15 REPLACED SWITCH

REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL

PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

99S15 RECALL COMPLETED

PERFORM RECALL INSTALL NEW SWITCH AND BLEED REAR BRAKES

99S15 99S15

INSTALL SWITCH

Box_File

PERFORM RECALL
98S15 SPEED CONTROL CABLE REPLACED SPEED CONTROL CABLE PER RECALL 98S15
AS PER RECALL 98S15 RECALL TO INSTALL CRUISE CONTROL SWITCH

REPLACE CRUISE CONTROL SWITCH WIRE CONN, BLEED BRAKE PER RECALL, RT OK
RECALL 98S15 98S15 REPLACE SPEED CONTROL SWITCH

PERFORM 98S15

PERFORMED RECALL

REMOVE & REPLACE SPEED CONTROL DEACTIVATION SWIT

REPLACE SPEED CONTROL SWITCH PER RECALL

PERFORMED RECALL

REPLACE CRUISE CANCEL SWITCH

RECALL R-R DEAC SW, INSTALLED NEW CONNECTED, RECD OK

REPLACE DEACTIVATION SWITCH

210115 PERFORM RECALL

RECALL

98S15 RECALL, REPLACE SWITCH

RECALL 98S15

RECALL 98S15

DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACED SWITCH

INSTALLED DEACTIVATION SWITCH PER RECALL, RT OK

RECALL 98S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

PERFORMED RECALL

RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 98S16B FOR .6 AND .1 FOR ADMIN. TIME

PERFORMED RECALL

PERFORMED RECALL

PERFORM RECALL

PERFORMED RECALL 98S15B 1 PERFORMED RECALL

RECALL COMPLETED

COMPLETED RECALL PER INSTRUCTIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACED DEACTIVATION SWITCH

REPLACE DEACTIVATE SWITCH AND CONNECTOR SHELL PER 98S16B

NOTE: FRONT BRAKES ARE 1-32 CUST. DECLINED-BELT IS DRY ROT DECLINED-BATTERY HAS CORROSION DECLINED CLEANING-
G RC 98S16 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE SWITCH AND CONNECTOR

98S15 TECH 113 98S16B 0.5 PERFORM RECALL PER FORD REPLACE SWITCH AND CONNECTOR

SERVICED A SPCR RECALL

PERFORMED 98S15 RECALL

1 PERFORM RECALL

98S15 98S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR R PER RECALL, BLEED BRAKES

RECALL

RECALL

RPLC CRUISE DEACTIVATION SWITCH PER 98S15

SPEED CONTROL SWITCH 98S15 RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER CAMPAIGN 98S15

OPEN RECALL

PERFORMED RECALL

RECALL 98S16B COMPLETED RECALL 98S16B COMPLETED

Box Files

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 REPLACE SWITCH
 INSTALL SWITCH
 PERFORM COMPLETE RECALL 99S15 PER INST
 COMPLETED RECALL AS PER INSTRUCTIONS
 99S15 RECALL 99S15 COMPLETED RECALL
 130678 99S15 REPAIR SPEED CONTROL
 93349 RECALL INSTAL BK SWITCH AS PER RECALL 99S15 XXX ROAD TESTED TO MAKE SURE CRUISE CONTROL WORKS PROPERLY
 99S15 99S15
 PERFORMED RECALL 99S15
 REPLACED SWITCH
 PERFORM 99S15
 REPL CRUISE CONTROL SWITCH AND METERING BLOCK - BLEED BRKS
 99S15 99S15
 REPLACE CRUISE CONTROL BRAKE CANCEL SWITCH
 REPLACE SPEED SWITCH AS PER RECALL
 RECALL R-R DEAC SW, INSTALLED NEW, RECD OK
 99S15 REPLACE DEACTIVATION SWITCH
 RECALL PERFORMED RECALL 99S15
 109012 99S15B 0.5 0.5 PERFORM CAMPAIGN 99S15
 REPLACE SW AND PLUG
 99S15 COMPLETED
 REPL CRUISE SWITCH 99S15
 PERFORM RECALL
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH
 CAMPAIGN COMPLETED

RPL SPEED CONTROL DEACTIVATION SWITCH PER 99S15
 REPLACED SWITCH AND CONNECTOR
 PER NOTIFICATION RECALL 99S15 REMOVE TAPE AND SECURE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 INSTRUCTIONS

NA 99S15 REPLACED DEACTIVATION SWITCH
 REPLACED DSPEED CONTROL DEACTIVATION SWITCH
 RECALL COMPLETE
 117000 RECALL WPB30 PERFORMED RECALL 99S15 REPLACED SPEED SWITCH
 61508 T 0.4, PERFORMED THE RECALL
 RECALL REPLACED SWITCH
 PERFORMED RECALL
 106800 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 47832 PERFORMED RECALL
 PERFORM RECALL 99S15 PER TECHNICAL INSTRUCTIONS
 640494 PERFORM RECALL INSTALLED SWITCH AND CONNECTOR
 PERFORMED RECALL AS OUTLINED
 COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99S15B .5 + .1
 PERFORM RECALL
 REPLACED CRUISE DEACTIVATE SWITCH AND HARDSHELL CONNECTOR PER RECALL
 1 1 REPL CONNECTOR
 OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15

Box Files

AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL

REPLACED DEACTIVATION SWITCH & CONNECTOR

1 CK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPAIR AS PER 99S15

PER RECALL PERF RECALL

REPL BRK PRSS SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL

RECALL 99S15 INSTALLED SPEED CONTROL SWITCH

1 PERFORMED RECALL 99S15

1 REPL CRUISE DEACT SWITCH

99S15 RECALL 99S15 RECALL

REPLACED DEACTIVATION SWITCH AND CONNECTOR

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY AND CONNECTOR. CHECK NORMAL OPERATION

REPLACED DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH T117

1 PERFORM RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

49098 PERFORMED RECALL REPLACED SWITCH & CONNECTOR

PERFORMED RECALL, INSTALLED NEW SWITCH

REPLACED SWITCH AND CONNECTOR

99S15 RECALL 99S15 RECALL COMPLETE

74747 PERFORM RECALL, REPLA SWITCH 99S15B .5

102112 PERFORM 99S15 RECALL PER INSTRUCTIONS

RECALL RECALL

SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL RECALL

88063 WPB40 WPB40 REMOVE AND INSTALL SPEED DEACTIVATION SWITCH AND HARNESS. POST TEST, POST ROAD TEST.

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

80232 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

97457 RECALL PERFORMED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PERFORM RECALL

43272 INSPECT FOR DEACTIVATION SWITCH. REMOVE AND REPLACE THE SWITCH AND CONNECTOR AS PER RECALL 99S15

PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATOR. PER RECALL

RECALL 99S15 PERFORMED RECALL 99S15

RECALL 99S15

COMPLETED RECALL 99S14

REPLACED SPEED CONTROL CABLE

REPLACED DEACTIVATION SWITCH & CONNECTOR

REPLACED DEACTIVATION SWITCH

RECALL PERFORMED

REPLACED SC DEACTIVATION SWITCH 99S15

8982-828-9 3455

Box_Files

PERFORMED RECALL AS PER INSTRUCTIONS
 PERFORMED RECALL INTERIM AND PART REPLACEMENT REPAIR R0 43757A WAS CODED INCORRECTLY ON THE LABOR OPERATION ALSO 43757A WAS CHARGEDBACK
 REPLACED DEACTIVATION SWITCH PER RECALL 99S15
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 RECALL COMPLETED
 REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 80202 PERFORMED SPEED CONTROL RECALL
 PERFORM RECALL 99S15
 PERFORM 99S15 RECALL

PERFORM RECALL 99S15- REPLACE CRUISE CONTROL SWITCH

RECALL DONE
 17442 RECALL WP40 PERFORMED RECALL, REPLACED CRUISE CONTROL DEACTIVATION SWITCH.
 RECALL PERFORMED RECALL
 31243 99S15 W REFORID 99S15 SPEED CONTROL SWITCH JH
 31067 RECALL 99S15 RECALL 99S15 DEACTIVATION SWITCH
 99S15, SWITCH AND CONNECTOR
 PERFORM RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER REC 99S15

137382 RECALL R&R DEACT. SWITCH & CONNECTOR PER RECALL
 67291 INSPECT AND REPLACE DEACTIVATION SWITCH PER 99S15 RECALL
 99S15. 99S15-REPAIR CRUISE CONTROL
 CHECKED OASIS. INSTALLED SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL SWITCH
 SPD CTRL DEACTIVATION SW REPLCMT PERFORMED RECALL 99S15
 PERFORM RECALL
 99S15 99S15
 99S15 RECALL 99S15B U.S.HRS REPLACE SWITCH AND CONNECTOR TK372
 REPLACE CRUISE SWITCH AND CONNECTOR
 RECALL PERFORM RECALL PER FORD
 SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15
 1 PERFORMED RECALL 99S15
 REPLACE CRUISE SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 DIAG PERFORMED RECALL 99S15
 REPLACE SPEED CONTROL SWITCH
 INSPECT AND REPLACE PRESSURE SWITCH AND CONNECTOR AS PER RECALL
 99S15 99S15 REPLACED CONNECTOR AND SWITCH
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .B
 RECALL 99S15 COMPLETED
 PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 PERFORMED RECALL 99S15, INSTALLED NEW DEACTIVATION SWITCH.
 RECALL 99S15B COMPLETED RECALL 99S15B COMPLETED
 F RG 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 99S15 RECALL, R & R SPEED CONTROL BRAKE DIAC. SWITCH AS PER RECALL
 148167 PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 99S15, ROAD TEST AND VERIFIED REPAIR
 RECALL DONE
 107612 PERFORM RECALL 99S15 REPLACE BRAKE SWITCH JUNT

2002-02-01 11:34:07

Box_Files

RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT
 68542 RECALL 99S15 REPLACED SPEED CONTROL SWITCH ROAD TEST OK
 MISC VEHICLE DAMAGE; L-F POWER WINDOW CONTROLS LOOSE BEZEL; AIR BAG LIGHT ON; FOG HORN ON
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR
 99S15 99S15
 RECALL COMPLETED
 78140 REPLACED SWITCH PER RECALL TECH 506
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 COMPLETE RECALL
 REPL SWITCH PER RECALL
 120489 REPLACE SWITCH PER 99S15 8728
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
 74505 RECALL REPLACED C C DEACTIVATOR SWITCH
 RECALL REPLACE M SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 60506 RECALL DID RECALL REPLACED SWITCH AND WIRES TECH 10
 RECALL RECALL
 SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15 RECALL
 REPLACE DEACTIVATION SWITCH SPEED CONTROL
 REPLACE DEACTIVATION SWITCH AND HARDSHELL CON NECTOR PER RECALL
 CAMPAIGN COMPLETED
 48982 W F INSTALLED DEACTIVATION SWITCH AS PER RECALL
 48923 REPLACE SWITCH PER RECALL
 REPLACED DEACTIVATION SWITCH
 RECALL PERFORM RECALL 99S15
 PERFORM UPDATE
 77215 RECALL 99S15 RECALL 99S15 DEEACTIVATION SWITCH
 FACTORY RECALL COMPLETED RECALL
 RECALL 99S15 PERFORM RECALL 99S15

RECALL
 139253 PERFORMED RECALL
 PERFORMED RECALL 99S15
 PERFORMED RECALL

PERFORM RECALL 99S15- REPLACE SPEED CONTROL SWITCH

NA 99S15 REPLACED SWITCH
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .8

REPLACE CRUISE DEACTIVATION SWITCH
 PERFORMED RECALL
 PERFORM RECALL
 63705 REPLACED C-C DE-ACTIVATION BUTTON M1 0.5 CC 42 PARTS FAILURE THIS RD LINE A
 JS PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 RECALL COMPLETED
 X REPLACED CRUISE DEACTIVATION SWITCH
 PERFORMED RECALL
 REPL CRUISE CONTROL SWITCHES
 1 PERFORM RECALL AS PER INSTRUCTIONS

5902-023-0 3408

Box_Files

RECALL 99S15 PERFORMED RECALL 99S15
SPEED CONT REPL SWITCH
00 99S15B
RECALL REPLACE SWITCH
PERFORMED RECALL 99S15
PERFORME 99S15
COMPLETED RECALL 99S15B 1
DID RECALL 99S15
120602 PERFORMED RECALL,REPLACED SWITCH

99S15 99S15
REPLACE SWITCH
RECALL 99S15 99S15 REPLACE SPEED CABLE
REPLACE DEACTIVATION SWITCH AS PER RECALL
99S15 99S15 PERFORM RECALL
PERFORMED RECALL 99S154
REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SECURED SPEED CONTR
99S02 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH
COMPLETE RECALL
PERFORMED RECALL 99S15-INSTALL SWITCH
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
REPLACED SWITCH AND CONNECTOR
INSTALL NEW SWITCH
REPLACE DEACTIVATION SWITCH AS PER 99S15

99S18 PERFORM RECALL 99S15.
42058 R&R SWITCH
COMPLETED RECALL
REPLACE BRAKE SWITCH
PERFORMED RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

99S15 SPEED CONTROL DEACTIVATION REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
99S15 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
115149 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
REPLACED BRAKE DEACTIVATION SWITCH
43137 PERFORM RECALL FOR CRUISE DE-ACTIVATION REPLACED SWITCH AND CONNECTOR

REPLACED SWITCH PER RECALL 99S15

PERFORMED RECALL 99S15
44991 PERFORM RECALL 99S15 REPLACED DEACTIVATION BRAKE SWITCH
INSTALL PER RECALL
PER RECALL REMOVED OLD SWITCH AND INSTALL NEW SWITCH AND CON N PER RECALL
PERFORMED RECALL 99S15
1 REPLACED SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATIONS.
PERFORMED RECALL

EM62-628-R 3489

Box_Files

PERFORM RECALL 99815 R&R CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR
 PERFORMED RECALL 99815-INSTALL SWITCH
 REPLACE CRUISE DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99815
 RECALL SW REPL
 99815 99815 RECALL
 REPLACE SWITCH PER RECALL

PER RECALL 99815
 REPLACED SWT PER RECALL
 RECALL 99815B PERFORM RECALL 99815B
 RECALL 99815 99815
 SAFETY RECALL 99815 -REPLACE SPEED CONTROL DEACTIVATION SWITCH

47172 79 PERFORM 99815 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST
 74388 CC 42 99815B 0.5- ADMIN 0.1 REPLACED SWITCH AND CONNECTOR.
 1 PERFORM RECALL 99815
 REPLACE DEACTIVATIO SWITCH PER RECALL
 99815 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONN.
 00 99815B
 REPLACED SWITCH AND CONNECTOR
 PERFORMED RECALL AS PER INSTRUCTIONS
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99815
 PERFORM RECALL ON SPEED SWITCH
 1 INSTALLED SWITCH AS PER RECALL
 99815 RECALL
 1 INSTALL DEACT SWITCH AS PER RECALL
 1 REPLACE THE CRUISE DEACT SWITCH PER RECALL
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99815
 PERFORM RECALL 99815
 REPLACED CONNECTOR AND SWITCH AS PER RECALL
 REPLACED SWITCH PER RECALL
 RECALL 99815
 TECH 141 PERFORM RECALL 99815
 MODIFY AS PER INSTRUCTIONS
 35948 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99815B
 1 PERFORMED RECALL 99815 REPLACED CRUISE CONTROL SWITCH AND CONNECTOR

THE SHORT MAY DISABLE THE SPEED CONTROL SYSTEM OR CAUSE A FUSE TO OPEN. AFTER INSPECTION,IF THE VEHICLE IS INVOLVED THE DEALER WILL REPLACE THE DEAC
 RECALL 99815 RECALL 99815
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99815
 99815 SP SW REPLACE
 RECALL PERFORMED
 RECALL COMPLETED
 PERFORMED RECALL 99815
 REPLACED SWITCH AND CONNECTOR

ERR2-025-A 2499

Box_Files

REPLACED SC DEACTIVATION SWITCH 99S15
99S15, CRUISE SWITCH
REPLACE CRUISE SWITCH PER RECALL

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15E
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

RECALL 99S15
RECALL CRUISE CONTROL RECALL 99S15

101858 99S15 RECALL
79849 99S15B 0.5 ADMIN D.1

PERFORM RECALL
REPLACE DEACTIVATION SWITCH AS PER RECALL
REPLACED SPEED CONTROL SWITCH AND CONNECTOR
99S15 99S15 REPLACED CONNECTOR AND SWITCH
PERFORMED RECALL 99S15
PERFORMED 99S15 RECALL
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
COMPLETE RECALL 99S15
RECALL COMPLETE

PERFORMED RECALL
REPLACE SWITCH
PERFORM 99S15 RECALL
X PERFORMED RECALL
REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15
128402 INSTALLED RECALL
74329 RECALL 0.5 99S15B INSTALLED RECALL SWITCH
RECALL 99S15 RECALL COMPLETE
47812 99S15 RECALL 99S15 REPLACE DEACTIVATOR SWITCH
REPLACE SWITCH AND HARD SHELL
PERFORM RECALL
99S15 RECALL
147485 PERFORM 99S15
99S15 RECALL COMPLETED

RECALL COMPLETED.
REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
1 REPLACE DEACTIVATION SWITCH
89711 REPLACE THE DEACTIVATION SWITCH
REPAIR AS PER RECALL
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
RECALL SW REPL
REPLACED DEACTIVATION SWITCH AND CONNECTOR.
85382 PERFORM 99S15 SPEED CONTROL SWITCH ROAD TEST OK
RECALL COMPLETED.
PERFORM 99S15 REPLACE CRUISE DUMP SWITCH BLEED BRAKES
RECALL 99S15 INSTALLED MODIFICATION FOR CRUISE CONTROL
PERFORM RECALL
COMPL: RECALL 99S15, SPEED CONTROL SWITCH. REPLACED DEACTIVATION SWITCH & CONNECTOR. APPROX TIME; 0.5 HRS

Box_Files

RECALL PERFORMED RECALL 99S15
 COMPLETED RECALL 99S15
 REPL SPD CNTRL DEACTIVATION SW
 REPLACED FAULTY C-CONTROL DEACTIVATION SWITCH, PER 99S15B.
 99S15 RECALL ON 0A808 99S15 RECALL REPLACED SWITCH & CONNECTOR
 99S15 RECALL
 PERFORM RECALL 99S15 REPLACE SPEED CONTROL SWIT
 PERFORM RECALL 99S15
 RECALL 99S15 PERFORMED RECALL 99S15
 REQUEST RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 UNKNOWN INSTALL CRUISE SWITCH AND CONNECTOR PER 99S15
 COMPLETED RECALL 99S15
 99S15 RECALL
 REPLACE AS PER RECALL 99S15
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
 SHORT MAY DIASABLE SPEED CONTROL OR CAUSE BRAKE LIGHT FUSE TO OPEN DISCONNECT CONNECTOR FROM CRUISE DEACTIVATION SWITCH & PROTECT END FROM COI
 70657 PERFORMED RECALL 99S15
 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 182122 RECALL 0.5 99S15B INSTALLED RECALL SWITCH
 RECALL 99S15 PERFORM RECALL 99S15
 INSTALL SPEED CONTROL CONNECTOR
 6857 99S15 99S15 .5 .5 99S15
 83150 RECALL 0.5 INSTALLED RECALL SWITCH
 PERFORMED RECALL
 REPLACED DEACTIVATION SWITCH AD HARD SHELL CO NNECTOR AS PER RECALL 99S15
 99S15 RECALL PERFORMED
 83450 REPLACED SPEED CONTROL DEACTIVATION S-W PER R RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL COMPLETED

 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 82 INSTALL RECALL SWITCH
 RECALL PERFORMED RECALL
 PERFORMED RECALL AS NEEDED ALL AOK
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 99S15 99S15
 REPLACE SWITCH AND CONNECTOR
 REPLACE SWITCH AND HARD SHELL
 REPLACE KIT PER RECALL
 RECALL PERFORMED
 INSTALLED SWITCH PER RECALL
 RECALL 99S15 COMPLETED
 REPLACE DEACTIVATION SWITCH
 41352 99S15 W REPLACE SPEED CONT. SWITCH
 65142 RECALL 99S15 RECALL 99S15
 185601 PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION & REPLACE WITH NEW KIT
 1 RECALL COMPLETE
 99208 REPLACE DEACTIVATION SWITCH PER 99S15 RECALL

8082-923-4 3482
 8082-923-4 3482

Box_Files

PERFORMED RECALL 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH
1 PERFORMED RECALL 99S15
199119 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 DONE 7216
CHECK AND REPAIR AS REQUIRED
RECALL RECALL
ONP PERFORMED RECALL
INSTALLED DEACTIVATION SWITCH AS PER RECALL 99S1
RECALL-SWITCH REPLACE DEACTIVATION SWITCH & CONN.
99S15 RECALL 99S15 RECALL
INSTALL CRUISE DISABLE SWITCH AND CONNECTOR PER RECALL
148342 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RPL SPEED CONTROL SWITCH PER 99S15

REPLACE DEACTIVATION SWITCH-WARRANTY-RECALL-BILL
F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
80583 W REPLACED SPEED CONTROL SWITCH PER RECALL 99S15.

99S15 99S15
TEST & REPLACE DEACTIVATION SWITCH
INSTALLED SPEED CONTROL DEACTIVATION SWITCH AND HEAT SHIELD CONNECTOR PER RECALL
PERFORM RECALL
REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15
PUT NEW DEACT SWITCH FOR SPEED CONTROL AND NEW WIRE CONNECT AND BLEED BRAKES
1 COMPLETED RECALL PER FORD INSTRUCTIONS. REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH. THANK YOU, KENN
SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15
1 DEACTIVATION SWITCH RECALL

RECALL 99S15 REPL SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
REPLACED SC DEACTIVATION SWITCH 99S15
RECALL 99S15
99S15 RECALL ON OASIS 99S15 RECALL REPLACED SWITCH & CONNECTOR
INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS NOTED IN RECALL 99S15 ALL OK TO RELEASE
1 PERFORMED RECALL 99S15
RPLG CRUISE CTRL DEACTIVATION SWITCH & CONNECTION PER 99S15
AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL

111847 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15.
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.
RECALL 99S15
REPLACED BRAKE DEACTIVATION SWITCH
63243 0.5 HRS REPLACED DEACTIVATION SWITCH PER RECALL 99S15.

Box_Files

104587 RECALL INSTALL NEW SWITCH AND PLUG
 RECALL RECALL
 PERFORMED RECALL 98S15
 RECALL 98S15 RECALL PERFORME
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
 REPLACED SWITCH PER 98S15
 70708 RECALL WPG40 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
 PERFORM RECALL 98S15 R&R CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR
 98S11 REPLACE SPEED CONTROL SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
 RECALL COMPLETED
 COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED 98S15 RECALL
 1 PUT KIT IN 77 STEVE
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 1 REPLACE SPEED CONTROL SWITCH 1
 SPEED CONTROL SWITCH 98S15 RECALL

PERFORMED RECALL
 REPLACED SC DEACTIVATION SWITCH 98S15
 PERFORMED RECALL 98S15
 98S15 RECALL ACT SWITCH
 PERFORM RECALL
 101419 98S15 RECALL WF INSTALL SPEED CONTROL SWITCH

RECALL 98S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15
 PERFORMED FACTORY RECALL 98S15
 RECALL 98S15 RECALL 98S15
 108714 RECALL 98S15B 0.5HRS REPLACE SWITCH AND CONICTOR TK372
 RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

1 PERFORM RECALL REPLACE DEACT SWITCH
 REPL CRUISE CONTROL SWITCH
 RECALL 98S15
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15
 1 PERFORMED RECALL 98S15
 RECALL 98S15
 RECALL COMPLETE
 RECALL 98S15 REPLACED SWITCH
 PERFORMED 98S15 RECALL
 1 REPLACE CRUISE DEACTIVATION SWITCH & CONNECTOR PER RECALL
 PERFORM RECALL 98S15 98S15
 RECALL PERFORM RECALL PER PROGRAM 98S15, SPEED DEAC SWITCH
 DEACTIVATION SWITCH 98S15
 PERFORMED RECALL 98S15 SPEED CONTROL

EM62-025-A 3494

Box_Files

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

RECALL 99S15

- MODIFY PER RECALL 99S15

1 REPLACED SWITCH AND CONNECTOR

RECALL COMPLETED 99S15 PERFORMED

RECALL 99S15 REPLACED DEACTIVATER SWITCH AND CONNECTOR AS PER RECALL 99S15.

REPLACED SPEED CONTROL DEACTIVATION SWITCH

41782 RECALL 99S15 PERFORMED RECALL 99S15

SPEED CONTROL SWITCH 99S15 RECALL

38745 RECALL WARR PERF. RECALL 99S15

OPEN RECALL PERFORM RECALL

99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

RECALL COMPLETE

AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH

PERFORMED RECALL AS PER INSTRUCTIONS

PERFORM RECALL 99S15

RECALL COMPLETE

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

71828 RECALL CRUZ CONTROL DEACTAVATION SW AND CONECTO WARR REPLACED DEACTAVATION SW AND HARD SHELL CONECTO ASSY PER RECALL 99S15

91271 R99S15 0.5HR RECALL COMPLETE

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONECTO

RECALL INSTALLED DEACTIVATION SWITCH

RECALL 99S15 REPLACED SWITCH

INSTALLED KIT TO COMPLETE

RECALL 99S15 99S15

PERFORM RECALL 99S15

RECALL 99S15B ... REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15

APPLIED RECALL 99S15

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL

INSTALL CRUISE SWITCH

99S15 RECALL PERFORMED

REPLACED SWITCH AND HARD SHELL CONNECTOR

PERFORM RECALL 99S15

58528 REPLACE BRAKE SWITCH AS PER RECALL 99S15B 0.5 HR

RECALL 99S15. REPAIRED IN AW RECALL 99S15.

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

INSTALL CRUISE CONTROL DEACTIVATION SWITCH

PERFORME 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

87128 INSTLL SWITHCH AND CONNECTOR

RECALL 99S15 REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15

REPLACE DEACTIVATION SWITCH

PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

90317 RECALL 99S15B 0.5 REPLACE DEACTIVATION SWITCH & HARD SHELL CONN

Box_Files

99S15 RECALL PERFORMED 99S15
 107605 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL ***WIPER DID NOT WORK PRIOR TO REPAIR WIPER MOTOR IS MISSING***
 PERFORMED RECALL 99S15
 99S15 INSTAL SWITCH AND CONNECTOR PER RECALL
 1 COMPLETED RECALL 99S15
 PERFORM RECALL 99S15
 RECALL COMPLETE
 PERFORMED RECALL
 118800 99S15B SHRL PERFORM RECALL
 119884 INSTALLED DEACTIVATION SWITCH AND WIRE PLUG
 33123 99S15 REPLACED THE BRAKE LINE SWITCH
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 99S15 REPLACE SWITCH AND CONNECTOR PER RECALL
 REPLACE SWITCH
 PERFORM RECALL 99S15 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 RECALL COMPLETE
 39103 RECALL 99S15B 0.3L PERFORMED RECALL
 68268 RECALL 99S15 WR REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL

 1 COMPLETED RECALL 99S15
 TECH 812 PERFORMED RECALL SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL
 RECALL COMPLETED
 69991 RECALL RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 1 PERFORM RECALL
 PERFORMED RECALL 99S15, REPLACE SPEED DEACTIVATION SWITCH
 SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 99S15
 99134 INSTALLED SW. AND HARD SHELL CONNECTION
 RECALL 99S15
 99S15B 0.5

 WORKING ON 74027 FROM 10-12-89 HEATER. PERFORM 99S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT RECALL.
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS INSTALLED DEACTIVATION SWITCH
 PERFORMED RECALL REPLACED SWITCH AND CHECKS OK
 99S15B RECALL
 COMPLETE RECALL 99S15
 RECALL 99S15B ... REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15
 SPEED CONTROL DEACTIVATION MOD. 99S15 RECALL REPLACE SPEED DEACTIVATION SWITCH AND CONNECTOR
 RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTOR
 1 PERFORM RECALL

 RECALL COMPLETED
 SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CKT THAT MAY RESULT IN AN UNDERHOOD FIRE. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CON
 PERFORM RECALL INSTALL SWITCH
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH

Box_Files

INSPECT AND PERF RECALL ACCORDING TO INSTRUCTIONS ==THANK YOU-DARREN GREEN TEAM== 1
RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
OPEN RECALL PERFORMED RECALL
PERFORM RECALL
REPLACED SC DEACTIVATION SWITCH 98S15
82731 98S15 0.5HR RECALL COMPLETE
RECALL 98S15 REPLACE C-C SW
38487 98S15 W REPLACE SWITCH 98S15 RECALL GA
. INSTALL SWITCH AS PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH
1 PERFORMED RECALL 98S15
83540 RECALL WTY PREFORM RECALL

INSTALL CRUISE CONTROL SWITCH AS PER RECALL
PREFORM RECALL PER TECH INSTRUCTIONS
800096 WARR PERFORM RECALL 98S15
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY. CHECK NORMAL OPERATION.
INSTALL UPATED SWITCH
. REPLACED SPEED CONTROL DEACTIVATION SWITCH
RECALL COMPLETED
REPLACED SPEEDS CRUS CONTROL SWITCH FOR RECALL
144158 INSTALL RECALL PARTS
PERFORMED RECALL 98S15 INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTO

90304 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15..ALSO NOTE THAT DUE TO MILEAGE RECOMMEND TRANS SERVICE, COOLANT SERVICE, INJECTOR CLEAN
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S
1 PERFORM RECALL REPLACE DEACTIVATION SWITCH

RECALL 98S15 R AND R SPEED CONTROL DEACTIVATION SWITCH PER RECALL
73083 RECALL COMPLETE
REMOVE AND REPLACE DEACTIVATION SWITCH AS PER RECALL 98S15
PERFORM RECALL
98S15-SWITCH RECALL 98S15-SWITCH RECALL
98S15 98S15
RECALL 98S15 RECALL 98S15

94246 RECALL REPLACED CRUISE SW
PERFORMED OPEN RECALL

38582 RECALL WP30 PERFORMED 98S15 RECALL INSPECTION ONLY.
REPLACED SWITCH
PERFORM RECALL 98S15 SPEED CONTROL
REPLACED SWITCH AND CONNECTOR
98779 98S15 PERFORMED RECALL
RECALL 98S15
1 PERFORM RECALL

EMIZ-025-A 3497

Box_Files

RECALL RECALL
 1 PERFORMED RECALL 99S15
 REPLACED CRUISE DEACTIVATION SWITCH
 99S15 99S15
 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR.
 74490 PERFORMED RECALL 99S15 REPLACED HARD-SHELL CONNECTOR
 PERFORMED THER ECALL 99S15
 PERFORMED RECALL
 COMPLETED RECALL 99S15
 RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SWITCH & CONNECTOR PER RECALL
 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 RECALL 99S15 REPLACE SWITCH AND CONNECTOR
 COMPLETE RECALL 99S15
 1 PERFORMED RECALL
 RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
 OPEN RECALL PERFORMED RECALL
 99229 REPLACE SPEED CONTROL SWITCH + CONNECTOR
 INSTALLED DEACTIVATION SWITCH PER RECALL
 1 PERFORM RECALL 99S15
 SPEED CONTROL SWITCH
 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15
 REPLACE DEACTIVATION SWITCH
 REPLACE BRAKE PRESSURE SWITCH PER RECALL.

RECALL 99S15 COMPLETED
 REPLACE SWITCH AND CONNECTOR PER RECALL
 REPLACED WIRING HARNESS FROM COMPUTER & INJECTOR
 1 PERFORMED RECALL 99S15
 024 REPLACED CRUISE DEACTIVATION SWITCH
 PERFORM RECALL
 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.
 R AND R DEACT SWITCH AND CONNECTOR
 189448 99S15 RECALL WF INSTALL SPEED CONTROL DEACTIVATION SWITCH
 99S15
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.

REPLACED THE SWITCH PER RECALL 99S15
 REPLACED SPEED CONTROL SWITCH.
 RECALL 99S15 REPLACE C-C SW
 RECALL SW CRUISE SW REPL
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
 PERFORMED 99S15 RECALL
 99: PERFORMED 99S15 RECALL, REPLACE CRUISE SWITCHES
 58876 RECALL 99S15 DONE SPEED CONTROL DEACT SWITCH
 COMPLETED RECALL
 REPLACED SPEED CONTROL CABLE PER RECALL

58876-423-4 3498

Box_Files

FACTORY RECALL COMPLETED RECALL

PERFORM RECALL

99314 REPLACED SPEED CONTROL SENSOR AS PER RECALL 99S15

REPLACE CRUISE DEACTO SWITCH

88080 W REPLACE SWITCH GA

PERFORMED RECALL REPLACE HARD SHELL CONNECTOR

REPLACE CRUISE DEACT SWITCH

OPEN RECALL PERFORMED 99S15 RECALL

PERFORM RECALL ON SPEED CONTROL SWITCH

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL COMPLETE

78843 SAFETY RECALL 99S15 W COMPLETED SAFETY RECALL

PERF RECALL 99S15

RECALL COMPLETE

PERFORMED RECALL 99S15-INSTALLED DEACTIVATION S WITCH

D RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACE SWITCH PER RECALL

FACTORY RECALL COMPLETED RECALL

99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

INSTALL CRUISE CONTROL SWITCH PER RECALL

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15

PERFORM RECALL 9222

RECALL 99S15 COMPLETED

58380 R99S15 0.05HR RECALL COMPLETE

1 INSTALL SWITCH FOR RECALL

RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S16B FOR .5 AND .1 FOR ADMIN. TIME

COMPLETE RECALL 99S15

REPLACE DEACTIVATION SWITCH

AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH

PERFORM 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

99S15 RECALL PERFORM RECALL 99S15 SPEED CONTROL SWITCH REPLACEMENT

PERFORM RECALL 99S15

1 INSTALLED NEW CRUISE SWITCH PER RECALL 99S15.

RECALL COMPLETE

PERFORM RECALL

1 PERFORM RECALL

INSTALL DEACTIVATION SWITCH PER RECALL

150224 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH

REPLACED DEACTIVATION SWTHC AND HARD SHELL

136017 SPEED CONTROL DEACTIVATION SWITCH RECAL 99S15 RENEW SPEED CONTROL DEACTIVATION SWITCH & CONN 23

INSTALL SPEED CONTROL DEACTIVATOR SWITCH PER RECALL WAITING

COMPLETED RECALL 99S15

RECALL 99S15 99S15 RECALL PERFORMED

1502-0225-A 3409

Box_Files

RECALL 99S15 PERFORM RECALL 99S15
 75990 REPLACE SPEED CONTROL DEA SWITCH AS PER RECALL 99-8-15
 119024 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL
 AS PER RECALL 99S15 RECALL TO REPLACE DEACTIVATION SWITCH
 AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL DEACTIVATION SWITCH

REPLACED CRUISE DEACTIVATION SWITCH AS PER RECAL
 PERFORM RECALL.....
 DID RECALL 99S15
 PERFORMED RECALL 1
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 RECALL 99S15 - B - RECALL

RECALL COMPLETED
 COMPLETED RECALL
 99S15 99S15
 SWITCHES ARE SHORTED REPLACE THE SWITCH
 99S15 RECALL 99S15 RECALL COMPLETE
 PERFORMED RECALL 99S15B REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 90606 99S15 RECALL WF INSTALL SPEED CONTROL SWITCH
 RPELACED SWITCH PER RECALL 99S15

99S15 RECALL
 RECALL COMPLETE

1 PERFORMED 99S15 RECALL
 1 PERFORMED RECALL 1
 99S15 RECALL PERFORM RECALL 99S15 SPEED CONTROL SWITCH REPLACEMENT
 77022 TIME TO REPLACE SPEED CONTROL SWITH AND CONNECT OR PER RECALL 99S15
 99S15 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 RECALL 99S15 REMOVED AND REPLACED THE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15. TEST DROVE VEHICLE AND THE
 78080 99S15 .5 REPLACE SWITCH AND CINNECOTR PER RECALL
 RECALL REPLACE SWITCH& HARD SHELL CONNECTOR& BLEED BRAKES
 RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 RECALL LETTER PERFORM RECALL AS PER FACTORY INSTRUCTION
 PERFORM RECALL
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH KIT
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15
 RECALL COMPLETE
 RECALL COMPLETED
 INSTALL NEW DEACTIVATION SWITCH AND HARNESS PER RECALL.

RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

Box_Files

1 REPLACED CRUISE SWITCH AND CONNECTOR.
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
INSTALL SWITCH KIT PER RECALL

0 98S15
RECALL 98S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH
CONNECTOR 98S15
SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 98S15
1 PERFORMED RECALL
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
PERFORMED RECALL 98S15

- PERFORMED RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH
145828 RECALL WPG40 RECALL COMPLETED, REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR
RECALL 98S15 COMPLETED
TECH INSTALLED CRUISE DEACTIVATION SWITCH PER FORD RECALL
REPLACE CRUISE CONTROL SWITCH
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. CHECK NORMAL OPERATION.
COMPLETE RECALL 98S15
RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL
REPLACED DEACTIVATION SWITCH AS PER 98S15

DID RECALL
PERFORMED RECALL
REPLACE SWITCH PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL LABOR 98S15B 0.5, ADMIN 0.1
REPL CRUISE CONTROL SWITCH 98S15
1 INSTALL DEACTIVATION SWITCH
PERFORMED RECALL 98S15

43840 98S15B .5 .5 RECALL
98S15 REPLACED SWITCH.
RECALL COMPLETE
20: PERFORMED 98S15 RECALL, REPLACE SPEED CONTROL SWITCH
RECALL 98S15B RECALL 98S15B
PERFORM RECALL 98S15
VERIFY FUEL ODOR,CK FOR LEAKS RI UPPER PLENUM,EGR VALVE,RI FUEL RAIL,INJ ASSY,RR INJECTOR O RING SEALS,PLENUM AND EGR GSKTS.CHECK FOR LEAKS,NONE

52785 RECALL 98S15 BASIC 98S152 INSTALLED SWITCH AS PER RECALL 98S15
126728 RECALL #98S15 0.5 INSTALL SPEED CONTROL DEACTIVATION SWITCH
98S15
1 REPLACE HARD SHELL CONNECTOR FOR CRUISE
70470 RECALL 98S15 DEACTON SWITCH INSTALL SWITCH AND CONNECTOR PER RECALL TECH 4132
98S15 REPLACE SWITCH AND CONNECTOR PER RECALL
PERFORM SPEED CONTROL DEACT SW RECALL
98S15B CHECK-REPLACE SPEED CONTROL DEACTIVATION SWITCH-CONNECTOR RECALL 98S09 COMPLETED

REPLACE SWITCH PER RECALL
REPAIRED PER RECALL
PERFORM RECALL

Box Files

REPLACE SWITCH
70785 W REPLACE SWITCH AND CONNECTOR PER RECALL GA
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL 99S15
PERFORMED RECALL
RECALL 99S15
REPLACE DEACTIVATION SWITCH PER 99S15
94428 RECALL 99S15 PERFORMED RECALL 99S15
PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
INTERM REPAIR REMOVED TAPE SECURE THE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15E 0.8 HRS PERMANENT REPAIR REPLACED SP EED CON
71394 RECALL WTY INSTALL SWITCH AND WIRE END PEWR RECALL

88027 PERFORMED RECALL 99S15 INSTALLED SWITCH
R&R DEACTIVATION SWITCH

134112 INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

COMPLETE RECALL 99S15
1 INSTALL SWITCH 1 99S15B 0.8
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN TIME
PERF. RECALL
PER THE OASIS PERFORM RECALL #99S15.
RECALL 99S15

REPLACE SWITCH AND CONNECTOR PER RECALL
RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
PERFORM RECALL 99S15
139285 99S15B 0.5 ADMIN 0.1
90188 99S15 .5 REPLACE SWITCH PER RECALL (((ADVISE CUST MASTER CYLINDER IS LEAKING))))))) NEEDS BOOSTER AND MASTER))))))
REPLACED DEACTIVATION SWITCH
REPLACED SWITCH AND CONNECTOR PER RECALL 99S15.
RECALL RECALL
RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

99S15 RECALL 99S15 REPAIR AS PER RECALL
99S15 RECALL PERFORMED
1 PERFORMED RECALL 99S15
RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15 99S15 INSTALLED SPEED CONTROL SWITCH
PERFORM RECALL REPALCE SWITCH AND HARD SHELL CONNECTOR
99S15 RECALL

Box_Files

CAMPAIGN COMPLETED

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

OPEN RECALL PERFORMED RECAL

PERFORMED CRUISE CONTROL CABLE 99S15

FACTORY RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE SWITCH PER RECALL

REPLACE SPEED CTRL DEACTIVATION SWITCH AND HARD SHELL PER RECALL

RECALL 99S15

114209 INSTALLED SWITCH PER RECALL

INSTALLED CONNECTOR AND DEACTIVATION SWITCH

RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND PLUG

83739 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARNESS.

PERFORMED RECALL 99S16. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

REPLACED DEACTIVATION SWITCH

38899 INSTALL CRUISE CONTROL DEACTIVATION SWITCH RECALL 99S15

99S15 REPLACED SWITCH PER RECALL

REPLACED CRUISE CONTROL SWITCH

REPLACED SPEED CONTROL SWITCH PER RECALL

REPLACED DEACTIVATION SWITCH PER RECALL

COMPLETED RECALL

INSPECT SPEED CONTROL SYSTEM AND COMPLETE LABOR OPERATION ACCORDINGLY COMPLETED SPEED CONTROL DEACTIVATION CAMPAIGN

REPLACED CRUISE SWITCH AND CONNECTOR

AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL SWITCH

OPEN RECALL COMPLETED RECAL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

99S15 REPLACE DEACTIVATION SWITCH 99S15

1 PERFORMED RECALL

PERFORM RECALL

RECALL 99S15 RECALL

RECALL COMPLETED

104321 99S15 WARRANTY INSTALLED SPEED CONTROL DEACTIVATION SWITCH

164105 99S15B .SHLL PERFORM RECALL

99S15 OPEN PERFORM RECALL

199981 PERFORMED DEACT SW RECALL

REPLACE CRUISE SWT. AND CONNECTOR

PERFORM RECALL 99S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PER NOTIFICATION RECALL 99S16 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS

PER RECALL PERF RECALL

RECALL 99S15 COMPLETED

RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION SWITCH AS

RECALL RECALL

123988 99S15 WARR REPLACED SWITCH AND CONN

Box_Files

RECALL 99S15 PERFORMED RECALL 99S15
72845 INSTALLED SPEED CONTROL DEACTIVATION SWIT
99S15B 0.5, TOTAL HRS 0.5, PERFORMED RECALL 99S15, REPLACED DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY.

REPLACE SPEED CONTROL SWITCH AND HARD SHELL CONNECTOR

REPLACED SWITCH AND CONNECTOR
REPLACED SPEED CONTROL SWTY
99S15 PERFORMED RECAL
PERFORM RECALL INSTALL SWITCH
1 RECALL COMPLETE
COMPLETE RECALL 99S15
PERFORMED RECALL
RECALL 99S15

PERFORMED RECALL
RECALL 99S15 REQUIRED. INS AND REPL BRAKE DEACTIVATOR SWITCH PER RECALL 99S15.

PERFORMED RECALL
RECALL 99S15 SPEED CONT RECALL
99S15 REPLACE SWITCH AND CONNECTOR
99S15 REPLACED SPEED CONTROL CABLE AS PER RECALL
PERFORM RECALL 99S15
REPL CRUISE DEACTIVATION SWITCH
78375 RECALL W INSTALL KIT QA
83075 R R DEACTIVATOR SWITCH PER RECALL
RECALL 99S15 PERFORM RECALL 99S15
81738 R/R CRUISE SWITCH RECALL 99S15
18861 PERFORM RECALL 99S15
PERFORMED RECALL 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACE BRAKE SWITCH PER RECALL
RECALL 99S15 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITC
42351 INSTALL REVISED S.C. DEACTIVATION SWITCH.
PERFORMED RECALL
1 REPLACED SWITCH AND CONN
REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL ALSO SEE RECALL RELATED DAMAGE IN REPAIR 0
RPLC SPEED CTRL DEACTIVATION SWITCH PER 99S15
REPLACED DEACTIVATION SWITCH
PERFORMED RECALL 99S15
RECALL PERFORMED RECALL 99S15
RECALL 99S15
119998 RECALL 99S15 WARRANTY REPLACE SPEED CONTROL SENSOR AND CONECTOR DO TO RECALL 99S15 3720
X INSTALLED SWITCH

Box_Files

INSTALL KIT PER RECALL

X 99S15 RECALL PERFORMED
RECALL 99S15

1 PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B .5

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

58147 REPLACE SPEED CONTROL DEACTIVATION SWITCH WHILE REPLACING SWITCH THREADS STRIPPED IN PROPORTIONING BLOCK ORDER PROPORTIONING BLOCK

REPLACE DEACTIVATION SWITCH

RECALL PERFORM RECALL

1 REPLACED SPEED CONTROL SWITCH 1

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

99S15 RECALL 99S15 RECALL

22290 REPLACED SPEED CONTROL DEACTIVATION SWITCH RECALL 99S15

REPL BK SW AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

99S15 99S15

99S15 REPLACED SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 99S15

RECALL REPLACE CRUISE CONTROL CABLE DEACT SWITCH REPLACE CONNECTOR

PERFORM RECALL 99S15

91928 RECALL REPLACE SWITCH AND WIRE CONNECTOR.

REPLACE DEACTIVATION SWITCH

109- SPD CONTROL SWITCH RECALL - 99S15 -REPLACED SWITCH PER RECALL

99S15 RECALL

PERFORMED RECALL 99S15

45124 RECALL PERFORM RECALL #99S15 PER BULLETIN

REPLACE SPEED DEACTIVATION SWITCH RECALL COMPLE

92510 99S15

REPLACE SWITCH PER RECALL

1 PERFORM RECALL 99S15

RECALL CRUISE CONTROL RECALL 99S15

RECALL 99S15 COMPLETED RECALL 99S15

PERFORM RECALL

183988 RECALL WAS PERFORMED RECALL 99S15

RECALL 99S15 PERFORM RECALL 99S15

COMPLETE RECALL 99S15

PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

INSTALLED KIT TO COMPLETE

PERFORM RECALL 99S15 99S15

99S15 RECALL

PERFORM RECALL 99S15

RECALL 99S15 RECALL: REPLACED DEACTIVATION SWITCH

113299 RECALL PERFORM RECALL 99S15-SPD.CONTORL SWITCH REPLACEMENT-INSTALL NEW SWITCH A86.

EMC2-025-A 3888

Box_Files

INSTALLED SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15 RECALL 99S15 COMPLETED
 99S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 99S15 99S15 RECALL
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 BOX B
 43576 RECALL 99S15 REPLACE SWITCH PER RECALL 99S15
 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH.
 1 RECALL COMPLETE
 1 08 REPLACED SWITCH

PERFORM RECALL 99S15
 VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK

RECALL 99S15 PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
 PERFORMED SPEED CONTROL RECALL 99S15
 R/R BRAKE SWITCH PER RECALL
 1 INSTALL SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR
 PER FORD MOTOR CO. 99S15 REPLACE DEACTIVATION SWITCH AND CONNECTOR
 132848 W PERFORM RECALL 99S15 REPLACE DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 99S15 99S15
 29244 INSTALLED 99S15 SPEED CONTROL SWITCH
 RECALL PERFORM RECALL 99S15, REPLACE SPEED CONTROL SWITCH
 PERFORMED RECALL
 PERFORMED RECALL
 REPLACED SWITCH AND CONNECTOR
 COMPLETED RECALL
 SUPPLEMENT #1 5-09 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 REPLACED SWITCH

99S15 RECALL PERFORM RECALL
 RECALL 99S15 REPLACE C-C SW
 REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL INST

14728 RECALL 99S15 COMPLETED
 REPLACE CONNECTOR AS PER 99S15 RECALL
 REPLACE BRAKE ON-OFF SWITCH, AND BLEED BRAKES
 99S15 COMPLETE F
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 RECALL 99S15 INSTALL SWITCH PER RECALL

1 COMPLETED RECALL

99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 99S15 RECALL 99S15 RECALL PERFORMED
 REPLACE DEACTIVATION SWITCH PER RECALL
 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

98S15 REPLACED SWITCH AND CONNECTOR

98S15B REPLACED CRUISE CONTROL DEACTIVATION
 PERFORMED RECALL 98S15
 RECALL REPLACE CRUISE SWITCH
 RECALL 98S15
 PERFORM RECALL 98S15

REPAIR AS PER RECALL

1 PERFORM RECALL-REPLACE SWITCH AND CONNECTOR
 REPLACED THE SWITCH PER RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15
 TECH INSTALLED NEW CRUISE DEACTIVATION SWITCH PER FORD RECALL
 49888 PERFORMED RECALL AS PER INSTRUCTIONS

RECALL 98S15 PERFORM RECALL
 RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 REPLACE BRAKE PRESSURE SWITCH AND CONNECTOR
 UNKNOWN INSTALL CRUISE CONTROL SWITCH AND CONNECTOR PER 98S15
 106- SPEED CONTROL SWITCH RECALL-98S15 - INSTALL DEACTIVATION SWITCH PER RECALL
 145760 RECALL 98S15B 0.5 0.5 REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15
 REPLACE SWITCH AND CONNECTOR
 REPLACED SWITCH PER RECALL
 INSPECT AND OR PERFORM RECALL INSPECTED AND OR PERFORMED RECALL AS PER RECALL INSTRUCTIONS.
 SPD CTRL DEACTIVATION SW REPLCMTPERFORMED RECALL 98S15
 RECALL REPLACED DEACTIVATION SWITCH PER RECALL
 REPLACE SWITCH PER 98S15.
 98S15 RECALL 98S15 RECALL COMPLETE
 38838 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH
 88349 INSTALLED 98S15 SPEED CONTROL SWITCH
 REPL CRUISE SWITCH 98S15
 RECALL SPEED CONTROL REPLACE DEACTIVATION SWITCH

8878 98S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH PER 98S15 RECALL JH

1 PERFORM RECALL

PERFORM RECALL 98S15

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

RECALL 98S15B 98S15B REPLACE SWITCH AND HARD SHELL CONNECTOR PLUG

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

98S15 REPLACED OLD SWITCH WITH NEW SWITCH

1 PERFORMED RECALL 98S15

REPLACED SWITCH PER RECALL

COMPLETE 98S15 RECALL

38838 RECALL REPLACE CRUISE CONTROL SWITCH AND CONNECTOR

REPLACE DEACTIVATION SWITCH

PERFORMED 98S15 RECALL REPLACED SWITCH AS PER R ECALL

RECALL RENEW SPEED CONTROL DE-ACTIVATION SWITC

Box_Files

COMPLETED RECALL 98S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15
 RECALL 98S15 PERF. RECALL
 REPLACED PARTS PER RECALL
 SPEED CONTRL DEACTIVATION SWITCHPERFORMED RECALL 98S15

REPLACE CRUISE DEACTIVATION CONNECTOR AND SWITCH PER RECALL 98S15

COMPLETED RECALL

OPEN RECALL PERFORM RECALL

REPLACED SWITCH & CONNECTOR PER RECALL

RECALL 98S15 RECALL

98S15 RECALL PERFORMED 98S15 RECALL, INSTALLED PART 9G852, REPLACED SPEED CONTROL DEACT SWITCH AND PERFORMED WIRING CONNECTOR REPAIR

RPL CRUISE SWITCH PER RECALL 98S15

73200 REPLACE SPEED CONTROL SWITCH AND CONNECTOR PER RECALL 98S15.

102874 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL #98S15.

RECALL 98S15

RECALL 98S15

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15

COMPLETED RECALL

PERFORM 98S15 INSTALL KIT FOR CRUISE

REPLACE DEACTIVATION SWITCH & CONNECTOR

TECH COMPLETED RECALL AS REQUIRED

PERFORMED RECALL 98S15

RECALL 98S15 INSTALL KIT PER 98S15

37201 REPLACED SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL REPLACE SWITCH

PERFORMED RECALL SPEED CONTROL SWITCH

PERFORMED RECALL 98S15

98S15 98S15 INSTALL K

PERFORM RECALL 98S15 REPLACE CRUISE CONTROL SENS

INSTALLED SWITCH PER RECALL

48565 RECALL 98S15 REPAIR AS PER RECALL

PERFORMED 98S15

1 PERFORMED RECALL

98S15 PERFORM RECALL 98S15

83712 W REPLACE SWITCH AND CONNECTOR GA

PERFORM RECALL 98S15 PER TECHNICAL INSTRUCTIONS

INSTALL NEW CRUISE SHUT OFF SWITCH & CONNECTOR 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

RECALL REPLACED CRUISE DEACTIVATION SWITCH PER RECALL

NA 98S15 REPLACED SWITCH

Box_Files

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEACTIVATION SW. RECALL 99S15

RECALLED BY FORD PERFORMED RECALL 99S15
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 00 99S15B
 OPEN RECALL 99S15 RECALL

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
 83312 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR BODY. RECALL 99S15.
 REPLACE SWITCH
 REPLACED DEACTIVATION SWITCH
 REPLACED BRAKE SWITCH.
 RECALL 99S15
 SHORT MAY DIASABLE SPEED CONTROL OR CAUSE BRAKE LIGHT FUSE TO OPEN DISCONNECT CONNECTOR FROM CRUISE DEACTIVATION SWITCH & PROTECT END FROM COI
 PERFORM RECALL 99S15

PERFORMED RECALL 99S15
 X 99S15 - REPLACED CRUISE CONTROL SOLENOID PER RECALL
 RECALL COMPLETED
 PERFORMED RECALL
 RECALL 99S15 REPLACE C-C SW
 PERFORMED RECALL
 PERFORMED RECALL 99S15 -- CHECK AND REPLACE DEACTIVATION SWITCH AND RECHECK OK
 1 COMPLETED RECALL
 1 PERFORM DEACTIVATION SWITCH RECALL
 REPLACED THE DEACTIVATION SWITCH AS PER RECALL 99S15 SPECS.
 REPLACED SPEED CONTROL SWITCH AS PER RECALL
 1 PERFORMED RECALL 99S15
 COMPLETED RECALL
 99S15 99S15 PERFORM RECALL
 RECALL 99S15
 RECALL 99S15
 REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15

1 PERFORM RECALL-REPLACE SWITCH AND CONNECTOR
 99S15 RECALL 99S15 RECALL
 85787 RECALL W REPLACE SWITCH AND PLUG GA DDDME = DEALER SELF APPROVAL
 99S15 RECALL PERFORMED 99S15 RECALL, R AND REPLACED DEACT. SWITCH, INSTALL BRAKE REPAIR KIT 99S52, BLEED BRAKE SYS. VERIFY.

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

83813 99S15 W 99S15
 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL
 RECALL RECALL

REPLACE SWITCH AND PLUG

REPL SW AND CONNECTOR PER RECALL

Box Files

RECALL 98S15 REPLACED HEADLIGHT SWITCH AND CONNECTOR
DEACTIVATED SWITCH
PER RECALL 98S15
PERFORMED RECALL
PERFORMED RECALL
INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL
PERFORM RECALL 98S15 T118
RECALL 98S15 PERF. RECALL
RECALL COMPLETE

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15
RECALL 98S15 DONE
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
M1 TIME TO TEST SPEED CONTROL, UNLISTED IN SLTS. REPLACED CRUISE CONTROL SWITCH, INOP.
COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH
1 PERFORMED RECALL 98S15
REPLACED CRUISE CONTROL CUTOFF SWITCH PER THE RECALL
PERFORM RECALL 98S15
PERFORMED 98S15
98S15 RECALL
01570 R R SPEED SWITCH AND CONNECTOR BLEED REAR BRAKES AND TEST DROVE
RECALL 98S15, PERFORMED RECALL 98S15.
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
RECALL REPLACE SPEED CONTROL SWITCH.
RECALL 98S15 98S15 RPL SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CON.
98S15 REPLACED DEACTIVATION SWITCH
98S15 RECALL 98S15 RECALL PERFORMED
COMPLETE RECALL 98S15
98S15 98S15 REPLACED DEACTIVATION SWITCH
131803 REPLACED DEACTIVATION SW. & CONN PER 98S15 98S15B
130730 RECALL 98S15 RECALL
102888 RECALL 98S15 REPLACE DEACTIVATION SWITCH AND CONNECTOR FOR RECALL 98S15

REPLACED CRUISE CONTROL SWITCH PER RECALL 98S15
REPLACE SWITCH
COMPLETE RECALL 98S15
1 REPLACE SWITCH& CONNECTOR
REPLACE CRUISE CONTROL CABLE
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
95224 98S15 .5 REPLACE SWITCH AND CONECTOR PRT RECALL
106612 REPLACE DEACTIVATION SWITCH AND CONNECTOR
COMPLETED RECALL
REPLACE SWITCH AND CONNECTOR PER RECALL
PERFORMED RECALL AS NEEDED ALL OK
PER RECALL REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER FORD RECALL NOTE
REPLACE CRUISE DEACTIVATION CONNECTOR AND SWITCH PER RECALL 98S15
RECALL R-R DEAC SW. AND CONNECTOR, RECD OK
98S15 98S15 PERFORM RECALL

2002-02-09 09:25:18

Box Files

PERFORMED RECALL 99S15
 RECALL W TECH 405 M 109397 PERFORM RECALL
 80870 PERFORM RECALL 99S15
 RECALL 99S15 99S15 COMPLETED RECALL
 211410 RECALL 99S15B, 14200A 0.8L PERFORMED RECALL ALOS HAD TO REPAIR THE WIRING TO CONNECTOR. OLD CONNECTOR MISSING HAD TO SPLICE NEW CONNECTOR IN.
 161302 99S15 RECALL W PERFORMED 99S15 RECALL. INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH.
 RECALL PERFORM RECALL
 REPLACED CRUISE SWITCH AS PER RECALL 99S15
 RECALL 99S15 99S15 COMPLETED RECALL
 99S15 RECALL 99S15 RECALL, RE-WIRE DEACTIVATION SWITCH
 74554 PERFORM RECALL 99S15, REPLACE SPEED CONTROL SWITCH AND BLEED BRAKES.

RECALL 99S15 99S15 RECALL PERFORMED
 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15
 99S15 99S15
 INSTALLED CRUISE DEACTIVATION SWITCH PER RECALL

163439 .3 REPLACE CRUISE SWITCH
 RECALL 99S15 PERFORMED RECALL 99S15B
 COMPLETE RECALL
 118118 DID RECALL 99S15 SPEED CONTROL NOTE ABS. LIGHT ON, ROTORS HAS VIBS, DENT LEFT UPPER FENDER.
 135082 REPLACE SWITCH AND CONNECTOR AS PER RECALL
 SPEED CONTROL SWITCH 99S15 RECALL
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS DIRECTED BY 99S15 SAFETY RECALL.
 RECALL 99S15
 PERFORMED RECALL 99S15-INSTALL SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.
 INSTALLED DEACTIVATION SWITCH PER RECALL 99S15
 R-R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED DEACTIVATOR SWITCH
 PERFORMED RECALL
 99S15 RECALL
 78421 RECALL 99S15 REPLACE DEACTIVATOR SWITCH AS PER RECALL
 RECALL 99S15 REPLACE C-C SW
 PERFORMED RECALL 99S15
 12252 PERFORM RECALL, REPLACE SWITCH 99S15B .5
 REPLACE CONNECTOR PER RECALL 99S15.
 99S15 99S15 RECALL, REPLACE SWITCH
 REPLACED DEACTIVATION SWITCH
 REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 99S15 RECALL 99S15 REPAIR AS PER RECALL
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH KIT PER RECALL
 PERFORMED RECALL 99S15
 PERFORMED RECALL 99S15
 REPLACED CRUISE CONTROL SWITCH 99S15
 PERFORM RECALL 99S15 99S15
 24804 PERFORM DEACTIVATION SWITCH AND CONNECTOR SHELL REPLACEMENT RECALL

Box_Files

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
PERFORMED RECALL AS PER INSTRUCTIONS
PERFORMED MODIFICATION
99S15 REPLACE DEACTIVATE SWITCH
99719 PERFORMED RECALL 99S15 TEST DROVE OK.

PERFORM RECALL
RECALL 99S15 RECALL 99S15

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15

RECALL COMPLETED 99S15 RECALL
REPLACED SWITCH PER RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL 99S15 RECALL
73888 REMOVED AND INSTALLED NEW BRAKE DEACTIVATION SWITCH AND WIRE CONNECTOR SLEEVE PER RECAL 99S15 AND THEN ROAD TESTED, SPEED CONTROL IS WORKING
RECALL RECALL
RECALL 99S15
REPLACE CRUISE CONTROL SWITCH ASY
CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION SWITCH AS
INSTALL KIT PER RECALL
SERVICE INSTALLED SPEED CONTROL SWITCH PER RECA
99475 99S15 0.5 HRS. SPEED CONTROL SWITCH RECA
99S15
RECALL 99S15 RECALL 99S15
RECALL 99S15 COMPLETE RECALL 99S15

99824 RECALL 99S15 INSTALL NEW SWITCH AND SHELL CONNECTOR
INSTALL SPEED CONTROL SWITCH PER RECALL 99S15
1 PERFORMED RECALL 99S15 SPEED CONTROL CABLE REPLACE SWITCH AND CONNECTOR.
REPLACED DEACTIVATION SW PER RECALL.
PERFORM RECALL
OPEN RECALL PERFORM 99S15 RECALL
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
COMPL: RECALL 99S15, CAUSE: SPEED CONTROL DEACTIVATION SWITCH,
PERFORMED RECALL
INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL
RECALL 99 S 15

CORRE: PERFORM RECALL

A

99S15 RECALL PERFORMED 99S15
99S15E RECALL 99S15E PERFORME
RECALL 99S15 99S15 RECALL PERFORM MODIFICATIONS
PERFORM RECALL
121140 INSTALL 99S15 SPEED CONTROL DEACTIVATION

INSPECT AND REPLACE SWITCH AND CONNECTOR PER RECALL
PERFORMED RECALL 99S15 AS REQUESTED.

Box_Files

14787 RECALL 98S15 RECALL 98S15
RECALL 98S15 COMPLETED
REPLACED SWITCH FOR CRUISE CONTROL AND HARDSHELL CONNECTOR AS INSTRUCTED BY PROGRAM 98S15
98S15 98S15
21478 REPLACED SWITCH PER RECALL TECH 608
97308 98S15 B 0.5 REPL. CRUISE DEAC SW
RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
RECALL SPEED CONT SWITCH PERFORM RECALL 98S15
REPLACED THE CRUISE DEACTIVATION SWITCH
INSTALL DEACTIVATION SWITCH 98S15 RECALL PER FORD INSTRUCTIONS
1 COMPLETED RECALL
1 COMPLETED
PERFORM RECALL
33447 RECALL W INSTALL SWITCH AND CONNECTOR 98S15 GA
98S15 98S15 RECALL PERFORMED
40848 RECALL DID RECALL REPLACED SWITCH AND WIRES TECH 10
9 PERFORM RECALL 98S15
66802 RECALL 98S15 PERFORMED RECALL 98S15 REPLACED CRUISE DEACTIVATION SWITCH

INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RE
PERFORMED RECALL
PERFORMED RECALL
REPLACED SWITCH PER BULLETIN

RECALL 98S15
- MODIFY PER RECALL 98S15
PERFORM RECALL !

COMPLETED RECALL 98S15

RECALL CRUISE CONTROL RECALL 98S15
REPL SPD CNTRL DEACTIVATION SW
A98 98S2 82 737 98S15B .5 ADMIN .1 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
1 1 PERFORM DEACTIVATION SWITCH RECALL
RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS
98S15 RECALL PERFORMED 98S15
WE PERFORMED RECALL 4237
98S15 98S15 REMOVE TAPE SECURE THE SPEED CONTROL SWITCH.
REPAIR AS PER RECALL
DID RECALL ON SWITCH BLEED BRAKES CHECKED OK..
COMPLETED RECALL
98S15 98S15
RPLC CRUISE DEACTIVATION SWITCH & PLUG PER 98S15, BLEED BRAKES
CONTROL DEACTIVATION SWITCH RECALL
PERFORMED RECALL AS PER 98S15
PERFORM RECALL
PERFORMED RECALL 98S15-INSTALL SWITCH
COMPLETE PERFORMED RECALL, R&R DEACTIVATION SWITCH

Box_Files

PERFORMED RECALL

99S15 REPLACED SWITCH AND CONNECTOR

COMPLETE RECALL 99S15

99S15 99S15

REPLACE CONN AND SWITCH PER RECALL INSTRUCTIONS

1 PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW

72875 REPLACE SWITCH AS PER 99S15 RECALL

REPLACE SPEED CONTROL SWITCH AND CONNECTOR

RECALL 99S15

1 TECH REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15

135435 RECALL DONE RECALL TECH 538

99S15 99S15

52028 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH

REPLACED CRUISE DEACTIVATION SWITCH

REPLACE CRUISE DEACTIVATION SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH

99S15 99S15

43883 RECALL W 0.5 HRS 0.1 ADMS INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 OPER 99S15-B

99S15 99S15

INSTALL SPEED CONTROL DEACTIVATION SWITCH

REPLACED DEACTIVATION SWITCH AS PER RECALL INSTRUCTIONS

REPAIR AS PER RECALL

RECALL REPLACE SWITCH AND HARDSHELL CONNECTOR

RECALL 99S15 RECALL 99S15 REPLACE SWITCH

78445 RECALL WARRANTY INSTALL SPEED CONTROL DEACTIVATION SWITCH

RECALL COMPLETED

RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15

PERFORM RECALL

COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

PERFORMED RECALL

105418 REPLACED SWITCH

REPLACE SPEED CONTROL SWITCH

61668 W REPLACE SWITCH PER RECALL ME

REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 PERFORMED RECALL 99S15

1 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER 99S15

79577 SAFETY RECALL 99S15. REPLACE SWITCH AND CONNECTOR PER 99S15. ROAD TESTED OK AFTER REPAIRS.

RECALL COMPLETED

INSTALLED SWITC

PERFORMED RECALL

58068 TECH 158 RECALL 99S15 99S15B(0.5)

PERFORMED RECALL 99S15. 99S15B .5HRS LABOR FRONT BRAKES AT 2MM, RECOMMEND REPLACING BRAKES

RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

34528 INSPECTED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL.

Box_Files

139407 PERFORMED RECALL 98S15

PERFORM RECALL

98S15 98S15 REPLACE SWITCH AND CONNECTOR

COMPLETED RECALL PER INSTRUCTIONS

COMPLETED RECALL PER INSTRUCTIONS

74008 98S15 REPLACED SW AND CONNECTOR

REPLACE SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

98S15 98S15

INSTALLED CRUISE CONTROL CUTOFF SWITCH PERFORMED RECALL 98S15

PERFORM RECALL

RECALL

98S15 PERFORMED RECALL 98S15

RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.

REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL

RECALL

REPLACE DEACTIVATION SWITCH

REPL SPD CNTRL DEACTIVATION SW

83188 RECALL 98S15 WPC RECALL 98S15

RECALL 98S15

RECALL

RECALL PERFORM ALL DONE

RECALL 98S15 REPLACE BRAKE REPAIR KIT

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 98S15

PERFORM 98S15 RECALL AS INSTRUCTED

COMPLETED AS PER FMC

1 PERFORMED RECALL 98S15

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.

PERFORMED RECALL 98S15-INSTALL SWITCH

98S15

PERFORM RECALL

REPLACED SWITCH PER RECALL

REPLACED SPEED DEACTIVATION SWITCH PER RECALL 98S1

INSTALLED SWITCH PER RECALL

PER FORD RECALL NOTICE. FORD RECALL COMPLETE PER INSTRUCTIONS.

REPLACE SPEED CONTROL SWITCH #BXW#

RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

PERFORM 98S15 RECALL. REPLACED SPEED CONTROL CAB

98S15

98S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH

COMPLETED RECALL 98S15

RECALL

DONE

83732 RECALL 98S15B .50 TEC 162 INSTALL NEW SWITCH AND CONNECTION

PERFORMED RECALL AS PER INSTRUCTIONS

RECALL 98S15 - SPEED CONTROL DEACTIVATION SWITCH INSPECTED SPEED CONTROL DEACTIVATION SWITCH. REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNEC

PERFORM RECALL

8383-025-A 3815

Box_Files

PERFORM RECALL 99S15 PER TECHNICAL INSTRUCTIONS

PERFORM RECALL 99S15

48196 WARR DIAG REPLACE SPEED CONTROL DEACTIVATOR AS PER RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL BULLETIN.

RPLC DEACTIVATION SWITCH & HARDSHELL CONN PER 99S15

99S15 RECALL 99S15 RECALL

49909 99S15B 0.6 0.5 PERFORM 99S15

PERFORM RECALL TO REPLACE PRESSURE SWITCH AND CON NECTOR

RECALL COMPLETED

C PERFORM RECALL

PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN RECALL BULLETIN REMOVE, TAPE AND SECURE SPEED CONTROL DEACTIVATION SWITCH

RC RC

131622 REPLACED CRUISE CONTROL DEACTIVATION SWITCH FOR RECALL

RECALL 99S15 REPLACE SWITCH AND CONNECTOR

REPLACE DEACTIVATION SWITCH PER RECALL

99S15 REPLACE DEACTIVATION SWITCH AND CONNECTOR

67626 REC WARR 627 PERFORM RECALL 99S15

REPLACCE SPEED CONTROL SWITCH #826#

INSTALL NEW SWITCH AND CONNECTOR 99S15

RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

PERFORMED RECALL 99S15 CRUISE DE-ACTIVATION 205

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPL SPD CNTRL DEACTIVATION SW

REPLACE SWITCH AND CONNECTOR

PERFORMED RECALL

PERFORMED RECALL

99S15 COMPLETED

REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL

INSTALLED SPEED DEACTIVATION SWITCH

RECALLED BY FORD PERFORMED RECAL

PERF. RECALL

RECALL PERFORMED RECAL

129958 RECALL 99S15 REPLACE CRUISE CONTROL SWIT

1 REPLACED SWITCH

PER RECALL 99S15

COMPLETED RECALL

RECALL RECALL

1 PERFORM RECALL AS REQUIRED

PERFORMED RECALL 99S15B

PERFORMED RECALL 99S15 REPLACED CRUISE DEACTIVATOR SWITCH

OPEN RECALL COMPLETED

RECALL RECALL

REPLACE SWITCH AND HARD SHELL

PERFORM RECALL 99S15 PERFORM DEEACTIVATION SWITCH RECALL

R&R CRUISE DEACTIVATION SWITCH & HARD SHELL PER RECALL

Box_Files

RECALL 99S15
 RECALL PERFORMED
 REPLACED DEACTIVATION SWITCH
 RECALL 99S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 PERFORMED RECALL
 PERFORM RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL
 RECALL 99S15 PERFORM RECALL 99S15
 REPLACED CRUISE DEACT SWITCH
 99S15 REPL CABLE

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 OPEN RECALL PERFORM RECALL
 REPLACE CONNECTOR AND SWITCH

RECALL COMPLETE
 PERFORM RECALL
 99S15 RECALL 99S15 RECALL - CRUISE RECALL
 RECALL 99S15
 REPL SPD CNTRL DEACTIVATION SW
 COMPLETE RECALL
 PERFORM RECALL
 PERFORM RECALL
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 RECALL PERFORMED RECALL
 REPLACE SWITCH
 RECALL COMPLETE
 PERFORM RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTIONS
 REPLACED CRUISE SWITCH
 PERFORMED RECALL
 REPLACED CRUISE BRAKE SWITCH
 REPLACED THE SWITCH PER RECALL 99S15

RECALL 99S15 RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 PERFORM 99S15 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
 RECALL 99S15 PERFORMED RECALL 99S15
 INSTALLED KIT 99S15 RECALL PERFORMED
 90282 INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL
 99S15 99S15
 RECALL 99S15
 91011 99S15 WARR REPLACED SWITCH AND CONN

REPLACE SWITCH
 RECALL 99S15 REPLACE SWITCH AND CONNECTOR
 92529 RECALL 99S15B .50 TECK 162 INSTALL NEW SWITCH AND CONNECTION PER RECALL

Box_Files

COMPLETED 99S15
 PERFORM RECALL 99S15
 PERFORMED RECALL
 RECALL REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR.
 RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.
 99S15 PERFORM RECALL
 INSTALL SPEED CONTROL SWITCH PER RECALL.
 RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH
 OPEN RECALL PERFORM RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL PERFORM RECALL
 RECALL 99S15
 PERFORM RECALL

99S15 REPLACED DEACTIVATOR SWITCH PER RECALL
 PERFORM RECALL 99S15
 1 COMPLETED RECALL
 RECALL 99S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
 PERFORMED RECALL 99S15-REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 82303 RECALL 99S15 COMPLETED
 45285 CRUISE BRAKE PRESSURE SW PIN POINT CONCERN FOUND FUSE BLOWN,INSTALL CIRCUIT BREAKER TESTER AND PIN POINT TEST,FOUND INTERMITTIN CONCERN,CUI
 PERFORMED RECALL
 PERFORM RECALL
 REMOVED AND REPLACED PRESSURE SWITCH PERFORMED RECALL 99S15

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL 99S15 99S15 COMPLETED RECALL
 66350 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL
 76423 PERFORMED RECALL 99S15
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 99S15 PERFORM RECALL
 1 PERFORM RECALL
 PERFORMED RECALL 99S15
 RECALL 99S15
 RECALL 99S15 REPLACE C-C SW
 127207 99S15B 0.5HR ADMIN 0.1HR PERFORMED RECALL REPLACED SWITCH AND CONN.
 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL
 113324 RECALL 99S15 REMOVED OLD SPEED CONTROL DEACTIVATION SWITCH INSTALED NEW DEACTIVATION SWITCH & HARD SHELL CONECTOR.
 RECALL COMPLETED.
 3 PROGRAM SPN XREF RO 80011 DTD 10-7-99 ACC MILAGE (267) L03 33 (9G852) INSPECT, FOUND LOOSE BRAKE SWITCH, REPLACE SWITCH, CLEAN OIL FROM CAR, RECHECK FC
 C INSTALL SWITCH AS PER RECALL
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 RECALL 99S15 REPLACE C-C SW
 99S15 RECALL
 REPAIR AS PER RECALL 99S15
 PERFORM 99S15 RECALL
 RECALL 99S15

Box_Files

PERFORMED RECALL 99S15
 105705 RECALL W/ REPLACE DEACTIVATION SWITCH AND CONNECTOR PER 99S15B 0.5 + 0.1
 9924 CRUISE CONTROL DEACTIVATION SWITCH RECALL
 9938 CRUISE CONTROL RECALL
 REPLACE BRAKE SWITCH PER RECALL
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 1 REPLACE DEACTIVATION SW. WARRANTY-RECALL-BILL
 RECALL 99S15 REPLACE C-C SW
 CONNECTOR 99S15
 RECALL 99S15 INSTALL BRAKE SWITCH
 RECALL 99S15B
 RECALL 99 S 15
 99S15
 REPLACE CRUISE CONTROL SWITCH PER RECALL
 99S15 RECALL REPLACED SWITCH
 PERFORMED RECALL
 1 PERFORMED RECALL
 RECALL 99S15

154894 REPLACED CRUISE CONTROL DEACTIVATION SWITCH & HARDSELL CONNECTOR FOR RECALL
 REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15
 PERFORM RECALL
 AS PER RECALL REPLACE SPEED CONTROL SW AND CONNECTOR PER RECALL
 99S15 99S15 RECALL COMPLETED
 PERFORMED RECALL
 39411 99S15 .5 REPLACE SWITCH AND CONNECTOR PER RECALL
 73227 99S15 W RENEW BRAKE VLV. SW. & HARDSELL. CONN. AS PER RECALL
 99221. RECALL 99S15B INSTALLED CRUISE DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL LABOR 99S15B 0.5, ADMIN 0.1
 99S15 99S15
 RPL CRUISE SWITCH PER RECALL 99S15

REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL
 99S15 REPLACE SWITCH
 OPEN RECALL 99S15 RECALL
 COMPLETE RECALL 99S15
 REPL CRUISE CONTROL SWITCH AS PER RECALL
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 37194 INSTALLED BRAKE KIT PER RECALL
 COMPLETED RECALL 99S15-INSTALLED DEACTIVATION SWITCH
 INSTALL SWITCH AND CONNECTOR PER RECALL 99S15
 99S15 RECALL 99S15 RECALL COMPLETE
 INSTALLED SWITCH
 63451 RECALL 99S15 INSTALL UPDATED SPEED CONTROL DE-ACTIVATION SWITCH AND CONNECTOR
 PERFORMED RECALL 99S15, .5HRS LABOR
 REMOVED AND REPLACED BRAKE SWITCH, BLEED SYSTEM, RT OK
 REPLACE SWITCH PER RECALL
 INSTALLED SWITCH
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

1 PERFORM RECALL 99S15 BRAKE SWITCH

X INSTALLED NEW DEACTIVATION SWITCH PER RECALL
 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL
 99S15 RECALL 99S15 REPAIRED AS PER RECALL
 00807 RECALL 0.6 99S15B INSTALLED RECALL
 RECALL 99S15 RECALL COMPLETED
 RECALL 99S15B PERFORM RECALL 99S15B
 99S15 RECALL 99S15 INSTALLED CRUISE CONTROL SWITCH PER RECALL 99S15
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .6
 99S15 99S15
 RECALL 99S15 RECALL PERFORME
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL PERFORMED RECALL
 REPLACED SWITCH
 INSPECTED SWITCH NECESSARY TO REPLACE SWITCH AS PER RECALL

COMPLETED CAMPAIGN COMPLETED OF 99S15B
 99S15 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL 99S15
 PERFORMED 99S15
 99S15 PERFORMED 99S15
 RECALL 99S15 RECALL COMPLETED
 99S15B RECALL 99S15B RECALL REPLACED CRUISE DEACTIVATION SWITCH
 RECALL 99S15 RECALL PERFORME
 REPLACED SW

RECALL IS REQUIRED COMPLETE RECALL
 PERFORMED RECALL
 RECALL 99S15 COMPLETED
 INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN
 RECALL PERFORMED RECALL
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 99S15 REPLACE CRUISE CONTROL PRESSURE SWITCH PER RECALL
 RECALL 99S15 99S15
 RECALL REPL S-C DEACTIVATION SW PER RECALL
 PERFORMED RECALL
 99S15 99S15 W SPEED CONT. SWITCH

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. TEST DROVE TO CHECK FOR NORMAL OPERATION.
 PERFORMED 99S15 RECALL
 RECALL REPLACED SWITCH AND CONNECTOR
 1 PERFORM RECALL 99S15 SPEED CONTROL DEACT. SWITCH 99S15B
 99S15B RECALL 99S15B RECALL
 99S15 99S15
 RECALL REPLACED SWITCH
 99S15 RECALL W REPLACE SWITCH GA
 99S15 99S15

Box Files

31143 WARRANTY PERFORMED ENGINE PERFORMANCE WORKSHEET. FOUND EBP SENSOR AND TUBE CLOGGED. R&R EBP, R&I EBP TUBE AND CLEANED OUT. REINSTALLED T
REPLACE SPEED CTRL SWITCH AND CONNECT
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
PERFORMED RECALL
COMPL: RECALL 98S15, CAUSE: SPEED CONTROL DEACTIVATION. CAUSE: REPLACE DEACTIVATION SWITCH AND CONNECTOR APROX TIME: 0.5 HRS
RECALL 98S15 COMPLETED

REPLACED BRAKE DEACTIVATION SWITCH
PERFORM RECALL
PERFORM RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH
91046 SAFTY RECALL PERFORMED RECALL 98S15 DEACTIVATION SWITCH REPLACEMENT ALSO TEST DROVE VEHICA

115629 98S15 RECALL R+R DEACTIVATION SWITCH

REPLACE SWITCH AND HARD SHELL
94430 REPAIRED SPEED CONTROL PER RECALL
98S15 SPEED CONTROL DEATIVATION 98S15
AS PER RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
PERFORM 98S15
18746 RECALL 98S15 PERFORMED RECALL
86235 SPEED CONTROL RECALL 98S15B 0.5 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH.
0 98S15 PROGRAM
REPLACED DISENGAGE SWITCH PER RECALL 98S15.
REPLACED CRUISE CONTROL SWITCH AND CONNECTOR AS PER RECALL 98S15
RECALL 98S15 COMPLETED
RECALL 98S15 PERFORMED 1
REPAIR AS PER RECALL
COMPLETED RECALL
RECALL 98S15
TECH INSTALLED NEW CRUISE DE ACTIVATION SWITCH PER FORD RECALL
COMPLETED RECALL
INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL
PERFORM RECALL 98S15
125200 RECALL 98S15 0.5 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15.
DEACTIVATION SWITCH 98S15
RECALL 98S15

REPLACE CRUISE DEACTIVATION SWITCH AS PER 98S15 RECALL
PERFORM RECALL
REPLACE CRUISE SWITCH PER RECALL

PERFORM RECALL
PERFORMED RECALL 98S15 FUSE FOR BRAKE SHIFT INTERLOCK BLOWN FROM HITTING WIRE WHEN CHANGING CONNECTION REPLACED FUSE ROAD TEST OKT
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY, CHECK NORMAL OPERATION.
PERFORMED RECALL 98S15-INSTALL SWITCH
PERFORMED RECALL
RECALL REMOVE TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SW

Box_Files

PERFORM RECALL
 99S15 99S15 REPLACE CRUISE SWITCH PER RECALL
 99S15 R&R SW & CONNECTOR
 REPLACED DEACTIVATION SWITCH AS PER RECALL
 JPERFORM RECALL 99S15 T101
 DONE AS PER INSTRUCTIONS
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .5
 101617 RECALL 99S15 0.5 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 COMPLETE RECALL 00
 RECALL 99S15
 PERFORMED RECALL
 SPD CTRL DEACTIVATION SW REPLACE PERFORMED RECALL 99S15
 1 INSTALLED SPEED CONTROL SWITCH 1
 REPLACE CRUISE SWITCH AND CONNECTOR
 96297 RECALL 99S15 RECALL 99S15
 REPLACED CC BRAKE SWITCH AS PER RECALL 99S15
 SPEED CONT REPL SWITCH
 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL C
 AS PER RECALL DEACTIVATOR SWITCH

 PERF RECALL 99S15
 PERFORMED RECALL 99S15 (SPEED CONTROL)
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER SAFETY RECALL 99S15.
 52178 RECALL 99S15 INSTALLED RECALL 99S15.
 RECALL 99S15 99X15
 PERFORMED RECALL ...INSTALLED DEACTIVATION SWITCH AND HARD SHELL CONNECTOR ...AS PER RECALL ...M
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR
 COMPLETED CAMPAIGN COMPLETED OP 99S15B
 99S15 COMPLETED 99S15 COMPLETE
 RECALL PERFORMED
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL
 99S15 99S15 COMPLETED
 48674 RECALL 99S15 CC42 W PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
 INSTALL SWITCH AND HARNESS PER RECALL
 DONE AS PER INSTRUCTIONS
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - 99S15B .5
 INSTALLED DEACTIVATION SWITCHES, PER RECALL RD TEST OK
 1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X3
 1 REPLACED BRAKE SWITCH CONNECTOR
 78213 REPLACED BRAKE SWITCH AND HARD SHELL CONNECTOR. NOTE: AIR SUSPENSION LIGHT ON DIMLY ON DASH.
 78169 RECALL PERFORMED RECALL 99S15
 REPLACE CRUISE SWITCH AND CONNECTOR
 RECALL PERFORMED RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 1 PERFORM RECALL AS REQUIRED
 REPLACE DEACTIVATION SWITCH AND CONNECTOR

Box_Files

RECALL REPLACE CRUISE DEACTIVATION SWITCH
 INSTALL SWITCH PER RECALL LETTER
 99S15 RECALL COMPLETED
 X RECALL
 CHECKED AND REPLACED VACUUM RELEASE
 0 COMPLETE RECALL
 REPLACE SWITCH AND CONNECTOR PER RECALL
 RECALL 99S15 RECALL COMPLETED
 REPLACED SPEED CONTROL SWITCH.
 99S15 PERFORMED 99S
 PERFORMED RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 99S15B RECALL 99S15B REPLACED CRUISE DEACTIVATION SWITCH RECALL
 REPLACE SWITCH AS PER RECALL
 PERF RECALL 99S15
 INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN. TIME
 PERFORMED RECALL 99S15. ALL OK AT THIS TIME.
 REPLACE CRUISE DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 RECALL RECALL
 M RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 REPLACED SWITCH AND CONNECTOR. 1
 RECALL 99S15 RECALL COMPLETED
 AE PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
 102720 99S15 W PERFORMED RECALL 99S15 SPEED DEACTIVATION SWITCH.
 PERFORMED RECALL 99S15
 REPLACED CRUISE CONTROL SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPL SWITCH PER RECALL
 RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL.
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 REPLACE CRUISE DEACTIVATION SWITCH
 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15
 RECALL 99S15 RECALL COMPLETED

RECALL PERFORMED RECAL
 PREFROMED RECALL
 REPLACE SWITCH AND CONNECTOR PER RECALL
 PERFORMED RECALL AS REQUIRED
 88748 REPLACED SPEED CONTROL DEACTIVATION SW, S-2 8274
 REPLACE BRAKE PRESSURE SWITCH PER RECALL
 PERFORMED RECALL 99S15
 92367 REPLACED SWITCH & CONNECTOR PER 99S15.
 1 PERFORMED RECALL 99S15

Box_Files

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL RETEST OK
 PERFORM RECALL
 RECALL PER FORD
 75828 PERFORMED RECALL 98S15
 PERF RECALL 98S15
 COMPLETED RECALL 98S15, REMOVED AND INSTALLED NEW SPEED CONTROL SWITCH AND WIRE HOUSING, TECH 272-8364

61122 RECALL WARRANTY COMPLETED RECALL 98S15, ROAD TEST - O.K.
 COMPLETED RECALL 98S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR 98S15B .5 + .1
 98S15B RECALL DONE 98S15B REPLACED CRUISE DEACTIVATION SWITCH
 PERFORMED RECALL AS BY FACTORY PERFORMED RECALL REPLACED DEACTIVATION SWITCH
 RECALL 98S15
 REPLACE SW AND CONNECTOR
 REPLACED DEACTIVATION SWITCH PER RECALL
 CRUISE SWITCH RECALL REMOVED AND REPLACED CRUISE SWITCH RECALL

61840 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
 PERFORMED RECALL 98S15 INSTALLED SWITCH AND CONNECTOR PER RECALL 98S15

PERF RECALL 98S15

67071 98S15 98S15B .5 .5 REPLACE CONECTOR, SWITCH, BLEED BRAKES
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 RECALL 98S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
 PERFORM SAFETY RECALL
 120782 RECALL ON SPEED DEACTIVATION SWITH WARR COMPLETED
 INSPECT SPEED CONTROL SYSTEM AND COMPLETE LABOR OPERATION ACCORDINGLY COMPLETED SPEED CONTROL DEACTIVATION CAMPAIGN
 98S15 COMPLETED 98S15 COMPLETED
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 RECALL PERFORMED RECAL 9815 REPLACED SWITCH
 55738 RECALL W 0.5 HRS ADMS 0.1 INSTALLSPEED CONTROL SWITCH PER RECALL 98S15 OPERATION 98S15- B
 1 PERFORMED A SAFETY RECALL AS TO REMOVE AND REPLACE THE DEACTIVATOR SWITCH
 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 97555 98S15 W REPLACED SWITCH
 41857 RECALL COMPLETE
 1 PERFORM RECALL
 98S15 98S15 98S15
 FORD SAFETY RECALL REPLACED SPEED DEACTIVATION SWITCH
 103944 RECALL 98S15
 RECALL PERFORMED RECAL
 INSTALLED CRUISE DEACTIVATION SWITCH PER RECALL
 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
 98S15B RECALL 98S15B REPLACED DEACTIVATION SWITCH
 RECALL 98S15 RECALL
 118848 RECALL SWITCH
 81857 R-R SPEED CONTROL SWITCH
 REPLACED DISENGAGE SWITCH PER RECALL 98S15.

Box_Files

98S15 98S15 REPLACE CRUISE SWITCH PER RECALL 98S15

98S15 98S15

PERFORM RECALL

PERFORMED RECALL

REPLACED DEACTIVATION SWITCH PER RECALL 1

1 REPLACE DEACTIVATION SWITCH. RETEST OK

98S15 98S15

RECALL 98S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

RECALL REPLACED CRUISE SW

REPLACE SWITCH RECALL 98S15

X REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

RECALL REPL DEACTIVATION SW PER RECALL

PERFORMED RECALL

107275 98S15 REPLACE SWITCH PER 98S15B 0.5 HRS

97844 WARR DONE RECALL 98S15 REPLACE BRAKE REPAIR KIT

71421 REPLACE SWITCH AS PER RECALL

REPLACE SPEED CONTROL CABLE AS PER RECALL

6783 RECALL 98S15 RECALL 98S15

PERF RECALL 98S15

RECALL REPLACED CONTROL SWITCH PER RECALL

COMPLETED RECALL 98S15 1

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL INSTALLED UPDATED DEACTIVATION SWITCH

PERFORM RECALL 98S15

REPLACED SWITCH AND CONN. PER RECALL

COMPLETE RECALL REPAIRS

RECALL 98S15 RECALL 98S15 COMPLETED

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATOR SWITCH AS PER RECALL 98S15

PERFORM RECALL

PERFORM RECALL

REMOVED DEACTIVATOR SWITCH THREADS COMING OUT WITH SWITCH-REPLACED WIRING CONNECTOR-REPLACED BRAKE DEACTIVATOR BLOCK AND BLEED BRAKE SYSTEM

INSTALL CRUISE SWITCH

90852-42-114508 DO RECALL 98S15 PUT IN NEW SW AND WIRE COND

REPLACE DEACTIVATION SWT PER RECALL

RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL 98S15

118557 REPLACE SWITCH & WIRE CONNECTOR AS PER 98S15

REPLACE CRUISE SWITCH AND CONNECTOR PER RECALL

RECALL 98S15 PERFORMED RECALL 98S15

REPLACE SPEED CONTROL SWITCH

COMPLETE RECALL

INSTALL DEACTIVATION SWITCH PER RECALL 98S15

Box_Files

1 COMPLETE RECALL
 PERFORMED RECALL 99S15. INSTALLED NEW BRAKE REPAIR KIT OPERATING OK. TECH 71-2488
 80800 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.

99S15 REPLACED DEACTIVATION SWITCH AS PER RECALL.
 REPLACED SWITCH AND CONN
 RECALL PERFORMED RECALL
 . REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR 99S15B .5
 TECH 812 PERFORMED RECALL SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
 1 REPLACE CRUISE CONTROL SWITCH.
 REPLACE CRUISE SWITCH AND CONNECTOR
 INSPECT AND INSTALL SPEED CONTROL DEACTIVATION SWITCH CONNECTOR
 47318 RECALL 99S15 DONE DEACT SWITCH SPEED CONTROL
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL C
 PERFORMED RECALL 99S15, R-R SWITCH, HARDSHELL, AND BLEED.
 1 PERFORM RECALL 99S15
 99S15 COMPLETED 99S15 COMPLETED
 PERFORMED RECALL 99S15-INSTALL SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 PERFORMED RECALL
 78858 RECALL 99S15B 0.5 HR INSTALL SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
 1 PERFORMED RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER 99S15 RECALL
 54273 RECALL 99S15 RECALL 99S15 REPLACE SPEED CONTROL SWITCH AND HARD SHELL
 RECALL COMPLETED ALL OK
 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACE SPEED CONTROL SWITCH ASY

PERFORM RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER SAFETY RECALL 99S15.
 PERFORMED RECALL
 PERFORMED RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORM FACTORY RECALL THANK YOU
 COMPL: 99S15, CAUSE: 9915, CORRE: SPEED CONTROL DEACTIVATION APROX TIME: 0.5 HRS
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 99S15 99S15 REPLACED CRUISE DEACTIVATION SWITCH
 99S15 RRECALL 99S15 REPLACE DEACTIVATION SWITCH AS PER RECALL
 6708 SPEED CONTROL SWITCH RECALL
 REPLACE SPEED CONTROL SWITCH AND CONNECT
 57358 .5 99S15 COMPLETE
 98244 RECALL 99S15 W 7823 VERIFIED RECALL INSTALLED DEACTIVATION SWITCH
 PERFORM RECALL
 REPAIR AS PER RECALL 99S15.

8082-425-R 2526

Box_Files

108457 98S15

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH
INSTALLED DEACTIVATION SWITCH AS PER 98S15
1 REPLACE CRUISE DEACTIVATION SWITCH.

RECALL 98S15 REPLACE C-C SW

108881 PERFORMED RECALL 98S15
1 INSTALLED CRUISE DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH
PERFORMED RECALL REPLACED SPEED DEACTI SWITCH
PERFORMED RECALL
98S15B 98S15B
PERFORM RECALL 98S15
REPLACED C CONTROL DEACTIVATION SWITCH PER 98S15 RECALL
107421 R+R CRUISE SWITCH
31887 98S15 PERFORM RECALL
PERFORM RECALL 98S15
CK Y REPLACE CC DEACTIVATION SWITCH
98S15E REMOVE TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - 98S15B .5
RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

RECALL 98S15 RECALL
98S15 98S15
81804 98S15B 0.5 HRS. SPEED CONTROL RECALL
REPLACED DEACTIVATION SWITCH.
RECALL PERFORM CRUISE CONTROL DEACTIVATION SW.RECALL CRUISE INOP.PRIOR
REPLACE SPEED CONTROL SWITCH
COMPLETE AS PER INSTRUCTED
REPLACED SPEED CONTROL DEACTIVATION SWITCH
PERFORMED RECALL
RECALL COMPLETE
X PERFORMED RECALL
98S15 RECALL NOTIFICATION 98S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL
97833 98S15 98S15 .5 .5 REPLACE SWITCH & CONECTOR PER RECALL

PERFORM RECALL 98S15
REPLACED BRAKE SWITCH AND CONN. PER RECALL 98S15

PERFORMED RECALL 98S15
98S15 REPLACE DEACTIVATION SWITCH
RECALL REPLACED DEACTIVATION SW AND BLED BRAKES

RECALL R+R DEAC SW, INSTALLED NEW CONNECTOR, RECD OK
82908 RECALL 0.5 PERFORM RECALL 98S15

PERFORMED RECALL 98S15 .6HRS LABOR

EP80-020-R-2527

Box_Files

74507 RECALL 98S15B 0.5 REPLACE SPEED CONTROL DEACTIVATOR SWITCH AND CONNECTOR.
INSTALLED SPEED DEACTIVATION SWITCH
RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW.
COMPLETED RECALL
RECALL COMPLETE

INSTALLED DEACTIVATION SWITCH
PERFORMED RECALL 98S15 REPLACED CRUISE SWITCH
REPLACED SC DEACTIVATION SWITCH 98S15
RECALL COMPLETE
COMPLETED RECALL 98S15, SPEED CONTROL DEACTIVATION SWITCH
1 COMPLETED RECALL
RECALL PERFORMED RECALL 98S15
PERFORM RECALL
PERFORMED RECALL

PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
REPLACE SPEED CONTROL DEACTIVATION SWITCH
REMOVE AND REPLACE CRUISE CABLE PER RECALL
OPEN RECALL. PERFORMED 98S15 RECALL
1 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL
98S15 COMPLETED 98S15 COMPLETED
RECALL 98S15
RECALL 98S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACE SWITCH
RECALL 98S15
04965 OPEN RECALL 98S15 REPLACE SWITCH DONE
23710 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
54115 RECALL PERFORMED RECALL 98S15 GC42 CUSTOMER DECLINE RECOMMENDED SERVICE
RECALL 98S15 PERFORMED RECALL 98S15
PERFORM RECALL 98S15
24474 98S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 0937
FACTORY RECALL. REPLACED DEACTIVATION SWITCH AS PER RECALL
SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15
RECALL DID RECALL

102857 RECALL 98S15B 0.5 SPEED CONTROL DEACTIVATION SWITCH RECALL 98S15
REMOVED AND REPLACED HARNESS CONNECTOR PERFORMED RECALL 98S15
RECALL CRUISE CONTROL RECALL 98S15
REPLACE SWITCH AND CONNECTION PER RECALL

RECALL 98S15 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15
SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15

Box_Files

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
99S15 RECALL SERVICE

PERFORM RECALL 99S15
REPLACE SPEED CONTROL SWITCH
RECALL REPAIR AS PER RECALL 99S15

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER FORD
99S15 99S15
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
RECALL REPAIR
R&R SPEED CONTROL DEACTIVATION SWITCH PER 99S15
DEACTIVATION SWITCH MTIME TO DIAG CONCERN, REPLACE DEACTIVATION SWITCH

RECALL PERFORMED RECALL 99S15
99S15 99S15 COMPLETED
99S15 99S15 RECALL PERFORMED
REPLACE SPEED CONTROL DEACTIVATION SWITCH...
SPEED CONTROL SWITCH 99S15 RECALL
A DONE
RECALL 99S15 RECALL 99S15
PERFORMED RECALL

48110 RECALL W REPLACE SWITCH AND PLUG GA

REPLACED SC DEACTIVATION SWITCH 99S15
INSOECT FOR RECALL 99S15
PERF RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS
RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
PERFORM RECALL PER MANUFACTURER REPLACED DEACTIVATION SW.
REPLACE SPEED CONTROL DEACTIVATION SWITCH
99S15 REPL SWITCH & CONNECTOR
68226 REPLACE DEACTIVATION SWITCH PER RECALL 99S15B 0.5 ADMIN 0.1

99S15 RECALL 99S15 RECALL COMPLETE
INSOECT FOR RECALL 99S15
99S15 REPLACE SWITCH
PERFORMED RECALL 99S15
REMOVED AND REPLACED BRAKE SWITCH PERFORMED RECALL 99S15

COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
PERFORMED RECALL PERFORMED RECAL
REPLACE SPEED CONTROL DEACTIVATION SWITCH

99S15 REMOVE OLD SPEED CONTROL SWITCH REPLACE WITH NEW ONE AS PER

Box Files

99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
PERFORM RECALL REPLACE SWITCH

RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SW.
PERFORMED RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL PERFORM RECALL
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

RECALL PERFORMED
PERFORMED RECALL 99S15
PERFORMED RECALL
PERF RECALL 99S15
RECALL COMPLETE

1 REPLACE SWITCH & CONNECTOR BLEED SYSTEM
PERFORMD RECALL
RECALL COMPLETED

REPLACED DEACTIVATION SWITCH PER FACTORY RECALL
1 1 REPL SPEED CONTROL SWITCH

PERFORMED RECALL

COMPLETE RECALL
99S15 RECALL SPEED CONTROL DEACTIVATION SWITCH
RECALL RECALL
PERFORM 99S15 99S15
99001 RECALL 99S15. PERFORMED RECALL 99S15 AND CHECKED;OK.
99S15 RECALL 99S15 SPEED CONTROL SWITCH

RECALL COMPLETE
99287 RECALL W INSTALL KIT GA
PERFORM RECALL
99S15 COMPLETED 99S15 COMPLETED
REPLACED SPEED CONTROL DEACTIVATION SWITCH
RECALL COMPLETE
INSOECT FOR RECALL 99S15
PERFORMED RECALL
RECALL COMPLETED.

REPLACE CRUISE DEACTIVATION SWITCH
RECALL . PERFORM RECALL
100029 PERFORMED RECALL

REPLACE CONNECTOR AND SWITCH
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
193879 REMOVE AND REPLACE DEACTIVATION SWITCH AND WIRE CONNECTOR AND BLEED BRAKE

A SHORT IN THE SPEED CONTROL SWITH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEACTIVATION SWITCH

Box_Files

REPLACE SPEED CONTROL DEACTIVATION SWITCH
DIAGNOSIS AND INSPECT FOR CAMPAIGN PERFORM CAMPAIGN AS PER NOTICE REPLACED SWITCH
C PERFORMED RECALL
REPLACE CRUISE SWITCH
PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

99S39 RECALL 99S15. PERFORMED RECALL 99S15 AND CHECKED OK.
PERFORMED RECALL
REPLACED BRAKE DEACTIVATION SWITCH AND CONNECTOR 99S9
SPEED CNTRL DEACTVTN SWITCH RPLCMT/PERF SAFETY RECALL 99S15
78767 RECALL 99S15 REPLACED DEACTIVATOR SWITCH AND CONNECTOR
REPLACED DEAC. SWITCH PER RECALL
COMPLETED RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
REMOVED AND REPLACED BRAKE SWITCH PERFORMED RECALL 99S15
PERFORMED RECALL
RECALL REPLACE SWITCH
REPLACE SWITCH AND CONNECTOR PER RECALL
REPLACED BRAKE SWITCH AND CONN PER RECALL 99S15
PERFORMED SPEED CONTROL RECALL
PERFORM SPEED SWITCH RECALL 99S15
99S15 RECALL 99S15 RECALL
102290 PERFORM RECALL AS PER FOMOCO
101670 RECALL 99S15B 0.5 0.5 RECALL

99S39 RECALL 99S15, REPLACE SWITCH
PERFORM RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH
X 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
51614 W.. REPLACE CRUISE SWITCH PER RECALL (CC82)
99718 RECALL WP30 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL 99S15
PERF RECALL
REPLACED SC DEACTIVATION SWITCH 99S15
99S15B
SPEED CNTRL DEACTVTN SWITCH RPLCMT/PERF SAFETY RECALL 99S15
REPAIR AS PER RECALL

99S16 RECALL SERVICE
REPLACED SPEED CONTROL DEACTIVATION SWITCH
INSTALLED SWITCH PER RECALL
RECALL 99S15
RECALL PERFORMED 99S15
RECALL INSTALL SWITCH
PERF RECALL

Box_Files

99S15 COMPLETED 99S15 COMPLETED
COMPLETED AS PER RECALL
COMPLETED RECALL REPLACED SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH
PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
PERFORMED RECALL 99S15 REPLACED SWITCH AND CONNECTOR
PERFORM RECALL 99S15
PERFORMED RECALL 99S15
PERFORM RECALL
REPL SPEED CONTROL SWITCHES
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
99S15 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH

87918 RECALL 99S15 W PERFORMED RECALL 99S15; REMOVED AND REPLACED DEACTIVATION SWITCH AND CONNECTING WIRES, BLEED AIR FROM SYSTEM.
INSTALLED KIT TO COMPLETE
PERFORMED THE RECALL 99S15
99S15 RECALL PERFORMED
PERFORM RECALL AS PER NOTICE
PERFORMED RECALL
PERFORMED 99S15 RECALL

PERFORMED RECALL
RECALL COMPLETE
INSTALLED PART PER RECALL

47556 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONENCTOR ROAD TEST
74256 REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER RECALL
PERFORMED RECALL
PERFORMED RECALL PERFORMED RECAL
RECALL 99S15 PERFORMED DEACTIVATION SWITCH RECALL
1 PERFORMED RECALL
PERFORM RECALL 99S15
RECALL REPLACE CRUISE CONTROL DEACTIVATION SWITCH RECALL
REPL DEACTIVATION SWITCH 99S15
REPLACE SWITCH PER RECALL
PERFORM RECALL 99S15
88757 RECALL 99S15 REPLACED SWITCH AND HARD SHELL CONNECTOR
PERF RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL 99S15 RECALL 99S15
99S15 COMPLETED 99S15 COMPLETED
PERFORMED RECALL 99S15 NEEDS FRT BRAKES CUSTOMER ADVISED
PREFORMED RECALL AS PER 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

Box_Files

99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
RECALL 99S15 REPLACED SWITCH

130379 REPLACED SWITCH AND CONNECTOR PER RECALL
RECALL 99S15 RECALL 99S15

REPLACED SWITCH AND CONNECTOR PERFORM 99S15 RECALL

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
INSTALL SWITCH PER RECALL

PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

1 PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH
DIAG AND PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH ON VEHICLE CRUISE OK NOW
RECALL 99S15 REPLACED DEACTIVATOR SWITCH AND HARDSHELL CONNECTOR

REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15

PERFORM RECALL 99S15

PERFORMED RECALL 99S15B

73296 PERFORMED RECALL 99S15 AND ROADTESTED

90102 99S15B 0.5 0.5 PERFORM 99S15

RECALL DONE

REPLACE SW PER RECALL INSTRUCTIONS

PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPAIR AS PER RECALL

99S15 COMPLETED 99S15 COMPLETED

1 REPLACED SENSOR AND CONNECTOR

1 PERFORM RECALL 99S15

PERFORMED RECALL 99S15B REPLACED DEACTIVATION SWITCH

PERFORM RECALL

SWITCH REPLACE SPEED CONTROL SWITCH

37638 RECALL INSTALL DEACTIVATION SWITCH

PERF RECALL

PERF RECALL

79733 RECALL 99S15 INSTALL NEW SPEED CNTRL SWTC

? COMPLETED RECALLS-CAMPAIGN 99S15

RECALL COMPLETE

RECALL COMPLETE

PERFORMED RECALL 99S15-INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH

1 PERFORM RECALL 99S15 BRAKE SWITCH

045 REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR

REPL SPEED CONTROL SWITCH

1 PERFORM RECALL 99S15

Box_Files

RECALL
PERFORMED RECALL
98S15 RECALL
COMPLETE RECALL

RECALL
98S15 COMPLETE RECALL

28200 98S15 DONE *28
0 REPLACED SWITCH PER RECALL
98S15 RECALL 98S15 REPLACE SWITCH AS PER RECALL
REPLACED SPEED CONTROL SWITCH

54420 RECALL WARR REPLACE CRUISE DEACTIVATOR SWITCH AND CONNECTOR

78779 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST
102568 98S15 RECALL REPLACE BRAKE SWITCH AND CONNECTOR PER RECALL

REPLACED CONTROL CONTROL DEACTIVATION SWITCH PER RECALL 98S15. CONSEQUENTIAL DAMAGE TO VALVE BLOCK, SWITCH WAS STRIPPED AND PULLED THREADS OUT.

1 PERFORM SPEED CONTROL DEACTIVATION SWITCH
INSTALL BRAKE SWITCH KIT
COMPLETED 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACE SPEED CONTROL SWITCH
DEACTIVATION SWITCH 98S15
84424 REPLACE SWITCH AND CONNECTOR BLEED REAR BRAKES

REPLACE DEACTIVATION SWITCH AS PER RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

0 98S15 PROGRAM
PERFORM RECALL REPLACE SWITCH
PERFORMED RECALL
RECALL 98S15 INSTALLED MODIFICATION FOR CRUISE CONTROL
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
11536 RECALL 98S15 RECALL 98S15 REPLACE SWITCH AND HARD SELL
RECALL 98S15
RECALL REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
PERFORM RECALL 98S15, REPLACE CRUISE DEACTIVATE SWITCH
PERFORM RECALL AS OUTLINE BY FOMOCO
PERFORM RECALL AS PER NOTICE
PERFORMED RECALL
81782 RECALL WP40 PERFORMED 98S15 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH
98892 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL
REPLACED SWITCH PER RECALL

ES02-025-A 3534

Box_Files

TECHNICIAN COMPLETED RECALL 98S15 - SPEED CONTROL DEACTIVATION SWITCH
 RECALL REPL SW.
 PER NOTIFICATION RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTIONS
 RECALL SPEED CONT DEACTIVATION M
 CAMPAIGN COMPLETED
 PERFORMED CRUISE CONTROL SWITCH RECALL
 PERFORMED RECALL BY INSPECTION AND REPLACING SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER
 REPLACE SWITCH AS PER RECALL
 PERFORM 98S15 RECALL
 RECALL SW REPLAC
 REPLACED SWITCH FOR SPEED CONTROL DEACTIVATION PER RECALL
 PERFORMED RECALL
 PERFORM RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTIONS
 RECALL 98S15
 98S15 RECALL PERFORMED
 1 JOB COMPLETED
 REPLACED DEACTIVATION SWITCH

 PERFORMED RECALL 98S15, REPLACED DEACTIVATION SWITCH AND REWIRED PIGTAIL
 INSTALL SWITCH AND CONNECTOR
 34328 REC WARR 627 PERFORM RECALL 98S15
 DID RECALL 98S15B
 1 REPLACED DEACTIVATION SWITCH
 PERFORM SPEED CONTROL DEACTIVATION SWITCH RECALL
 REPLACE SPEED CONTROL SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15.
 REPLACED SPEED CONTROL CABLE PER RECALL
 98S15 98S15
 RECALL RECALL
 60651 RECALL 98S15 REPLACED SWITCH
 RECALL DONE

 1 REPLACED CONNECTOR & SWITCH

 PERFORMED RECALL

 RECALL SW REPL
 REPLACE SWITCH
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 78361 98S15 SPEED CONTROL RECALL 0.5 98S15B PERFORMED RECALL AS PER RECALL
 PERFORMED RECALL
 1 COMPLETED RECALL
 47204 PERFORMED SPEED CONTROL RECALL 98S15
 PERFORM RECALL 98S15 COMPLETED
 PERFORMED RECALL 98S15 CRUISE DEACTIVATION .5 HR 2068
 75071 PERFORM 98S15 RECALL , REPLACED SWITCH
 PERFORMED RECALL 98S15
 49824 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR
 28217 REPLACED SPEED CONTROL DEACTIVATION SWITCH, S-2 8274
 REPLACE DEACTIVATION SWITCH AS PER RECALL

Box_Files

MAINTENANCE RECALL COMPLETE
 RECALL SW SW REPLACE
 1 REPLACE HARD SHELL CONNECTOR
 PERFORMED RECALL
 RPELSAEC CC CONNETOR AND SWITCH
 PERFORM RECALL
 RECALL COMPLETE
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 PERFORM RECALL-99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 93124 RECALL 99S15 RECALL 99S15 REPLACE SWITCH AND HARD SHELL
 1 PERFORM RECALL
 93118 RECALL PERFORMED RECALL 99S15
 INSTALL SWITCH AND HARD SHELL
 99S15 REPLACE CRUISE DEACTAVATION SWITCH
 99708 SAME PERFORM RECALL 99S15 7156
 76215 RECALL 99S15 REPLACE THE DEACTIVATOR SWITC
 26890 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH IN
 1 INSTALL CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 PERFORM RECALL 99S15

PERFORMED THE RECALL 99S15

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEACTIVATION SWITCH
 99S15 99S15
 93197 99S15 REPLACED CRUISE SWITCH
 REPLACE CRUISE SWITCH
 103291 PERFORMED RECALL 99S15.
 132820 PERFORM RECALL 99S15 INSTALL DECTIVATION SWITTH

PERFORM RECALL 99S15
 99S15 99S15
 PERFORMED RECALL
 1 RECALL 99S15B
 3 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL 99S15 CRUISE CONTROL SWITCH
 REPLACED DEACTIVATION SWITCH AND CONNECTOR
 COMPLETED RECALL 99S15 REPLACEMENT OF SPEED CONTROL DEACTIVATION SWITCH

112790 PERFORM RECALL 99S15B, (REPLACE CRUISE SWITCH AND CONNECTOR)
 PERFORMED RECALL
 PERFORMED RECALL AS NEEDED ALL OK

1 REPL. CONN. AND DEACT SWITCH
 85482 RECALL W INSTALL SWITCH AND CONNECTOR ME
 INSTALL DEACTIVATION SWITCH AS PER 99S15

VERIFY RECALL AND PERFORM PER INST

Box_Files

85170 PERFORM 99S15 RECALL
 REPLACED THE SWITCH PER RECALL 99S15
 99S15 99S15 RECALL
 OTHER 99S15 PERFORM RECALL
 RECALL COMPLETED
 99S15 99S15
 85469 99S15 RECALL W PERFORM 99S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH

0 99S15 PROGRAM

INSPECT FOR RECALL 99S15
 REPLACE SWITCH
 112050 RECALL W REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15
 PERFORMED RECALL 99S15
 INSTALL SPEED CONTROL SYSTEM
 REPLACE SWITCH PER RECALL
 87601 DID RECALL 99S15 CRUISE CONTROL.

99S15 COMPLETED
 RECALL RECALL
 RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 RECALL 99S15
 RECALL COMPLETED ALL OK
 RECALL SW REPL CRUISE SW
 78205 99S15 WARR REPLACED SWITCH AND CONN

PERFORMED RECALL 99S15B.

88828 99S15 MECC TO REPLACESPEED CONTROL DEAC SW PER RECALL
 REPLACE CRUISE SWITCH PER RECALL
 REPLACE SPEED CONTROL SWITCH
 COMPL: RECALL 99S15 CAUSE: SPEED CONTROL
 REPLACE SWITCH PER RECALL

CORRE: REPLACE DEACTIVATION SWITCH AND CONNECTOR

1 REPLACED CRUISE SWITCH. BLEAD BRAKES. TEST DROVE
 PERFORM RECALL REPL DEACTIVATION SWITCH
 RECALL COMPLETE, REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 87621 REPLACED DEACTIVATION SWITCH AS PER RECALL. 99S15B 0.5HR ADMIN 0.1HR
 99S15 PERFORMED RECALL
 99S15 PERFORMED RECALL 99S15
 PERFORMED RECALL
 REPLACE SW AND CONNECTOR
 A PERFROM RECALL

PERFORMED RECALL
 F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 84887 REPLACED BRKE CONTROL KIT AS PER RECALL 99S15.

Box_Files

123228 98S15 WARR VERIFIED RECALL PERFORMED RECALL 98S15 NOTE DRIVERS GLASS INOP PRIOR TO REPAIRS 2321
98S15 REPL SWITCH & CONNECTOR

INSTALL NEW DEACTIVATION SWITCH AND HARDSHELL CONNECTOR 98S15

RECALL 98S15 COMPLETED

PERFORMED RECALL

78803 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER 98S15 RECALL

REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR

98S15 98S15 DONE

PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

1 PERFORM RECALL

INSTALLED DEACTIVATING SWITCH AS PER RECALL 98S15 . TECH 43-2418

86685 98S15 C-CONTROL RECALL .5 TEST DROVE & HAD NO PROBLEMS

PERFORMED RECALL

PERFORMED RECALL

REPLACED SC DEACTIVATION SWITCH 98S15

RECALL 98S15B PER RECALL INSTRUCTIONS

98S15 98S15 RECALL PERFORMED

AS PER RECALL REPLACE BRAKE SWITCH PER RECALL

SPEED CNTRL DEACTVTN SWITCH RPLCNTPERF SAFETY RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL

REPLACED DEACTIVATION SWITCH

REPAIRED AS PER RECALL SPEED CONTROL DEACTIVATIONSWITCH

PERFORMED RECALL 98S15

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED CONTROL DEACTIVATION SWITCH

1 PERFORM RECALL

REPLACE SWITCH AND HARD SHELL

RECALL 98S15 COMPLETED

INSTALLED NEW CONNECTOR AND BRAKE PRESSURE SWITCH BLED SYSTEM AND CHECKED AND OK

COMPLETED RECALL 98S15

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

RECALL COMPLETED

REPLACED DEACTIVATION SWITCH

RECALL REPLACE SWITCH, HARDSHELL CONNECTOR& BLEED BRAKES

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

PERFORMED RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL

23410 RECALL REPLACED CRUISE SW. 98S15B — .5 HRL

REPLACE SPEED CONTROL SWITCH

PERFORM RECALL

1 PERFORMED RECALL 98S15

REPLACED SPEED CONTROL SWITCH.

COMPLETED RECALL 98S15

83504 PERFORMED RECALL 98S15 INSTALL NEW DEACTIVATION SWITCH AND CONNECTOR

REPLACED DEACTIVATION SWITCH PER RECALL

Bcx_Files

RECALL 99815

1 COMPLETED RECALL AS REQUESTED.
73827 W REPLACED SPEED CONTROL SWITCH PER RECALL 99815.
PERFORM RECALL
PERFORM RECALL 99815
X COMPLETED
PERFORMED SPEED RECALL 99815
PERFORMED RECALL AS PER INSTRUCTIONS
REPLACE KIT PER RECALL
180088 42 WP40 99815 RECALL REPLACE SWITCH

PERFORMED RECALL 99815

PERFORM RECALL 99815 REPLACE CRUISE DUMP SWITCH BLEED BRAKES
PERFORM RECALL

86384 W REPLACED SPEED CONTROL SWITCH PER RECALL 99815.
REPLACED DEACTIVATION SWITCH
RECALL SW CRUISE SW

PERFORMED CRUISE CONTROL RECALL 99815

RECALL PERFORM RECALL 99815

RECALL 99815 COMPLETED RECALL 99815

SHORT MAY DISABLE SPEED CONTROL OR CAUSE BRAKE LIGHT FUSE TO OPEN DISCONNECT CONNECTOR FROM CRUISE DEACTIVATION SWITCH & PROTECT END FROM COI

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99815 - MILES OUT 88001

112882 WARRANTY PERFORMED RECALL 99815 AS PER RECALL INSTR, ROAD TEST OK,

PERFORM RECALL REPLACE SWITCH

32458 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99815

73384 RECALL 99815 RECALL 99815

94880 PERFORMED RECALL 99815

RECALL PERFORM RECALL 99815 SPEED CONTROL

REPLACED DEACTIVATION SWITCH

PERFORMED RECALL 99815 - CHECK AND REPAIRED DEACTIVATION SWITCH AND RECHECK OK

PERFORMED RECALL

INSTALLED DEACTIVATION SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

17024 RECALL 99815 INSTALL NEW SWITCH AND CONNECTOR

PERFORMED RECALL 99815.

87386 INSTALLED NEW CONNECTOR AND SWITCH AS PER RECALL.

1 08 REPLACED SWITCH

CABLE PERFORM RECALL

99815 RECALL 99815 RECALL, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDS

COMPLETED RECALL

PERFORMED RECALL

PERFORMED RECALL 99815

PERFORMED RECALL

PERFORMED RECALL

PERFORMED RECALL

INSTALL DEACTIVATION SWITCH PER RECALL

ENG-225-A 3/8/99

Box_Files

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

08700 RECALL 99S15 INSTALLED UPDATED SPEED CONTROL DEACTIVATION SWITCH, CHECKS OK

REPLACED DEACTIVATION SWITCH & CONNECTOR HOUSING AS PER 99S15

99S15

REC

RECALL

99S15

1 PERFORM RECALL

RECALL ELECT CK OUT TIME AND REPL CC FLUID SW PER RECALL WF TEC300

PERFORM RECALL

RECALL 99S15 COMPLETED

PERFORMED 99S15

X REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACE KIT PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

1 PERFORMED RECALL

PERFORMED RECALL

COMPLETED RECALL PER INSTRUCTIONS

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

PERFORM RECALL 99S15

REPLACED DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORM RECALL

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

CHECK FOR RECALL, PERFORM RECALL

INSTALL SWITCH AND CONNECTOR

41188 INSTALLED NEW SPEED DEACTIVATION SWITCH TO COMPLETE RECALL 99S15

99S15 COMPLETED REPLACED SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL

RECALL PERFORM RECALL 99S15

28498 99S15 W REPLACE SPEED CONTROL SWITCH AND CONNECTOR ROAD TEST. RECOMMEND HOSE REPLACEMENT TECH NUMBER 2953 GA

PERFORMED RECALL PER BULLETIN #99S15

PERFORM RECALL

RECALL

RECALL

27388 RECALL 99S15 INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH PER INST

RECALL REPLACE DEACTIVATION SWITCH SPEED CONTROL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

PERFORMED OPEN RECALL 99S15

REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL CRUISE

SW REPLACE

RECALL REPLACE SWITCH ASY.

94004 RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

Box_Files

1 PERFORMED RECALL
 REPLACED SPEED CONTROL SWITCH PER RECALL
 RECALL COMPLETED
 SPEED CONTROL DEACTIVATION RECALL
 REPLACE SWITC AND CONNECTOR
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 126830 INSTALLED RECALL
 INTERM REPAIR REMOVED TAPE SECURE THE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15E 0 3 HRS PERMANENT REPAIR REPLACED SP EED CON
 99S15 99S15
 PERFORMED RECALL 99S15
 99264 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 RECALL 99S15 COMPLETED
 99S15 REPLACE DEACTIVATION SWITCH AND CONNECTOR
 PERFORMED RECALL
 99S15 RECALL INSTALLED MODIFICATION FOR CRUISE CONTROL
 RECALL RECALL
 JS PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
 INSTALL SWITCH
 99S15 99S15
 FACTORY RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
 99273 RECALL DONE

 RECALL 99S15 COMPLETED
 RECALL DONE
 182105 WARR REPLACED SPEED-CONTROL DEACTIVATION SWITCH
 RECALL A8DF8DAFAD8FASDFD
 REPLACED DEACT SWITCH,BLEED SYSTEM PER RECALL
 RECALL COMPLETED
 INSTALLED NEW DEACTIVATION SWITCH PER RECALL

 . -DONE 99S15
 REPLACED CRUISE DEACTIVATION SWITCH
 PERFORMED RECALL
 1 REPLACED SWITCH

 RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL
 REPLACED SWITCH AND CONNECTOR
 70746 RECALL DO RECALL 99S15
 PERFORMED RECALL 99S15
 PERFORMED RECALL
 RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15 RECALL PERFORME
 43986 PERFORMED SPEED CONTROL RECALL REPLACED THE SWITCH AND CONNECTOR
 RECALL REPLACE DECT SWITCH PER RECALL
 RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.

 INSTALL CONNECTOR AND SWITCH

Box_Files

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PERMANENT REPAIR ADMIN 10 4 90
 VERIFY RAR SPEED CONTROL HARD SHELL CONNECTOR PER RECALL
 79210 W DID RECALL 99S15
 REPLACED SPEED CONTROL SWITCH PER RECALL
 RECALL 99S15 99S15
 127778 99S15 PERFORMED RECALL
 A RECALL COMPLETE
 72140 DO RECALL 99S15. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR. BLEED BRAKE SYSTEM AND ROAD TEST. BRAKES WORK GOOD AT
 REPLACE SPEED CONTROL SWITCH PER RECALL
 RECALL 99S15 COMPLETED
 RECALL 99S15. REPLACE CRUISE CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR PER RECALL 99S15.
 107280 PERFORMED RECALL
 PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 99S15 RPL SWITCH
 REPL SPEED CONTROL CABLE 99S15
 1 COMPLETED RECALL
 RECALL 99S15 RECALL 99S15
 RECALL 99S15 RECALL 99S15
 PERFORMED RECALL 99S15
 99S15 RECALL 99S15 RR SPEED CONTROL SWITCH AS PER RECALL
 45260 RECALL WA REPLACE SWITCH AND CONNECTOR
 PERFORMED RECALL
 106385 PERFORMED RECALL-REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR-ROADTESTED VEHICLE-ALL IS OK
 RECALL COMPLETED
 RECALL RECALL
 REPLACED DEACTIVATION SWITCH AS PER RECALL
 INSTALL CRUISE CONTROL CABLE
 RECALL 99S15 REPLACED DEACTIVATION SWITCH
 RECALL REPLACED SWITCH AND CONNECTOR
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15
 RECALL REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
 RECALL 99S15
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 88716 RECALL 99S15 PERFORMED RECALL. REPLACED DEACTIVATION SWITCH AND CONNECTOR.
 RECALL RECALL
 56977 RECALL W PERFORM RECALL 99S15 GA
 REPLACE SWITCH & CONNECTOR PER RECALL
 140302 PERFORMED RECALL
 1 OK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG
 REPLACED SPEED CONTROL PER RECALL
 99S15 RECALL 99S15 RECALL
 RECALL 99S15 SPEED CONTROL RECALL PERFORMED.
 RECALL PERFORMED RECALL 99S15
 REPLACED SWITCH AS PER RECALL
 RECALL COMPLETED.
 RECALL RECALL
 RECALL PERFORMED RECALL
 G RQ 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

2002-02-01 09:42

98S15
 98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.
 TECH COMPLETED RECALL AS REQUIRED.
 1 REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 RECALL 98S15 PERFORMED RECALL
 RECALL PERFORMED 98S15 RECALL REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH
 72271 RECALL WARR REPAIR REPLACE BRAKE SWITCH PER RECALL. OLD PART TURNED INTO PARTS DEPARTMENT.
 42 98S15
 RECALL PERFORMED RECALL 98S15. C
 RECALL REPAIR
 PERFORMED RECALL
 ADD AJ INSTALL DEACTIVATION SW PER RECALL...
 98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL C
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR.
 REPLACE SPEED CONTROL CONNECTOR PER RECALL
 RECALL REPLACE CRUISE DEACT SWITCH AND CONNECTOR
 98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL C
 — PERFORMED RECALL
 COMPLETED 98S15 RECALL
 RECALL 98S15
 PER RECALL PERF RECALL

 REPLACE CRUISE CONTROL SWITCH

 REPLACED SWITCH AND CONNECTOR
 REPLACE SPEED CONTROL SWITCH
 REPLACED SWITCH

 RECALL PERFORM RECALL 98S15 SPEED CONTROL SWITCH
 RECALL RECALL

 98S15 98S15
 RECALL 98S15
 PERFORMED RECALL
 98S15 98S15
 PERFORMED RECALL 98S15
 RECALL 98S15 PERFORM AS INSTRUCTED
 PERFORM RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 101131 RECALL 98S15 CC42 W PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH.
 PERFORM RECALL
 INSTALL CRUISE DEACTIVATION SWITCH AS PER RECALL NUMBER 98S15
 24880 REPLACE SWITCH AND CONNECTOR PER RECALL
 INSPECTED AND INSTALLED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15. TECH 35-1133

 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL
 42 98S15

Box_Files

PERFORMED RECALL 99S15 99S15
1 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL
REPLACE DEACTIVATION SWITCH RECALL
REPL SWITCH #XXXX#

99S15 99S15 PERFORM RECALL
REPLACE SWITCH PER RECALL
120742 PERFORMED RECALL 99S15 SPEED CONTROL SWITCH
RECALL SPEED CONTROL REPLACE DEACTIVATION SWITCH CONECTOR
51385 CHECK AND INSPECT PERFORMED RECALL 99S15
PERFORMED RECALL
REPLACE SWITCH PER RECALL
61485 PERFORMED RECALL NO. 99S15

REPL SPEED CONTROL CABLE 99S15
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15
112673 PERFORMED 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
PERFORMED RECALL 99S15B .5 ADMIN .1
INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN
INSTALL CRUISE CONTROL DEACTIVATION SWITCH.

RECALL 99S15
FORD SAFETY RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH
REPLACED THE BRAKE PRESSURE SWITCH PER RECALL 99S15
65249 RECALL RECALL 99S15
SPEED CNTRL DEACTVTN SWITCH RPLCNTPERF SAFETY RECALL 99S15
REPLACE SWITCH
78286 RECALL 99S15 W 7923 INSTALLED DEACTIVATION SWITCH
PERFORM RECALL
128876 99S15 99S15 .5 REPLACE SWITCH & CONECTOR
SERVICE CAMPAIGNS SERVICE CAMPAIGNS REPLACED BRAKE DEACTIVATION SWITCH-THREADS CAME OUT OF JUNCT

PERFORMED RECALL
68441 RECALL 99S15 DONE DEACT SWITCH REPLACE
COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99S15B .5 + .1
PERFORM 99S15
PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL 99S15 INSTRUCTIONS
PERFORMED RECALL 99S15

RECALL 99S15 DONE
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
PERFORMED RECALL 99S15

REPLACED DEACTIVATION SWITCH
99S15 REPL DEACT SWITCH 99S15 REPLACE DEACTIVATION SWITCH PER RECALL
INSTALLED BRAKE SHIELD PER RECALL RETESTED OK. NO OTHER CONCERN AREAS EVIDENT AT THIS TIME.
136394 W REPLACE SWITCH RAT.