


- Serviceability
- Auxiliary Battery



Serviceability

-A -K -W



- SST and Service Tool
  – Following SSTs are newly adopted.

Tool	Name (Part No.)	Purpose of Use
SST	Diagnosis Cable (09893-42030) 	Wire harness for battery diagnosis
	Leak Test Tool (09893-10010) 	Airtightness check of the HV battery assembly
	Leak Test Cap (09893-42020) 	

Serviceability

-A -K -W

SST and Service Tool – Cont.

Tool	Name (Part No.)	Purpose of Use
SST	AC Leak Test Adapter HIGH (09893-10060)  AC Leak Test Adapter LOW (09893-10070) 	Airtightness check of the refrigerant line in the HV battery assembly

Auxiliary Battery


-A -K -W

- Replacement
  - Lib is provided to hook the negative side wire harness of auxiliary battery in order to improve workability.

With Lib



Negative side wire harness is fixed by the lib.



Without Lib

Negative Side Wire Harness



Negative side wire harness is annoying and the auxiliary battery is difficult to remove.