

Related Diagnostic Trouble Shooting Codes (DTC)

MY	Description	DTC
2020	Crash Event Storage Full and Locked: No Sub Type Information	B1193:00
	Driver Frontal Stage 1 Deployment Control: Circuit Open	B0001:13
	Driver Frontal Stage 1 Deployment Control: Circuit Resistance Below Threshold	B0001:1A
	Driver Frontal Stage 1 Deployment Control: Circuit Short to Battery	B0001:12
	Driver Frontal Stage 1 Deployment Control: Circuit Short to Ground	B0001:11
	Driver Frontal Stage 1 Deployment Control: Incorrect Component Installed	B0001:4A
	Driver Frontal Stage 1 Deployment Control: Signal Cross Coupled	B0001:2B
	Driver Frontal Stage 2 Deployment Control: Circuit Open	B0002:13
	Driver Frontal Stage 2 Deployment Control: Circuit Resistance Below Threshold	B0002:1A
	Driver Frontal Stage 2 Deployment Control: Circuit Short to Battery	B0002:12
	Driver Frontal Stage 2 Deployment Control: Circuit Short to Ground	B0002:11
	Driver Frontal Stage 2 Deployment Control: Incorrect Component Installed	B0002:4A
	Driver Frontal Stage 2 Deployment Control: Signal Cross Coupled	B0002:2B
	Fuel Cutoff Event: Event Information	B1492:68
	Lateral Acceleration Sensor: Event Information	C0061:68
	Longitudinal Acceleration Sensor: Event Information	C0062:68
	Roll Rate Sensor: Event Information	C0064:68
	Vertical Acceleration Sensor: Event Information	C0065:68
	Yaw Rate Sensor: Event Information	C0063:68
2021	Crash Event Storage Full and Locked: No Sub Type Information	B1193:00
	Driver Frontal Stage 1 Deployment Control: Circuit Open	B0001:13
	Driver Frontal Stage 1 Deployment Control: Circuit Resistance Below Threshold	B0001:1A
	Driver Frontal Stage 1 Deployment Control: Circuit Short to Battery	B0001:12
	Driver Frontal Stage 1 Deployment Control: Circuit Short to Ground	B0001:11
	Driver Frontal Stage 1 Deployment Control: Incorrect Component Installed	B0001:4A
	Driver Frontal Stage 1 Deployment Control: Signal Cross Coupled	B0001:2B
	Driver Frontal Stage 2 Deployment Control: Circuit Open	B0002:13
	Driver Frontal Stage 2 Deployment Control: Circuit Resistance Below Threshold	B0002:1A
	Driver Frontal Stage 2 Deployment Control: Circuit Short to Battery	B0002:12
	Driver Frontal Stage 2 Deployment Control: Circuit Short to Ground	B0002:11
	Driver Frontal Stage 2 Deployment Control: Incorrect Component Installed	B0002:4A
	Driver Frontal Stage 2 Deployment Control: Signal Cross Coupled	B0002:2B
	Fuel Cutoff Event: Event Information	B1492:68
	Lateral Acceleration Sensor: Event Information	C0061:68
	Longitudinal Acceleration Sensor: Event Information	C0062:68
	Roll Rate Sensor: Event Information	C0064:68
	Vertical Acceleration Sensor: Event Information	C0065:68
	Yaw Rate Sensor: Event Information	C0063:68