











Hybrid Powertrain Control Module 2	P1FA6	00	Current	- - -	Hybrid/EV Battery Interface Control Module 5 Not Programmed	
Hybrid Powertrain Control Module 2	P1FA7	00	Current	- - -	Hybrid/EV Battery Interface Control Module 6 Not Programmed	
Hybrid Powertrain Control Module 2	P1FA8	00	Current	- - -	Hybrid/EV Battery Interface Control Module 7 Not Programmed	
Hybrid Powertrain Control Module 2	P1FA9	00	Current	- - -	Hybrid/EV Battery Interface Control Module 8 Not Programmed	
Hybrid Powertrain Control Module 2	P1FAA	00	Current	- - -	Hybrid/EV Battery Interface Control Module 9 Not Programmed	
Hybrid Powertrain Control Module 2	P1FAB	00	Current	- - -	Hybrid/EV Battery Interface Control Module 10 Not Programmed	
Hybrid Powertrain Control Module 2	P3030	00	Current	- - -	Hybrid/EV Battery Interface Control Module 11 Not Programmed	
Hybrid Powertrain Control Module 2	P303B	00	Current	- - -	Hybrid/EV Battery Interface Control Module 12 Not Programmed	
Hybrid Powertrain Control Module 2	U0111	00	Passed and Failed	- - -	Lost Communication with Battery Energy Control Module	
Hybrid Powertrain Control Module 2	U185A	00	Passed and Failed	- - -	Lost Communication with Battery Energy Control Module on High Voltage Energy Management CAN Bus	
Hybrid Powertrain Control Module 2	U1817	00	Passed and Failed	- - -	Lost Communication with Hybrid/EV Powertrain Control Module on Bus B	
Power Steering Control Module	U0121	00	History	- - -	Lost Communication with Electronic Brake Control Module	
Parking Assist Control Module	U0422	00	History	- - -	Invalid Data Received From Body Control Module	