



THE FUNCTION AND AMPERAGE
OF THESE FUSES ARE
DEPENDENT ON THE
EQUIPMENT
EQUIPPED
CUSTOMER SELECTABLE
FUSE
200 AMP FUSE MAY BE
SUBSTITUTED

CIRCUIT BREAKERS
DRIVER POWER
SEAT


AC PASS POWER
SEAT 233

NOT POPULATED

RELAYS
K1 NOT POPULATED
K2 ASD
K3 NOT POPULATED
K4 FRT BLOWER MOTOR
K5 NOT POPULATED
K6 NOT POPULATED
K7 NOT POPULATED
K8 RR BLOWER MOTOR
K9 RUN-START
K10 RR DEFOG
K11 NOT POPULATED
K12 RUN-ACCESSORY #1
K13 RUN #2

F13 NOT POPULATED
F14 MEDIA HUB/
PWR LUNAR
F15 CBC/PWR LOCKS
F16 ECU
F17 NOT POPULATED
F18 CBC/EXT LIGHTS
F19 NOT POPULATED
F20 LOW TEMP PASSIVE
PUMP
F21 PIM PWR PNL MOTOR
F22 NOT POPULATED
F23 NOT POPULATED
F24 RR WIPER
F25 HANDS FREE OR MOD/
RMS/ ACTIVE GRILL
SHUTTER
F26 FRT BLOWER MOTOR
F27 RR SLIDE OR MOD
- RT
F28 DIAGNOSTIC PORT/USB
C/P/VIDEO USB PORT
F29 NOT POPULATED
F30 ECU/PWR INJECT MOD
F31 3 & 4 WAY VALVES
F32 ECU
F33 POWER LIFTGATE
F34 RR DOOR MOD -LT
F35 SUNROOF CONTROL MOD

F36 NOT POPULATED
F37 CBC/EXT LIGHTS/PCN
F38 NOT POPULATED
F39 RR BLOWER MOTOR
F40 FMS OIL PUMP
F41 NOT POPULATED
F42 NOT POPULATED
F43 FUEL PUMP MOTOR
F44 CBC/INT LIGHTS
F45 PWR INVERTER AC
F46 DRIVER DOOR AC
F47 PWS ODOM MOD
F48 ECU MOTOR
F49 RR SLIDE OR MOD-LT
F50 RR DOOR MOD - RT
F51 FRONT WIPER
F52 NOT POPULATED
F53 ESC-ECU & VALVES
F54 RR HUB/KIN/ESL/DND
VRM
F55 FRT & RR HUB CTRL
F56 DCM/ESL/ESP/ESC
F57 PIM-MAIN PWR SUPPLY
F58 NOT POPULATED
F59 NOT POPULATED
F60 RR CARGO PWR OUTLET
F61 NOT POPULATED
F62 PIM-MAIN PWR SUPPLY
F63 HV ELECT COOLANT
HTR ENABLE
F64 NOT POPULATED
F65 NOT POPULATED
F66 CLUSTER
F67 DASH/PARKTRONIC/HALF
F68 NOT POPULATED
F69 BCM
F70 EAC
F71 HORN
F72 NOT POPULATED
F73 RR DEFOG
F74 NOT POPULATED
F75 OVERHEAD CONSOLE
RR CENTER STACK
F76 UCONNECT/CENTER
DISPLAY/TELEMATICS
F77 RR ENTERTAINMENT
MEDIA HUB/USB/S
RAIN SENSOR/SUNROOF
RR VIEW MIRROR
F78 TCM 2F/E-SHIFTER/
CLUSTER
F79 JCS/HMC/EPB SM
STRG COLUMN CTRL
F80 BCM
F81 APN
F82 NOT POPULATED
F83 TRANS OIL PUMP 1
F84 NOT POPULATED
F85 CIGAR LIGHTER
F86 NOT POPULATED
F87 NOT POPULATED
F88 FRT HEATED SEATS
F89 RR HEATED SEATS
F90 EBCM-ECU
F91 FRT VENT SEATS/
HTD STR WHEEL
F92 SECURITY GATEWAY
F93 NOT POPULATED
F94 ESC-MOTOR PUMP
F95A USB IP (RUN-ACC)
F95B USB IP (DIRECT B-)
F96 AIRBAG
F97 AIRBAG
F98 NOT POPULATED
F99 NOT POPULATED
F100 AUTO HEADLAMP LEVEL/
RR CAMERA/BLINDSPOT
CUP/HUMIDITY SNR
IN CAR TEMP SNR



6351-3560 REV002

6351-4288/001

11/06/2019 12:31