

[illegible]

SGW	Security Gateway Module	CAN-C				

ECU SUMMARY INFO (CONT...)

ECU	COUNTRY CODE	HARDWARE VERSION	SOFTWARE VERSION	IDENT	SERIAL NUMBER	CVNS
TCM	USA / USA					
PCM	USA					
ICS	USA					
RFH	USA / USA					
ESM	USA					
DTCM	USA					
ORC	USA					
EPS	USA					
HVAC	USA					
PTCM	USA					
AMP	USA					
IPC	USA					
SCCM	USA					
RADIO	USA					
OCM	USA					
BPCM	Rest of world / ROW					
HCP	USA					
AHCP	USA					
ABSO	USA					
SGW						
DPDM	USA					

DTC SUMMARY

ECU	DTC CODE	DTC DESCRIPTION	STATUS
TCM			Stored
TCM			Stored
DTCM			Stored
RADIO			Stored
BPCM			Stored
HCP			Active
ABSO			Stored
ABSO			Stored

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. § 552 (B) (6)

ENVIRONMENTAL DATA SUMMARY

TCM | [REDACTED]

NAME	VALUE	UNITS
DTC	[REDACTED]	
Test Failed	[REDACTED]	
Test Failed This Operation Cycle	[REDACTED]	
Pending DTC	[REDACTED]	
Confirmed DTC	[REDACTED]	
Test Not Completed Since Last Clear	[REDACTED]	
Test Failed Since Last Clear	[REDACTED]	
Test Not Completed This Operation Cycle	[REDACTED]	
Warning Indicator Requested	[REDACTED]	
DTC Extended Data Record Number - All	[REDACTED]	
Occurrence flag	[REDACTED]	
Original Odometer Value	[REDACTED]	miles
Most Recent Odometer Value	[REDACTED]	miles
Frequency Counter	[REDACTED]	
Ignition Cycle Counter	[REDACTED]	

TCM | [REDACTED]

NAME	VALUE	UNITS
DTC	[REDACTED]	
Test Failed	[REDACTED]	
Test Failed This Operation Cycle	[REDACTED]	
Pending DTC	[REDACTED]	
Confirmed DTC	[REDACTED]	
Test Not Completed Since Last Clear	[REDACTED]	
Test Failed Since Last Clear	[REDACTED]	
Test Not Completed This Operation Cycle	[REDACTED]	
Warning Indicator Requested	[REDACTED]	
DTC Extended Data Record Number - All	[REDACTED]	
Occurrence flag	[REDACTED]	
Original Odometer Value	[REDACTED]	miles
Most Recent Odometer Value	[REDACTED]	miles
Frequency Counter	[REDACTED]	
Ignition Cycle Counter	0	

DTCM | [REDACTED]

NAME	VALUE	UNITS
DTC	[REDACTED]	
Test Failed	[REDACTED]	
Test Failed This Operation Cycle	[REDACTED]	
Pending DTC	[REDACTED]	

Confirmed DTC	
Test Not Completed Since Last Clear	
Test Failed Since Last Clear	
Test Not Completed This Operation Cycle	
Warning Indicator Requested	
DTC Extended Data Record Number - All	
Occurrence flag	
Original Odometer Value	miles
Most Recent Odometer Value	miles
Frequency Counter	
Ignition Cycle Counter	
System Battery Voltage	Volts
Module Battery Voltage	Volts
Transference motor position sensor supply voltage	Volts
Transference Motor Current	Amps
Transference Position Sensor	Volts
DTCM Temperature	°F
Transference Motor Duty Cycle	%
Transference Motor Direction State	
Front Axle Locker Sensor Feedback	
Rear Axle Locker Sensor Feedback	
Front Axle Locker Low side Driver	
Rear Axle Locker Low side Driver	
FAD Supply Power Voltage	Volts
FAD Feedback Status	
FAD Feedback Voltage	Volts
FAD Lock request	
Transference Mode Switch	
Time Since Last Ignition On	minutes
Vehicle Speed	MPH
Left Front Wheel Speed	rpm
Right Front Wheel Speed	rpm
Left Rear Wheel Speed	rpm
Right Rear Wheel Speed	rpm
Brake Pedal	
ESP Requested Center (Transference) Differential State	
ESP Requested Center Differential Torque	Ft-Lbs
Steering Wheel Angle	degrees
Delta Steering Wheel Angle	degrees
Ambient Air Temperature	°F
PRNDL Display	
Transmission Current Gear	
Throttle Pedal Position	%
Static Engine/Electric Motor Torque	Ft-Lbs

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)

Engine RPM		rpm
Actual Mode of Transference Clutch		
Actual Transference Clutch Lock Torque		Ft-Lbs
Desired Transference Clutch Lock Torque		Ft-Lbs
T-Case Motor Incremental Position Sensor (IPS)		degrees
T-Case Clutch Wear IPS Position		degrees
PTCM Internal DTC Reason		
Transfer Case Shift Inhibited		
Transfer Case Status		
Axle Locker Status (Bus)		
Clutch Calibration Not Learned reason		
Electric Motor RPM		rpm
T-Case Clutch Wear Position (Initial)		degrees

RADIO |

NAME	VALUE	UNITS
DTCTable		
TestFailed		
TestFailedThisMonitoringCycle		
Pending DTC		
Confirmed DTC		
Test Not Completed This Monitoring Cycle		
Warning Indicator Requested		
DTCExtendedDataRecordNumber		
Occurance Flag		
Reserved		
Original Odometer Value		miles
Most Recent Odometer Value		miles
Frequency Counter		
Ignition Counter		
RDI \$6080		
Event Counter		

BPCM |

NAME	VALUE	UNITS
DTC		
Test Failed		
Test Failed This Operation Cycle		
Pending DTC		
Confirmed DTC		
Test Not Completed Since Last Clear		
Test Failed Since Last Clear		
Test Not Completed This Operation Cycle		
Warning Indicator Requested		

Occurrence flag	
Original Odometer Value	miles
Most Recent Odometer Value	miles
Frequency Counter	
Ignition Cycle Counter	
FoM - for this DTC (lifetime fails)	events
FoM - for this DTC (lifetime fails counts on pass)	seconds
FoM - for this DTC (lifetime longest fail on pass)	seconds
Battery Total Time Awake	seconds
Key in Ignition	
EPT -WakeUp	
HCP Contactor Command	
Contactor Status	
Plug in Status	
Balance Mode	
Vehicle Speed	MPH
System (12) Volts at time of fault	Volts
Battery Lifetime AmpHrs of Charge	AHr
Battery Lifetime AmpHrs of DisCharge	AHr
HVIL Status -Vehicle	
Cycles left to self heal	No Unit
HV Battery Charge Power 2sec	watts
HV Battery Charge Power 10sec	watts
HV Battery Discharge Power 2sec	watts
HV Battery Discharge Power 10sec	watts
Key - DriveRdy (CAN)	
Battery Lifetime Number Of Closes	
Battery Full AmpHr Capacity	AmpHrs
Battery Cell Voltage Maximum	mV
Battery Cell Voltage Minimum	mV
Battery Cell Voltage Average	mV
Battery Temperature Maximum Module	°F
Battery Temperature Minimum Module	°F
Battery Temperature Average Module	°F
DTC Extended Data Record Number - All	
DTC Extended Data Record Number - 2	
HV Battery Charge Power 30sec	watts
HV Battery Discharge Power 30sec	watts
Key Position	
SOC	%
HV Bat SOH-R	%
HV Bat SOH-C	%
Cell Impedance Max Discharge	mOhms
Cell Impedance Min Discharge	mOhms

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)

HVIL Status - Battery pack	
HVIL PWM Duty Cycle source - Vehicle	%
HVIL PWM Duty Cycle Source - Battery	%
HVIL PWM Duty Cycle Sink - Battery	%
HVIL PWM Frequency source - Vehicle	Hz
HVIL PWM Frequency Sink - Vehicle	Hz
HVIL PWM Frequency Source - Battery	Hz
HVIL PWM Frequency Sink - Battery	Hz
HVIL Returned current - Vehicle	mA
HVIL Returned current - Battery	mA
Battery Cell Highest Cell number	
Battery Cell Lowest Cell number	
HV Battery Current Sensor Primary	Amps
HV Battery Current Sensor Secondary	Amps
HV Battery Current HVBatCmt	Amps
HV Battery Voltage (cell sum)	Volts
HV Battery Voltage (Module Sum)	Volts
Battery Temperature Highest Sensor number	
Battery Temperature Lowest Sensor number	
HV Cooling Battery coolant inlet temp	°F
HV Cooling Battery coolant outlet temp	°F
BPCM temperature max	°F
BPCM temperature min	°F
Vehicle Isolation Impedance (Positive side)	Mega Ohms
Vehicle Isolation Impedance (Negative side)	Mega Ohms
Vehicle Isolation Impedance (Equivalent)	Mega Ohms
Battery Isolation Impedance (Positive side)	Mega Ohms
Battery Isolation Impedance (Negative side)	Mega Ohms
Battery Isolation Impedance (Equivalent)	Mega Ohms
Engine Speed	rpm
Accelerator position	%
GPS_Date - Year	Year
GPS_Date - Month	
GPS_Date - Day	Days
UTC_Time - Hours	Hours
UTC_Time - Minutes	
UTC_Time - Seconds	seconds
HCP - System Shutdown Command (CAN)	
HCP - ePT LOC Diagnostics Enable (CAN)	
HCP - Propulsion system active (CAN)	

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)

Qualified Contactor Command - QCC	
Verified Contactor Command - VCC	
HVIL PWM Duty Cycle sink - Vehicle	%
HV Sensor- Pack Voltage (U BAT P - U BAT M)	Volts
HV Sensor - DC Link Voltage (U DC LINK)	Volts
HV Sensor - main fuse Voltage (U MAIN P - U MAIN M) - U DC LINK	Volts
BPCM Fuse Voltage (U MAIN P - U AUX FUSE)	Volts
APM Fuse Voltage (U MAIN P - U AUX REL)	Volts
HV Sensor - Battery Voltage - Positive contactor (U BAT P)	Volts
HV Sensor - Battery Voltage - Negative contactor (U BAT M)	Volts
HV Sensor - Weld Contactor Voltage - Positive contactor (U MAIN P)	Volts
HV Sensor - Weld Contactor Voltage - Negative contactor (U MAIN M)	Volts
HV Sensor - U AUX FUSE	Volts
HV Battery Total Amp Hour Capacity (CAN)	AHr
HV Battery - Pack Isolation state (CAN)	
HV Battery - Powertrain Isolation state (CAN)	
HV Sensor - Pack Voltage VALIDITY (CAN)	
HV Battery Current HVBatCrnt VALIDITY (CAN)	
HV Battery Total Amp Hour Capacity VALIDITY (CAN)	
BPCM - MCU Reset Counter	
BPCM - RAM Reset Counter	
BPCM - ROM Reset Counter	
BPCM - Safety Mechanism (TSR) Reset Counter	
BPCM - Hall current sensor supply voltage (5VQT1)	Volts
BPCM - Precharge Penalty Timer (CAN)	seconds
BPCM - RTC Circuit Status	
BPCM - HVBat Sleep Time	seconds
BPCM - System Mode	No Unit
BPCM - HV Battery pack contactor request (CAN)	
BPCM - HV Battery Pack contactor Open (CAN)	
BPCM - HV Battery pack Contactor welded and impeded opening (CAN)	
BPCM - Crash Indication (CAN)	
BPCM - Crash Indication VALIDITY (CAN)	
BPCM - Retention Status	
BPCM - Active weld check type	
BPCM - Current Category of Wearout Counter	
HV Contactor State - Positive Contactor	
HV Contactor State - Negative Contactor	
HV Contactor State - Precharge Contactor	
CSC Fault - Cn Pin Open	
CSC Fault - Cn Short to SWn	
CSC Fault - Auxiliary channel 1 Pin Open	
CSC Fault - Auxiliary channel 2 Pin Open	
CSC Fault - Measured result difference between Alternative path and Primary path is out of range	

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)

CSC Fault - Balancing Switch Short
 CSC Fault - Balancing Switch Open
 CSC Fault - Alternate reference voltage is out of range
 CSC Fault - Vaa voltage is out of range
 CSC Fault - Level-shift amplifier offset voltage is out of range
 CSC Fault - Stuck ADC output bits verification with zero-scale
 CSC Fault - Stuck ADC output bits verification with full-scale
 CSC Fault - Multiplexer Open/Short verification with single HVMUX test current source
 CSC Fault - Multiplexer Open/Short verification with both HVMUX test current sources
 CSC Fault - Measured result difference between Module voltage and Cell voltage summation
 CSC Fault - $V_{hv} < V_{hvuv}$
 CSC Fault - $V_{hv} - V_{dcn} > V_{hvov}$
 CSC Fault - Die Temperature is over the upper limit
 CSC Fault - Scanning for cell information is not complete
 CSC Fault - ADC Data Path error
 CSC Fault - Packet Error Check
 CSC Fault - Power-on reset event occurred
 CSC Fault - 32kHz oscillator frequency is not within +/-5% of its expected value
 CSC Fault - Same as Alrtosc1 (redundant alert)
 CSC Fault - Die Temperature is over the upper limit
 CSC Fault - Module number addressing is fail
 CSC Fault - Alive counter is not matched to the expected value
 CSC Fault - PEC Bits in Data-check byte error
 CSC Fault - $V_{hv} - V_{12}$ is too low
 CSC Fault - Transmit data is not equal to read back data
 CSC Diagnostics - Initialization Status
 CSC Diagnostics - CSC #01 Status
 CSC Diagnostics - CSC #02 Status
 CSC Diagnostics - CSC #03 Status
 CSC Diagnostics - CSC #04 Status
 CSC Diagnostics - CSC #05 Status
 CSC Diagnostics - CSC #06 Status
 CSC Diagnostics - CSC #07 Status
 CSC Diagnostics - CSC #08 Status
 CSC Diagnostics - AFE Internal Operation Mode

HCP |

NAME	VALUE	UNITS
DTC		
Test Failed		
Test Failed This Operation Cycle		
Pending DTC		
Confirmed DTC		

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)

Test Not Completed Since Last Clear	
Test Failed Since Last Clear	
Test Not Completed This Operation Cycle	
Warning Indicator Requested	
DTC Extended Data Record Number	
Occurrence flag	
Original Odometer Value	miles
Most Recent Odometer Value	miles
Frequency Counter	
Ignition Cycle Counter	
Microcontroller reset reason - Core 0	
Microcontroller reset reason - Core 1	
Real time clock	sec
RAM stamps keyOn	sec
RAM Stamps	Min
Accelerator Pedal Position	%
Engine Coolant Temperature	°F
Engine Speed	rpm
Vehicle Speed	MPH
HV Battery SOC	%
Brake Switch Status	
Battery Feed Voltage 1 Sense	Volts
Battery Feed Voltage 2 Sense	Volts
Battery Feed Voltage 3 Sense	Volts
Internal EPS Voltage Sense A	Volts
Internal EPS Voltage Sense B	Volts
Hybrid System State	
Outside Air Temperature	°F
Ignition State	
Propulsion System Active	
HV Contactor Status	
APM Status	
Impact Event	
PRND Position Display	
Distance Travelled with Light ON	miles
HV Battery Sleep Time	Days
eMotor A Shutdown History [0]	
eMotor A Shutdown History [1]	
eMotor A Shutdown History [2]	
eMotor A Fault History [0]	
eMotor A Fault History [1]	
eMotor A Fault History [2]	
eMotor A Fault History [3]	
eMotor A Fault History [4]	

eMotor A Fault History [5]
eMotor B Shutdown History [0]
eMotor B Shutdown History [1]
eMotor B Shutdown History [2]
eMotor B Fault History [0]
eMotor B Fault History [1]
eMotor B Fault History [2]
eMotor B Fault History [3]
eMotor B Fault History [4]
eMotor B Fault History [5]
eMotor A FA Speed or Position Fault Active
eMotor A FA Motor Temperature Fault Active
eMotor A FA inverter Temperature A Fault Active
eMotor A FA inverter Temperature B Fault Active
eMotor A FA inverter Temperature C Fault Active
eMotor A FA DC Current Fault Active
eMotor A FA DC Voltage Fault Active
eMotor A FA Acceleration Fault Active
eMotor A FA Rotor Temperature Fault Active
eMotor A FA Capacitor Temperature Fault active
eMotor A FA Current Sensor A Fault Active
eMotor A FA Current Sensor B Fault Active
eMotor A FA Current Sensor C Fault Active
eMotor A FA Postion Sensor Fault Active
eMotor A FA DC Voltage Out of Range Fault Active
eMotor A FA Reserved
eMotor B FA Speed or Position Fault Active
eMotor B FA Motor Temperature Fault Active
eMotor B FA Inverter Temperature A Fault Active
eMotor B FA Inverter Temperature B Fault Active
eMotor B FA Inverter Temperature C Fault Active
eMotor B FA HV input Current Fault Active
eMotor B FA HV Input Voltage Fault Active
eMotor B FA Acceleration Fault Active
eMotor B FA Rotor Temperature Fault Active
eMotor B FA Capacitor Temperature Fault Active
eMotor B FA Current Sensor A Fault Active
eMotor B FA Current Sensor B Fault Active
eMotor B FA Current Sensor C Fault Active
eMotor B FA Position Sensor Fault Active
eMotor B FA DC Voltage Out of Range Fault Active
eMotor B FA Reserved
eMotor A Current Ia Max
eMotor A Current Ia Min

eMotor A Current Ib Max
eMotor A Current Ib Min
eMotor A Current Ic Max
eMotor A Current Ic Min
eMotor A Current Id Max
eMotor A Current Id Min
eMotor A Current Iq Max
eMotor A Current Iq Min
eMotor A Current Sum Max
eMotor A Current Sum Min
eMotor A HV Input voltage Max
eMotor A HV Input Voltage Min
eMotor A speed max mrads
eMotor A speed min mrads
eMotor B Current Ia Max
eMotor B Current Ia Min
eMotor B Current Ib Max
eMotor B Current Ib Min
eMotor B Current Ic Max
eMotor B Current Ic Min
eMotor B Current Id Max
eMotor B Current Id Min
eMotor B Current Iq Max
eMotor B Current Iq Min
eMotor B current Sum Max
eMotor B current sum Min
eMotor B HV Input Voltage Max
eMotor B HV Input Voltage Min
eMotor B speed Max mrads
eMotor B speed Min mrads
eMotor A Current Ia Offset
eMotor A Current Ib Offset
eMotor A Current Ic Offset
eMotor B Current Ia Offset
eMotor B Current Ib Offset
eMotor B Current Ic Offset
eMotor A HV Battery Voltages
eMotor A HV input Voltages
eMotor B HV Battery Voltages
eMotor B HV input Voltages
eMotor A Motoring Torque Limit
eMotor A Regenerative Torque Limit
eMotor B Motoring Torque Limit
eMotor B Regenerative Torque Limit

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)

eMotor A Torque command		Ft-Lbs
eMotor A Torque achieved		Ft-Lbs
eMotor A speed RPM		rpm
eMotor B Torque command		Ft-Lbs
eMotor B Torque achieved		Ft-Lbs
eMotor B Speed RPM		rpm
eMotor A Temperature Stator		°F
eMotor A Temperature Inverter Model		°F
eMotor A Temperature Inverter 0		°F
eMotor A Temperature Inverter 1		°F
eMotor A Temperature Inverter 2		°F
eMotor A Temperature Coolant Inlet		°F
eMotor A Temperature Coolant Outlet		°F
eMotor A Temperature PCB		°F
eMotor A Temperature Rotor		°F
eMotor A OS Runtime Seconds		sec
eMotor B OS Runtime Seconds		sec
eMotor B Temperature Stator		°F
eMotor B Temperature Inverter Model		°F
eMotor B Temperature Inverter 0		°F
eMotor B Temperature Inverter 1		°F
eMotor B Temperature Inverter 2		°F
eMotor B Temperature coolant Inlet		°F
eMotor B Temperature coolant outlet		°F
eMotor B Temperature PCB		°F
eMotor B Temperature Rotor		°F
eMotor A Lifetime Over Current w/o Over Voltage Events		
eMotor A Lifetime Over Current Events		
eMotor A Lifetime Over Voltage Events		
eMotor A Lifetime Max Voltage		Volts
eMotor A Lifetime Max Phase Current		
eMotor A Lifetime General Retry Events		
eMotor A Key Cycle Max Voltage		Volts
eMotor A Key Cycle Max phase Current		
eMotor A Key Cycle General Retry Events		
eMotor B Lifetime Over Current w/o Over Voltage Events		
eMotor B Lifetime Over Current Events		
eMotor B Lifetime Over Voltage Events		
eMotor B Lifetime Max Voltage		Volts
eMotor B Lifetime Max Phase Current		
eMotor B Lifetime General retry Events		
eMotor B key Cycle max Voltage		Volts
eMotor B key Cycle max Phase Current		
eMotor B key Cycle General Retry Events		

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)

eMotor A MTMR Fault Word		
eMotor B MTMR Fault Word		
GPS Date - Year		Year
GPS Date - Month		
GPS Date - Day		Days
UTC Time - Hours		Hours
UTC Time - Minutes		
UTC Time - Seconds		seconds
ECU Time - Milliseconds		ms

ABSO |

NAME	VALUE	UNITS
DTC		
Test Failed		
Test Failed This Operation Cycle		
Pending DTC		
Confirmed DTC		
Test Not Completed Since Last Clear		
Test Failed Since Last Clear		
Test Not Completed This Operation Cycle		
Warning Indicator Requested		
Occurrence flag		
Controller Event		
Mirror Memory		
Undervoltage Suspected		
Original Odometer Value		miles
Most Recent Odometer Value		miles
Frequency Counter		
Ignition Cycle Counter		
Fault Time		S
Current System Mode		
Previous System Mode		
Wheel Speed Left Front		MPH
Rotation Direction Left Front		
Wheel Speed Right Front		MPH
Rotation Direction Right Front		
Wheel Speed Left Rear		MPH
Rotation Direction Left Rear		
Wheel Speed Right Rear		MPH
Rotation Direction Right Rear		
Steering Wheel Angle		°
Longitudinal Acceleration		m/s^2
Yaw Rate		°/s
Supplier Internal Code		

ABSO |

NAME	VALUE	UNITS
DTC		
Test Failed		
Test Failed This Operation Cycle		
Pending DTC		
Confirmed DTC		
Test Not Completed Since Last Clear		
Test Failed Since Last Clear		
Test Not Completed This Operation Cycle		
Warning Indicator Requested		
Occurrence flag		
Controller Event		
Mirror Memory		
Undervoltage Suspected		
Original Odometer Value		miles
Most Recent Odometer Value		miles
Frequency Counter		
Ignition Cycle Counter		
Fault Time		S
Current System Mode		
Previous System Mode		
Wheel Speed Left Front		MPH
Rotation Direction Left Front		
Wheel Speed Right Front		MPH
Rotation Direction Right Front		
Wheel Speed Left Rear		MPH
Rotation Direction Left Rear		
Wheel Speed Right Rear		MPH
Rotation Direction Right Rear		
Steering Wheel Angle		°
Longitudinal Acceleration		m/s ²
Yaw Rate		°/s
Supplier Internal Code		

SNAPSHOT DATA SUMMARY

No Snapshot Data available for

No Snapshot Data available for

No Snapshot Data available for

No Snapshot Data available for

No Snapshot Data available for

No Snapshot Data available for

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)

No Snapshot Data available for [REDACTED]

No Snapshot Data available for [REDACTED]

INFORMATION REDACTED PURSUANT TO THE FREEDOM OF INFORMATION ACT (FOIA), 5 U.S.C. 552 (B) (6)