

September 3, 2015

02374 Version 1

Noncompliance Recall: 2003 Odyssey Front Passenger Airbag

AFFECTED VEHICLES

Year	Model	Trim	VIN Range
2003	Odyssey	ALL	Check the iN VIN statues for eligibility

BACKGROUND

During manufacturing, an incorrect airbag was installed that did not meet the advanced airbag specification for the 2003 model year.

A very small number of vehicles are affected by this noncompliance recall.

CUSTOMER NOTIFICATION

Owners of affected vehicles will be sent a notification of this campaign.

Do an iN VIN status inquiry to make sure the vehicle is shown as eligible.

Some vehicles affected by this campaign may be in your used inventory. Repair these vehicles before they are sold.

Should your dealership sell an unrepaired vehicle that subsequently causes injury or damage because of the recalled item, the dealership will be solely responsible to the damaged party, and will be required to defend and indemnify American Honda for any resulting claims. To see if a vehicle in inventory is affected by this recall, do a VIN status inquiry before selling it.

CORRECTIVE ACTION

Replace the front passenger's airbag module, then remove the airbag inflator from the old assembly and return it to Takata.

NOTE: If the customer wants their original airbag cover, transfer the customer's cover onto the new airbag assembly.

PARTS INFORMATION

Part Name	Part Number	Quantity
Front Passenger's Airbag Module	06780-S0X-A70ZA	1
Inflator Return Box and Shipping Labels	See Ordering Instructions Below	1

To order an inflator return box and shipping labels, contact Armando Gonzalez by either calling him at (210) 250-5079 or emailing him at FieldAction.14305@menloworldwide.com.

Make sure you provide the following information when you contact Menlo:

- Dealership contact name
- Dealer address
- Dealer phone number
- Affected VIN and customer name

CUSTOMER INFORMATION: The information in this bulletin is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely maintain your vehicle. These procedures should not be attempted by "do-it-yourselfers," and you should not assume this bulletin applies to your vehicle, or that your vehicle has the condition described. To determine whether this information applies, contact an authorized Honda automobile dealer.

WARRANTY CLAIM INFORMATION

Operation Number	Description	Flat Rate Time	Template ID	Defect Code	Symptom Code	Failed Part Number
7541B8	Replace the front passenger's airbag module. Includes transferring the original cover to the new airbag if the customer wants the original cover.	0.6 hr	15-061A	5ZN00	JU000	06780-S0X-A70ZA

Skill Level: Repair Technician

REPAIR PROCEDURE

NOTE:


- Make sure you have the anti-theft code for the audio and navigation system (if applicable), then write down the frequencies for the audio unit's preset buttons.
 - Be careful not to damage any parts when replacing the airbag module, and **follow the procedure exactly**.
 - If, before removing the airbag module, you suspect that it may be a counterfeit or otherwise suspect, **do not remove the airbag module**. Contact your DPSM for assistance.
 - Make sure you have reviewed the SRS Precautions and Procedures in the service repair information before doing the REPAIR PROCEDURE.
1. Turn the ignition switch to the ON (II) position and check if the SRS indicator comes on for about 6 seconds, then goes off.
 - If the indicator comes on, then goes off after about 6 seconds, go to step 2.
 - If the indicator does not come on, or if it stays on, contact your DPSM for assistance.
 2. Disconnect the battery negative cable and wait at least 3 minutes before continuing.
 3. Remove the front passenger's airbag module. Refer to the service information.
 4. Place the airbag module, face down, on a clean shop towel.

NOTE: If you need to transfer the original cover onto the new airbag module, the orientation of the airbag is critical because if the airbag is installed incorrectly, the harness will be too short when you reinstall the airbag module.


5. Visually inspect the airbag and the inflator for any unusual writing or markings.

- If there is nothing unusual about the airbag or the inflator, go to step 6.
- If there are any unusual markings, like an incorrect label or a model year written in marker, the airbag and inflator may be a counterfeit part. For more information about counterfeit airbags, you can refer to safercar.gov, enter keywords **MANAGING COUNTERFEIT**, and select **Recommended Dealer Guidance for Managing Counterfeit Air Bags** from the list. **If you suspect that the airbag or inflator is counterfeit, do not continue this procedure.** Contact your DPSM for assistance.

NON-STANDARD SAFETY LABEL




GREASE PENCIL OR PAINT MARKINGS




HAND ENGRAVING



NO LABELS ON INFLATOR




6. Remove the harness from both ends of the inflator brackets.




7. Short the red wires.

NOTE: **You must cut and short the wires** as indicated to prevent accidental deployment.


- Cut the red wires as shown.



- Cut about 2 inches of the corrugated tube, then pull out the two red wires.



- Strip away about 1 inch of the wire insulation, then twist the wires together.




- Tape the twisted ends with electrical tape.


- Cut off the connector and short the yellow wires.

NOTE: **You must cut and short the wires** as indicated to prevent accidental deployment.


- Cut all four wires to remove the connector.



- Cut about 2 inches of the corrugated tube, then pull out the yellow wires.




- Strip away about an inch of the wire insulation, then twist the wire ends together.




- Tape the twisted ends with electrical tape.

- Remove the four inflator nuts.




10. Remove the inflator bracket.

NOTE: You can only remove one of the brackets, as the other is welded to the airbag housing.




11. Remove the inflator by pushing it out.



12. Put the original inflator in the empty inflator box that you ordered from Menlo. Make sure there is no other hardware in the box because if the package rattles, it will not be accepted by the courier.

13. **If the customer wants their original airbag cover, do the following;** otherwise, go to step 14.

- Using an applicable tool, gently pry open the original airbag cover as shown so that the hooks can be removed from the slots, then separate the original airbag from the original airbag cover.



- Separate the new airbag from the new airbag cover.
 - Install the new airbag into the original airbag cover.
14. Install the new airbag assembly into the vehicle and torque the new locknuts to **9.8 N•m (7.2 lb-ft)**. Refer to the service information.
15. Reconnect the battery negative cable and enter the anti-theft code for the audio and navigation system (if applicable), then enter the audio unit presets.
16. Turn the ignition to the ON (II) position and make sure the SRS indicator comes on for about 6 seconds, then goes off.
17. Return the airbag inflator. Follow the shipping instructions outlined in PIB A15-0002, *Inflator Kit Return Process* to return the undeployed inflator.

END