

ISO/TS16949 REGISTERED
TB-059 • August 2015

How do I identify if I have an Ultra LT Fifth Wheel?


Method 1: Identify the Model Number

Model number location



Method 2: Provide the serial number to Fontaine Fifth Wheel at 844-597-7393 or ultraltrecall@fifthwheel.com and someone will be able to tell you if you have an Ultra LT fifth wheel.

Location of 9 Digit Serial Number



Serial number engraved directly into the right side of fifth wheel skirt. Note: position 5 and 6 of the serial number indicates the year built. Serial number is always 9 digits.

If the model number identified using method 1 is on this list, you have an Ultra LT Fifth Wheel.

Ultra LT Model Numbers

AA4LWO675012
AA4LWO775012
AA4LWO875012
AATPL4000
SL4APB6250
SL4APB7250
SL4APB8250
SL4LWI675012
SL4LWI775024
SL4LWO675012
SL4LWO675016
SL4LWO675024
SL4LWO675036
SL4LWO775012
SL4LWO775016
SL4LWO775024
SL4LWO775036
SL4LWO875012
SL4LWO875016
SL4LWO875024
SL4LWO875036
SL4SMB6875
SL4SMB7875
SR4LWO675012
SLTPL4000
SRTPL4000