

**December 2, 2017**

07740 Version 2

## Safety Recall: Outer Second Row Seats Tip During Braking

Supersedes 17-097, dated November 18, 2017 to revise the information highlighted in **yellow**

### AFFECTED VEHICLES

Year	Model	Trim	VIN Range
2011–17	Odyssey	ALL	Check the iN VIN status for eligibility

### REVISION SUMMARY

A video is now available to illustrate the proper latching procedure.

### BACKGROUND

The second row outboard (outer) seats can be placed in two positions, standard or wide. The rear outboard strikers have a collar to define the two set positions. If a second row outer seat is positioned over the collar while latching the seat to the floor, the seat will not properly latch. An unlatched second row outer seat may tip forward during moderate to heavy braking, increasing the risk of injury to an occupant, including a child seated in a LATCH (Lower Anchor and Tethers for Children) installed child seat.

**This bulletin will be revised in the future once the repair procedure, parts information, and warranty claim information are available.**

For customer convenience, there is a PDF demonstrating the proper latching procedure at [recalls.honda.com](http://recalls.honda.com).


**Additionally, there is a video illustrating these instructions. You can view the video by clicking [here](#).**

**Whenever an affected Odyssey comes into your dealership for service, follow these instructions to properly position the second row outer seats and confirm they are securely latched to the floor.**


### Second Row Outer Seat Positions

The two second row outer seats can be installed in two positions, standard and wide:

The second row center seat has only a single seat position.



**STANDARD POSITION**



**WIDE POSITION**

In the standard position, the seats are located inward for:


- Easier access to the third row
- Maximizing second row outer seat passenger headroom

In the wide position, the seats are located outward for:


- Installation of three car seats in the second row
- Additional hip and shoulder room for passengers in the second row seats

## Latching the Second Row Outer Seats

Follow these steps when installing or repositioning the second row outer seats, and check that the second row seats are secure to help assure passenger safety. Follow the steps below every time the rear seat latches have been released from the floor.




1. Insert the front seat hooks into the front floor strikers.




2. Slide the seat into either the standard or wide position:
  - Pull the seat out to the wide position, or push the seat into the standard position until it stops (identified in green).
  - **Do not position the seat hooks in the middle of the striker.** The seat will not lock into position (identified in red).

*Driver's Side Shown*




3. Lower the rear of the seat. There is both a rib on the floor and a collar on the rear metal striker. Check that the rear latch and damper are inside or outside of the rib and collar (identified by the green highlight in the illustration):
- The rib and collar separate the standard and wide seat positions.
  - Do not attempt to latch the seat in the middle (identified in red); the damper and rear latch will rest on the rib and collar and will not lock.


*Driver's Side Shown*



4. Press down on the rear part of the seat to set both rear latches. The latches click as they engage the floor strikers.




5. Raise the seat-back to an upright position, then rock the seat back and forth, trying to tilt it forward, and make sure both the inner and outer latches are locked in position.



### Third Row Seat Access

The two outer second row seats are equipped with a third row access feature that is activated by pulling the third row access lever or strap.




When a child seat is installed in the outer second row seats (typically using the LATCH anchors), the child seat prevents the seat-back from folding forward, which limits access to the third row. Some owners use the seat lock release lever to tip the entire seat forward with the child car seat installed to gain access to the third row.




American Honda does not recommend using this method to access the third row seats. When the second row outer seat is tipped forward, the seat may slide into the area between the standard and wide positions that prevents the seats from latching. Therefore, using this method of access increases the risk of having an unsecured second row outer seat.


*Driver's Side Shown*



If despite the risks, a customer chooses to tip the entire second row seat forward to access the third row, they need to make sure the seat is in the standard or wide position when lowering and latching the seat.



Check that the seat is latched by rocking the seat back and forth, trying to tilt it forward, and make sure both the inner and outer latches are locked and the front seat hooks are under the front latches.



END