Safety Recall Notice Service Bulletin 509057 Rev. A



631 West 11th Street • P.O. Box 310 • Winamac, IN 46996

July 2019	(574) 946-4139 • 1-800-THE-LIFT • www.braunability.com
NHTSA Recall #: Pending	This service bulletin details replacement of the Toyota Sienna steering shaft extension.
Steering Shaft Extension Replacement	
Applicable for 2019 Toyota Siennna Side Entry Vehicles	Read instructions before beginning.
Manufactured February 20, 2019 to July 8, 2019.	Kit Number: E90391RKS
Warranty Topics: Recall / 19TSESS / Replace Part	Labor Time: 1 Hour

Tools Required


Torque Wrench (ft•lbs) • 12mm Socket • 13mm Socket • Ratchet Drive • Marker Pen




- 1. Turn front wheels and steering wheel to the straight position. See Photo A.
- 2. Turn steering wheel counterclockwise from straight to approximate position shown in Photo B.

Steering shaft extension is now positioned to access steering shaft extension mounting bolts.








3. Locate steering shaft extension. See Photos C through F.








M8 Bolt (12mm Head) and Lock Nut



Intermediate Steering Shaft Assembly

Steering Shaft Extension





M8 Bolt (13mm Head) and Lock Nut

- 7. Remove and retain M8 bolt (13mm head) and lock nut shown in Photo J.
- 8. Remove and discard steering shaft extension. See Photos J and K.
- Install replacement steering shaft extension onto steering gear assembly shaft. Align flat surface of steering shaft extension with line on steering gear assembly shaft drawn in Step 4. See Photos G and L.

Note: The replacement steering shaft extension is marked with a blue witness mark as seen in Photo L.







M8 Bolt (13mm Head) and Lock Nut

- Secure steering shaft extension to steering gear assembly shaft using M8 bolt (13mm head) and lock washer removed in Step 7. Torque to 19 ft•lbs. See Photos M and O.
- Connect intermediate steering shaft assembly to steering shaft extension. Align flat surface of steering shaft extension with line drawn on intermediate steering shaft assembly in Step 4. See Photos G and N.
- Secure intermediate steering shaft assembly to steering shaft extension using M8 bolt (12mm head) and lock washer removed in Step 5. Torque to 19 ft•lbs. See Photos N and P.
- 13. Ensure steering wheel is properly oriented in the "straight" position.
- 14. Test drive and confirm proper operation.



M8 Bolt (12mm Head) and Lock Nut Through Intermediate Steering Shaft Assembly

