
ENGINEERING DETAILS: RIDING MODE

Basic settings

Whenever the software of the instrument cluster is updated, all custom settings are reset to their default, basic settings.

Wheelie (DTC) - front wheel lifted clear of the ground

Base setting on DYNAMIC PRO riding mode: Maximum stability. Efforts are made to suppress a wheelie

DETALLES DE INGENIERÍA: MODO DE CONDUCCIÓN

Configuración básica

Cada vez que se actualiza el software del tablero de instrumentos, todas las configuraciones personalizadas se restablecen a su configuración básica predeterminada.

Wheelie (DTC): rueda delantera levantada del suelo

Configuración básica en el modo de conducción DYNAMIC PRO: estabilidad máxima. Se hacen esfuerzos para suprimir un wheelie