



RECALL

R24CW: Park Brake Hand Lever Secondary Latch

Models Affected: Certain 2024 Model Year Blue Bird Vision School Buses equipped with Orscheln Hand Park Brake

Issue: Hand park brake lever may be released through the application of force to the park brake handle without pushing the release button.

Corrective Action: Inspect and replace if needed.

WARNING: Always follow all Federal, State, Local and Shop safety standards and use proper safety equipment, and thoroughly read and understand all instructions before performing these procedures. Park bus on level surface, apply parking brake, turn off ignition key, and chock wheels.

Parts/Items Needed:

Item	Description	Quantity
1	10050455 Lever, Brake, Parking Button Trigger Guard (IF NEEDED)	1

Instructions:

1. Ensure lever (aka handle) is in the applied position. (Figure 1)
2. Apply 8 lbs. of force to handle without pressing secondary release. (Figure 2)
3. Repeat step # 2 two additional times.
4. If handle does NOT go into unapplied position any of the 3 rounds of test application (steps # 1 – 3), return bus to service.
5. If handle does move into the unapplied position during any of the 3 rounds of test application, replace lever assembly (Part # 10050455).



Figure 1



Figure 2