

HINO  **PARTS**

A Toyota Group Company



HINO **Quick Reference Guide**

2005-2010

(Updated June, 2009)

HINO Quick Reference Guide 2005-2010 Model Years

The Quick Reference Guide is designed to help you quickly look up parts for commonly ordered parts. The format has been changed from previous years.

The main sections are in alphabetical order but the Sub-sections are not.

The **PART NAME** is listed in the first column. The name refers to what HINO may call the part or what the typical truck industry name is.

The second column **DESCRIPTION** gives more detailed information about what the part includes or does not include.

The third column is the actual **PART NUMBER** and should be entered as shown. Supercessions may apply.

The fourth column is the **MODEL** this part applies to and the model years that it applies to.

The fifth column is the **GROUP**. HINO uses five major groups. Engine – Electrical – Drive – Cab Rear Body and Chassis/Tool

The sixth column is the **FIGURE #** that the part can be found in the Hino Electronic Parts Catalog and is helpful if you need other parts in addition to what's listed in the Quick Reference Guide.

HINO Production Series Code

In order to insure you are ordering the correct part number for the vehicle you are working on it is critical that you use the Production Series Code. This is located just below the VIN number on the VIN plate. The plate is attached to the passenger side doorjamb on all conventional trucks. The Production Series

Code can also be found in Dealer Connect through the warranty screen. Go to DC600 then DC611 and then click on options. The vehicle options will be displayed and the Production Series Code is shown directly below the header – Options – It will always consist of two letters and 1 number.

See the example shown above from the EPC.
The P/N 420807191A applies to the
Production Series Code of AA2

The second part number of 420807201A
applies to the Production Series Code of BA2

VIN Identification

Explanation of HINO VIN Number

J H B N A 6 J F 2 5 1 S 1 0 0 0 1

(Manufactures I.D.)
JHB – Built in Japan
5PV – Built in USA
(1-3)

Model (see list*)
(4-5)

Engine Type (see list)**
(6-7)

Wheelbase - Higher Letter
is a Longer Wheelbase
(see list *)**
(8)

Check Digit
(9)

Model Year (see list **)**
(10)

Assembly Plant Code
1= Japan 2= Long Beach CA.
(11)

Production Modification Code
(S) Starting (Initial Production)
(T) Major Production Modification)
(12)

Sequential Series Number
Chassis I.D. Number
(13-17)

*Model

Code	Model	GVW	Brake
NA	145	14,050	Hydraulic
NB	165	16,000	Hydraulic
NC	185	18,000	Hydraulic
ND	238/258	23,000/ 25,500	Hydraulic
NE	268	25,950	Hydraulic
NJ	268A	25,950	Full Air
NV	338	33,000	Full Air

**Engine Type

6J	J05D-TA	175HP
8J	J08E-TA	220HP
8J	J08E-TB	260HP

***Wheelbase

Code	Inches	Kind
F	147	LDT
G	152	MDT
J	175	LDT
K	183	LDT
L	187	LDT
M	201	MDT
N	212	MDT
P	217	MDT
R	235	MDT
T	253	MDT
V	271	MDT

****Model Year

Code	Year	Code	Year
5	2005	B	2011
6	2006	C	2012
7	2007	D	2013
8	2008	E	2014
9	2009	F	2015
A	2010	G	2016

Accessories Guide

HINO 2005-2010 Accessories Guide

Note: some kit quantities are not shown in inventory and are assembled after order is placed.

Description	Part Number
Block Heater JO5E-TA (4 Cyl.)	3510238K4
Block Heater JO8E-TA (6 Cyl.)	3510238K6
Glow Plug Kit JO5E-TA (4 Cyl.)	191101271K4
Glow Plug Kit JO8E-TA (6 Cyl.)	191101271K6
Heated Mirror Kit with Lights	87902KIT05
Chrome Heated Mirror Kit. '08 Models only	87902KIT08C
Black Heated Mirror Kit. '08 Models only	87902KIT08B
Chrome Mirror Cover Kit. 2008 Models Only	87902KITCC
Fender mounted Mirror Kit (contains one mirror. Fits either side ALL MODELS)	97687
52 Gal. Dual Fuel Tank Conversion for ND, NE, NJ, NV. 2005-2008	D61
95 Gal. Fuel Tank Conversion for ND, NE, NJ, NV. 2005-2008	771004620K
For 2009 trucks or trucks using Aluminum fuel tanks you must buy the parts kit and the tanks separate. For 52gl Dual Fuel Tank	FAD61 (parts kit only) S7740E0430 Al. 52gl tank
For 2009 trucks or trucks using Aluminum fuel tanks you must buy the parts kit and the tank separate. For 95gl Fuel Tank	FA771004620K (parts kit only) S7740E0450 Al. 95gl tank
Pac Brake (Exhaust Brake) 4 Cyl. Eaton Manual Transmission. 2005-2007	C40012
Pac Brake (Exhaust Brake) 6 Cyl. With Air Brakes. 2005-2007	C40013
Pac Brake (Exhaust Brake) 6 Cyl. Without Air Brakes. 2005-2007	C40014
Pac Brake (Exhaust Brake) 4 Cyl. Aisin Transmission	C40011
4" Bumper Extension Kit for NA, NB, NC Models Only.	52101LDTKIT
4" Bumper Extension Kit for ND,NE, NJ, NV Models Only.	52101MDTKIT
Chrome Bumper- NA, NB, NC.	52101E0120
Chrome Bumper- ND,NE,NJ,NV.	52101E0130
Chrome Grill- NA,NB, NC	53101E0030
Chrome Grill- ND, NE, NV, NJ.	53101E0060
Chrome Headlamp Bezel (Left) All Models- 2005 ONLY	761081500A
Chrome Headlamp Bezel (Right) All Models- 2005 ONLY	761071660A
Chrome Wheel Simulator Kit. 16" Front and Rear Wheel Covers with Lug Nut Covers	42600H4010
Chrome Wheel Simulator Kit 19.5". FOR 258 LP ONLY. Front and Rear Wheel Covers with Lug Nut Covers. ND	42600H4090

Description	Part Number
Chrome Wheel Simulator Kit. 19.5" FOR 258 ALP ONLY Front and Rear Wheel. Covers with Lug Nut Covers. NJ	42600H4095
Chrome Wheel Simulator Kit. 22.5" Front and Rear Wheel Covers with Lug Nut Covers. ND-NV.	42600H4100
Air Deflector Kits. All Models -White	G-MAD-H-AS-01
Air Deflector Kits. All Models- Black	G-MAD-H-AS-01-05
Air Deflector Kits. All Models- Red	G-MAD-H-AS-01-07
Sun Visor Fits All Conventional Models	HIS54
Instrument Cluster. Simulated Wood Grain Trim Panel Kits. All Models - 2005-2007 only	554141290A
Door Trim Panel - L/S. Simulated Wood Grain Trim Panel Kits. All Models - 2005-2007 only	681431030A
Door Trim Panel - R/S. Simulated Wood Grain Trim Panel Kits. All Models - 2005-2007 only	681441020A
Mud Flaps 24"X30"	HPJ530DW
Mud Flaps 24"X36"	HPJ536DW
Floor Mats (All Models)	FLRMATNAPS
Hino Seat Covers Drivers Side	SA23623
Hino Seat Covers Passenger Side	SA23624
Hino Seat Covers Bench Seat	SA23625
Front Stabilizer Kit. 2005-2010 NA, NB, NC Models Only	D67
Rear Stabilizer Kit. 2005-2010 ND,NE, NJ Models Only	D68PL
Rear Stabilizer Kit. 2005-2010 NV Model Only	D68PL338
Rear Shock Kit. 2005-2010 NA, NB, NC Models Only	D68LDT
Rear Shock Kit. 2005-2010 ND,NE, NJ Models Only	D68MDTC6
Rear Shock Kit. 2005-2010 NV Model Only	D68MDTC7
Heavy Duty Rear Shock Kit for NV 338 Air Suspension Only	66994000
Hendrickson Air ride Susp. Kit. Also, for 268A and 338 Models	482501320A, 3150D2578
Dump Valve Kit. '05-'07 NJ, NV.	5018354KIT
Dump Valve Kit. 2008-2010 ND,NE, NJ, NV Models	27690E0010K
Air Horn Kit 05-07 NJ-NV & All 2008-2010 Models	135456
Differential Lock Kit. 2008-2010 NV and NJ Models Only	154100
Vertical Exhaust Kit. 2005-2007 Only ND- NV	152120
Vertical Exhaust Kit. 2008-2010 Only ND- NV	255152-70-0001

Contents

		PAGE
Air Conditioning	Compressor, Belts, Condenser,s Receiver Driers, Evaporators, Thermostat, Expansion Valves, Idler Pulleys, Compressor Clutches, Control Panels, High Pressure Switches, Evaporator Filters and Air Conditioner Hoses	7-8
Brake System	Hydraulic: Brake Pads, Master Cylinders, Boosters, Servo Assemblies, Calipers, Rotors, Caliper Pins/Boots/Seals Kits, Caliper Pistons and Caliper Hardware Kits.....	9-11
	Electrical: Stop Light Switches, ABS System: Sensors/Brackets, Tone Rings, Brake Motor Relays and Modulator Valves.....	12-13
	Air: Brake Shoes and Drums, Brake Hardware Kits and Springs	13
	Air: Slack Adjusters, S-Cams and Brake Chambers	14
	Air & Hydraulic – ABS Systems: Wheel Speed Sensors, Extension Harnesses, Air Switches and Modulator Valvea.	14-15
	Air: Pressure Regulators, Brake Valves, Driers, Pressure Control Valves, Rebuild Kits, Air Valves, Cartridges and Heater Assembly.....	15-16
Bumpers	Chrome, White and Black, Three Piece And One Piece Options	16
Clutches	Clutch Kit, Spice Clutch Packs, Pilot/ Bearings, Release Bearings, Fork Springs Clutch Forks, Shaft Clutches, Shaft Keys, Spacers, Bushings and Lube Hose	17-18
	Master/Slave Cylinders, Push Rods, and Repair Kits	19
	Flywheels, Ring Gears, Bolts, Pins and Collars	20
Cooling System	Water Pumps, O-Rings, Water Pump Belts, Pulleys and Bolts.....	21
	Thermostat Kits, Gaskets, Radiators, Retainers, Caps and Reserve Tanks	22
	Fan Clutches, Radiator Hoses, Low Coolant Sensors.....	23
Driveline	Differential Pinion Seals, Axle Shafts	24
	Axle Gaskets, U-Joint Kits, Center Bearings, Boot Kits and U-Joint Scraps	25
Electrical (Cab)	Switches: Park Brake, Dimmer, Head Lamp & Directional, Wiper, Cruise Control, Cargo Box, Heated Mirror, Transmission Mode, ABS Diagnostic, Idle Control, Buzzer, Air Horn, Display, Ignition, and DPR Manual Operation	26
Engine (Electrical)	Sensors: Water Temp, Low Coolant, Oil Pressure, Cam and Crank Speed, Air Intake Pressure, Mass Air Flow, Common Rail Pressure, Throttle Position	27
	Starters, Alternators	27
	Headlight & Tail Lamp, Relays and Turn Signal Flashers.....	28
	EGR Solenoids, Computer Fuel Injection, and EGR Valves & Manifolds.....	29
	Intake Shutter, Throttle Body, and Intake Meter Assy.....	29
	Fuses, Fusible Links, and Fuse/Relay bBox Covers	29

Contents (Cont.)

PAGE

Engine	Valves, Springs and Guides.	30
	Oil Pumps, Oil Caps, Plugs and Gaskets.....	30
	Conn Rod Bearing Sets, Main Bearings Sets and Thrust Washers	31
	Piston Liners, Ring Sets and Wrist Pin Kits	32-33
	Gaskets, Gasket Kits and Main Seals	34
	Intercooler and Intercooler Hoses	35
	Exhaust Systems: Turbochargers, Front and Tail Pipes, Muffler, Filters,	36-37
	Exhaust Sensors, Exhaust Brakes; Gaskets: Turbo, Header Pipe, Oil Return, Oil Supply, Exhaust Manifold, EGR Manifold, Crossover Pipe, Exhaust Pipe	
Fuel Injection System	Common Rail Fuel Injection System	38
Filters	Oil, Air, Fuel and Power Steering.....	39
Fuel	Fuel Tanks, Straps, Brackets, Sending Units, Gaskets and Fuel Caps	40
Heater	Heater Fan Motor, Resistor, Heater Core and Cables.....	41
Horn	Horns, Horn Spiral Cable and Horn Cover.....	41
Hubs	Hubs and Rotors, Hubs, Hob Seals, Front Covers and Gaskets.....	42-44
Lettering And Badges	Lettering And Badges.....	45
Lighting	Head Lamps, Head Lamp Assemblies, Bulbs, Turn Signal Assemblies.....	46
	Dome Lamp, Lens, Marker Lamp, Lens, Tail-Turn-Brake Light Assemblies.	
Locks/Keys/Ignition Switch	Key Blanks, Door Locks, Lock Sets and Ignition Switches.....	47
Mirrors	Mirrors, Mirror Brackets and Mirror Light/Lamp Bulbs & Assemblies.....	48-49
Paint Codes	Paint Codes.....	50
Parking Brake	Cables, Handle Grip, Drums, Shoe-Brake Lining Assemblies and Park Brake	51
	Assemblies	
Sealants	Sealants.	52
Steering	Power Steering Box, Pump Assembly, Tie Rods, Pin Kits, Etc.	52-53
Suspension (Front/Rear)	Shock Absorbers Front And Rear, Spring Assembly, Spring Bushings, U-bolts	53-55
	and Hardware	
Transmission (Manual)	Pipe Plugs, Oil Seals, Gaskets, Transmissions, Speed Sensor Kits, Etc	56
Transmission (Automatic)	Aisin: Gauge Oil Level, Tube Sub Assembly, Seals, Gaskets, Etc.....	57
	Automatic Shift Cables, Speed Sensor Kits, Driven Gears, Switch Assembly, Transmission Assembly, Retainer	57-58
Wheels	Wheel Bearings, Races, Wheels, Rims, Lug Nuts, Wheel Studs.	59-62
Windshield/Wipers	Windshield, Rubber Gasket Blades, Arms, Motor, Washer Reservoir, Cap, Pump.....	62

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Air Conditioning					
A/C Compressor Drive Belt	Single V-Belt	SZ91045266	NA,NB,NC 2005-2010	Engine	18-50
A/C Compressor Drive Belt	Single V-Belt	883811100A	ND,NE,NJ,NV 2005-2010	Engine	18-50
A/C Condenser	The Condenser Has The Dryer Built Into It	S884102580	ALL MODELS 2005-2007	Cab	B9-04
A/C Condenser	The Condenser Has The Dryer Built Into It	88460E0130	NA,NB,NC 2008-2010	Cab	B9-04
A/C Condenser	The Condenser Has The Dryer Built Into It	88460E0120	ND,NE,NJ,NV 2008-2010	Cab	B9-04
A/C Drier Cartridge	Dryer Desiccant Refill And Plug	S884741040	ALL MODELS 2005-2010	Cab	B9-04
A/C Evaporator	Core And Rubber Seal Around It	S885011070	ALL MODELS 2005-2010	Cab	B9-00
A/C Thermostat	Located At A/C-Heater/ Evaporator Box	S886251170	ALL MODELS 2005-2010	Cab	B9-00
A/C Expansion Valves	Located At A/C-Heater/ Evaporator Box	S885151070	ALL MODELS 2005-2010	R97469	B9-00
Idler Pulley Assembly	For Production Date Of 11/03 Only Does Not Include Adjusting Bolt	883601200A	NA,NB,NC 2005 ONLY	Engine	18-50
Idler Pulley Assembly	For Production Date Of 12/03 Forward Does Not Include Adjusting Bolt	S883601430	NA,NB,NC 2005-2010	Engine	18-50
Idler Pulley Assembly	Does Not Include Adjusting Bolt	S883601380	ND,NE,NJ,NV 2005-2010	Engine	18-50
A/C Compressor	With Clutch	S883101810	NA,NB,NC 2005-2010	Cab	B9-03
A/C Compressor	With Clutch	S883101800	ND,NE,NJ,NV 2005-2010	Cab	B9-03
A/C Compressor	With Out Clutch	883201820A	NA,NB,NC 2005-2010	Cab	B9-03
A/C Compressor	With Out Clutch	S883201810	ND,NE,NJ,NV 2005-2010	Cab	B9-03
Compressor Clutch	New-Denso	S883301270	ALL MODELS 2005-2010	Cab	B9-03
A/C And Heater Fan Motor Switch	Has No Knob- Comes With The 2 Lights	S874801270	ALL MODELS 2005-2010	Cab	B9-00
A/C On/Off Switch	In A/C-Heater Control Panel In Dash	S886101150	ALL MODELS 2005-2010	Cab	B9-01
A/C High Pressure Switch	Threads Into High Pressure Line-Not Shown In EPC Illustration	S833802500	ALL MODELS 2005-2010	Chassis	91-00
Blower Resistor	Located On Heater/Evaporator Box Under Dash	S871381200	ALL MODELS 2005-2010	Cab	B9-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Air Conditioning (Cont.)					
A/C-Heater Control Panel	Includes Cables And Fan Switch - Does Not Include A/C On/Off Switch	S874101600	ALL MODELS 2005-2010	Cab	B9-00
A/C Filter Element	Filter/Screen In Evaporator Box	S872121200	ALL MODELS 2005-2010	Cab	B9-00
Hose Discharge	Condenser To Compressor	S887114200	NA,NB,NC 2005-2007	Chassis	91-00
Hose Discharge	Condenser To Compressor	88711E0100	NA,NB,NC 2008-2010	Chassis	91-00
Hose Suction	Compressor To Evaporator	S887124770	NA,NB,NC 2005-2007	Chassis	91-00
Hose Suction	Compressor To Evaporator	88712E0180	NA,NB,NC 2008-2010	Chassis	91-00
Hose Liquid	Evaporator To Condenser	S887132340	NA,NB,NC 2005-2007	Chassis	91-00
Hose Liquid	Evaporator To Condenser	88721E0020	NA,NB,NC 2008-2010	Chassis	91-00
Hose Liquid	Evaporator To Condenser	S887132350	ND,NE,NJ,NV 2005-2007	Chassis	91-00
Hose Liquid	Evaporator To Condenser	88721E0010	ND,NE,NJ,NV 2008-2010	Chassis	91-00
Hose Suction	Compressor To Evaporator	887124780A	ND,NE,NJ,NV 2005-2007	Chassis	91-00
Hose Suction	Compressor To Evaporator	88712E0160	ND,NE,NJ,NV 2008-2010	Chassis	91-00
Hose Discharge	Condenser To Compressor	S887114210	ND,NE,NJ,NV 2005-2007	Chassis	91-00
Hose Discharge	Condenser To Compressor	88711E0080	ND,NE,NJ,NV 2008-2010	Chassis	91-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Hydraulic - Disc Brake Pads					
Disc Brake Pads	4 Brake Pads With Holdown Plate Front Axle	MDP5113	NA,NB,NC 2005-2010	Drive	66-10
Disc Brake Pads	4 Brake Pads With Holdown Plate Rear Axle	MDP5113	NA,NB 2005-2010	Drive	68-10
Disc Brake Pads	4 Brake Pads - Front Axle	KITD769AM	ND,NE 2005-2010	Drive	66 -10
Disc Brake Pads	4 Brake Pads - Rear Axle	KITD769AM	NC,ND,NE 2005-2010	Drive	68-10
2005 - 2010 - Brake System - Hydraulic - Front Calipers, Master Cylinders					
Master Cylinder	On Firewall	BX2234933	NA,NB,NC, ND,NE 2005-2010	Chassis	37-05
Booster	Brake Booster Attaches To Rear Of Master Cylinder.	0204022940	NA,NB,NC, ND,NE 2005-2010	Chassis	37-05
Servo Assembly	Includes Master Cylinder, Booster And Back Up Pump Motor	447201011A	NA,NB,NC, ND,NE 2005-2010	Chassis	37-05
Disk Brake Caliper	Right Front Caliper - No Pads	LRG715	NA,NB,NC 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper - No Pads	LRG714	NA,NB,NC 2005-2010	Drive	66-10
Disk Brake Caliper	Right Front Caliper 64mm Piston 8k Axle	60450481	ND,NE 2005-2010	Drive	66-10
Disk Brake Caliper	Right Front Caliper 64mm Piston 8k Axle With Pads	60450474005	ND,NE 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper 64mm Piston 8k Axle	60450480	ND,NE 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper 64mm Piston 8k Axle With Pads	60450473005	ND,NE 2005-2010	Drive	66-10
Disk Brake Caliper	Right Front Caliper 70mm Piston 10k Axle	60450483	NE 2005-2010	Drive	66-10
Disk Brake Caliper	Right Front Caliper 70mm Piston 10k Axle With Pads	60450468005	NE 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper 70mm Piston 10k Axle	60450482	NE 2005-2010	Drive	66-10
Disk Brake Caliper	Left Front Caliper 70mm Piston 10k Axle With Pads	60450469005	NE 2005-2010	Drive	66-10

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Hydraulic - Rear Calipers					
Disk Brake Caliper	Right Rear Caliper	LRG716	NA 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper	LRG717	NA 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper	LRG714	NB 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper	LRG715	NB 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper - 64mm	60450480	NC,ND 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper - 64mm	60450481	NC,ND 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper - 64mm With Pads	60450473005	NC,ND 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper - 64mm With Pads	60450474005	NC,ND 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper - 70mm	60450482	NE 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper - 70mm	60450483	NE 2005-2010	Drive	68-10
Disk Brake Caliper	Right Rear Caliper - 70mm With Pads	60450468005	NE 2005-2010	Drive	68-10
Disk Brake Caliper	Left Rear Caliper - 70mm With Pads	60450469005	NE 2005-2010	Drive	68-10
2005 - 2010 - Brake System - Hydraulic - Rotors					
Front Rotor	Rotor Only	23123626002	NA 2005-2010	Drive	66-00
Front Rotor	Rotor Only	23123625002	NB,NC 2005-2010	Drive	66-00
Front Rotor	Rotor Coated - Tone Ring Machined In	23123557004	ND,NE 2005-2010	Drive	66-00
Rear Rotor	Rotor-Tone Ring Included	23123618007	NA 2005-2010	Drive	68-00
Rear Rotor	Rotor-Tone Ring Included	23123624007	NB 2005-2010	Drive	68-00
Rear Rotor	Rotor Tone Ring Included	23123617004	NC 2005-2010	Drive	68-00
Rear Rotor	Rotor - Tone Ring Machined In	23123557004	ND,NE 2005-2010	Drive	38-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Hydraulic - Caliper, Seals, Hardware					
Caliper Guide Pin Kit	2 Guide Pins, Boots, Bolts, Plugs, Grease	SJ1035	NA,NB,NC Front 2005-2010	Drive	66-10
Caliper Guide Pin Kit	2 Guide Pins, Boots, Bolts, Plugs, Grease	SJ1035	NA,NB Rear 2005-2010	Drive	68-10
Guide Pin Boot Kit	2 Guide Pin Boots And Grease	SP8566	NA,NB,NC Front 2005-2010	Drive	66-10
Guide Pin Boot Kit	2 Guide Pin Boots And Grease	SP8566	NA,NB Rear 2005-2010	Drive	68-10
Boot & Seal Kit	2 Caliper Seals, Dust Boots And Pin Boots	SP8597	NA,NB,NC Front 2005-2010	Drive	66-10
Boot & Seal Kit	2 Caliper Seals, Dust Boots And Pin Boots	SP8597	NA,NB Rear 2005-2010	Drive	68-10
Boot & Seal Kit	For 64mm Piston-Contains 4 Seals& Boots	R4011731	NC Rear 2005-2010	Drive	68-10
Boot & Seal Kit	For 64mm Piston-Contains 4 Seals& Boots	R4011731	ND,NE Front 2005-2010	Drive	66-10/68-10
Boot & Seal Kit	For 64mm Piston-Contains 4 Seals& Boots	R4011731	ND Rear 2005-2010	Drive	66-10/68-10
Boot & Seal Kit	For 70mm Piston-Contains 4 Seals& Boots	R4011730	NE Front/Rear 2005-2010	Drive	66-10/68-10
Caliper-Piston	1- 60 Mm Caliper Piston	31320085	NA,NB,NC Front 2005-2010	Drive	66-10
Caliper-Piston	1- 60 Mm Caliper Piston	31320085	NA,NB Rear 2005-2010	Drive	68-10
Caliper-Piston	64mm Piston And Plug	R4011511	NC Rear 2005-2010	Drive	68-10
Caliper-Piston	64mm Piston And Plug 8k Axle	R4011511	ND,NE Front/Rear 2005-2010	Drive	66-10/68-10
Caliper-Piston	70mm Piston And Plug 10k Axle	60050334	NE Front/Rear 2005-2010	Drive	66-10/68-10
Hardware Kit	For Both 64mm And 70mm Pistons	R4011729	Front/Rear 2005-2010	Drive	66-10/68-10

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Electrical - Brake Light Switches - ABS System					
Stop Light Switch	At Brake Pedal Bracket	843802220A	NA,NB,NC ND,NE 2005-2010	Chassis	35-00
Stop Light Switch	2nd Switch At Brake Pedal Bracket	S843802190	NA,NB,NC ND,NE 2007-2010	Chassis	35-00
Stop Light Switch	Air Brake	S843802180	NJ,NV 2005-2006	Chassis	35-00
Stop Light Switch	Air Brake	S833802620	NJ,NV 2007-2010	Chassis	35-00
ABS Wheel Speed Sensor	Front Sensor - W/O Retainer Clip	894417770A	NA,NB,NC 2005-2010	Drive	66-00
ABS Sensor Bracket	Bolts To Spider Front	69180474	NA,NB,NC 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Rear Sensor - W/O Retainer Clip	894417810A	NA,NB 2005-2010	Drive	66-00
ABS Sensor Bracket	Bolts To Spider Rear	69180473	NA,NB,NC 2005-2010	Drive	68-00
ABS Wheel Speed Sensor	Rear Sensor - W/O Retainer Clip	894417830A	NC 2005-2010	Drive	68-00
ABS Wheel Speed Sensor	Front Sensor - W/O Retainer Clip	894417780A	ND,NE NJ ALP 8k Axle 2005-2010	Drive	66-00
ABS Sensor Bracket	Bolts To Spider Front	69180474	ND,NE 8k Axle 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Front Sensor - W/O Retainer Clip	894417790A	ND,NE 10k Axle 2005-2010	Drive	66-00
ABS Sensor Bracket	Bolts To Spider Front	69180473	ND,NE 10k Axle 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Rear Sensor - W/O Retainer Clip	894417830A	ND,NE 2005-2010	Drive	68-00
ABS Sensor Bracket	Bolts To Spider Rear Axle	69180472	ND,NE 2005-2010	Drive	68-00
ABS Wheel Speed Sensor	Front Sensor - W/O Retainer Clip	894417800A	NJ,NV 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Right Side Rear Sensor - W/O Retainer Clip	894417841A	NJ,NV 2005- 2010	Drive	68-00
ABS Wheel Speed Sensor	Left Side Rear Sensor - W/O Retainer Clip	894417851A	NJ,NV 2005-2010	Drive	68-00
ABS Wheel Speed Sensor Bushing	Speed Sensor Retainer Clip	R955459	ALL 2005-2010	Drive	66-00
Tone Ring	Rear Tone Ring Only - No Screws	09002221	NA,NB 2005-2010	Not Shown	Not Shown
Tone Ring	Rear Tone Ring	3237N1262	NJ 258 ALP 2008-2010	Not Shown	Not Shown
Tone Ring	Front Tone Ring	09002217	NB,NC 2005-2010	Not Shown	Not Shown

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brake System - Electrical - Brake Light Switches - ABS System (Cont.)					
ABS Tone Ring Screws	6 Required	08205977	NA,NB 2005-2010	Not Shown	Not Shown
Brake Motor Relay	Located At Servo	BX2772777	NA,NB,NC,ND,NE 2005-2010	Chassis	36-00
ABS Modulator Valve	1 Required	S4784070580	NA,NB,NC,ND,NE 2005-2010	Chassis	37-03
2005 - 2010 - Brakes - Air - Brake Shoes/Drums					
Brake Shoe W/Lining	1 Brake Shoe And Lining - Front Axle	SMA2124702QP	NJ,NV 2005-2010	Drive	66-10
Brake Shoe Kit	Brake Shoe Kit 1 Per Wheel Or 2 Per Axle W/Hardware Front Axle	XK2124702QP	NJ,NV 2005-2010	Drive	66-10
Brake Shoe W/Lining	1 Brake Shoe And Lining - Rear Axle	SMA2124710QP	NJ 258 ALP 2007-2010	Drive	66-10
Brake Shoe Kit	Brake Shoe Kit 1 Per Wheel Or 2 Per Axle W/Hardware Rear Axle	XK2124710QP	NJ 258 ALP 2007-2010	Drive	66-10
Brake Shoe W/Lining	1 Brake Shoe And Lining - Rear Axle	SMA2124707QP	NJ,NV 2005-2010	Drive	68-10
Brake Shoe Kit	Brake Shoe Kit 1 Per Wheel Or 2 Per Axle W/Hardware Rear Axle	XK2124707QP	NJ,NV 2005-2010	Drive	68-10
Front Brake Shoe Hardware Kit	Contains All Springs, Bushings, And Rollers Completes One Wheel	KIT8824HD	NJ,NV 2005-2010	Drive	66-10
Rear Brake Shoe Hardware Kit	Contains All Springs, Bushings, And Rollers Completes One Wheel	KIT8000MBHD	NJ,NV 2005-2010	Drive	68-10
Shoe Retaining Spring	2 Required Per Side	2258H1230	NJ,NV 2005-2010	Drive	66-10
Shoe Return Spring	1 Required Per Side	258L1234	NJ,NV 2005-2010	Drive	66-10
Drum	Front - Drum Only	85123366002	NJ,NV 2005-2010	Drive	66-00
Drum	Front - Drum Only	85123465002	NJ 258 A/LP 8k Axle 2007-2010	Drive	66-00
Drum	Rear - Drum Only	85123466002	NJ 258 A/LP 2007-2010	Drive	68-00
Drum	Rear - Drum Only	85123207002	NJ,NV 2005-2010	Drive	68-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brakes - Air - Slack Adjusters - Brake Chambers					
Automatic Slack Adjuster	Right Front	R802699	NJ,NV 2005-2010	Drive	66-10
Automatic Slack Adjuster	Left Front	R802698	NJ,NV 2005-2010	Drive	66-10
Automatic Slack Adjuster	Right Rear	R802649	NJ,NV 2005-2010	Drive	68-10
Automatic Slack Adjuster	Left Rear	R802648	NJ,NV 2005-2010	Drive	68-10
S-Cam	Right Front	2210A7463	NJ,NV 2005-2010	Drive	66-10
S-Cam	Left Front	2210Z7462	NJ,NV 2005-2010	Drive	66-10
S-Cam	Right Rear	2210T7586	NJ,NV 2005-2010	Drive	68-10
S-Cam	Left Rear	2210U7587	NJ,NV 2005-2010	Drive	68-10
S-Cam Bushing	Bushing Set- One Set Completes One Axle Fits Front Or Rear.	KIT8042	NJ,NV 2005-2010	Not Shown	Not Shown
Brake Chamber	Front	A703276T20	NJ,NV 2005-2010	Drive	66-10
Brake Chamber	Rear	C313276D30	NJ,NV 2005-2010	Drive	68-10
2005 - 2010 - Brakes - Air & Hydraulic - ABS System					
ABS Wheel Speed Sensor	Front Sensor - No Retainer Clip	894417800A	NJ,NV 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Left Rear Sensor - No Retainer Clip	894417851A	NJ,NV 2005-2010	Drive	66-00
ABS Wheel Speed Sensor	Right Rear Sensor - No Retainer Clip	894417841A	NJ,NV 2005-2010	Drive	66-00
ABS Wheel Speed Sensor Bushing	Speed Sensor Retainer Clip	S8997605104	ALL 2005-2010	Drive	66-00
ABS Extension Harness	19" Long	82164E0L40	NA,NB,NC,ND,NE 2005-2010	Not Shown	Not Shown
ABS Extension Harness	19" Long	820711490A	NJ,NV 2005-2006 ONLY	Not Shown	Not Shown
ABS Extension Harness	19" Long	82164E0L50	NJ,NV 2007-2010	Not Shown	Not Shown
ABS Extension Harness	72" Long	S820711510	NJ,NV 2005-2010	Not Shown	Not Shown
ABS Extension Harness	120" Long	820711520A	NJ,NV 2005-2010	Not Shown	Not Shown

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brakes - Air & Hydraulic - ABS System (Cont.)					
Air Switch	On Front Air Valve At Crossmember Controls Rpm	S833802620	NJ,NV 2005-2010	Chassis	36-00
Air Switch	On Rear Valve At Crossmember Top Of Valve Spring Brake Switch	833802440A	NJ,NV 2005-2010	Chassis	36-00
Air Switch	On Rear Valve At Crossmember Bottom Of Valve Buzzer Switch	833802430A	NJ,NV 2005-2010	Chassis	36-00
ABS Modulator Valve	1 For Each Wheel - Mounted On Frame	S4008500540	NJ,NV 2005-2010	Chassis	36-00
2005 - 2010 - Brakes - Air - Valves/Rebuild Kits/Air Drier					
Air Pressure Regulator	Air Governor	282436	NJ,NV 2005-2010	Chassis	36-51
Governor Rebuild Kit	O-Rings To Rebuild Valve 282436	276121	NJ,NV 2005-2010	Chassis	36-51
Air Brake Valve	Foot Valve	800630	NJ,NV 2005-2010	Chassis	36-69
Air Valve Rebuild Kit	Minor Rebuild Kit For 800630	287368	NJ,NV 2005-2010	Chassis	36-69
Air Valve Rebuild Kit	Major Rebuild Kit For 800630	289352	NJ,NV 2005-2010	Chassis	36-69
Pressure Control Valve	Pressure Control Valve For Spring Brake	288063N	NJ,NV 2005-2010	Chassis	36-77
Air Valve Rebuild Kit	O-Rings To Rebuild Valve 288063	108123	NJ,NV 2005-2010	Chassis	36-77
Air Valve	Spring Brake Control Valve-Maxi Brake	800310	NJ,NV 2005-2010	Chassis	36-86
Air Valve Rebuild Kit	O-Rings To Rebuild Valve 800310	5006939	NJ,NV 2005-2010	Chassis	36-86
Air Valve	Relay Air Valve	103010N	NJ,NV 2005-2010	Chassis	36-81
Air Valve Rebuild Kit	O-Rings To Rebuild Valve 103010	102802	NJ,NV 2005-2010	Chassis	36-81
Air Drier Assembly	Bendix-Complete Air Drier	065612	NJ,NV 2005-2007	Chassis	36-94
Air Drier Assembly	Complete Air Drier	S4430E0160	NA,NB,NC,ND,NE 2008-2010	Chassis	36-94
Air Drier Assembly	Complete Air Drier	448303060A	NJ,NV 2008-2010	Chassis	36-94
Air Drier Repair Kit-Major	Major Repair Kit Includes Bottom Half Of Drier, Purge Valve Kit, Delv. Chk. Valve Kit	5005622	NV,NJ Bendix 2005-2007	Chassis	36-94
Air Drier Repair Kit-Major	Major Repair Kit Includes Bottom Half Of Drier, Purge Valve Kit, Delv. Chk. Valve Kit	S443061550	NA,NB,NC,ND,NE 2008-2010	Chassis	36-94

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Brakes - Air - Valves/Rebuild Kits/Air Drier (Cont.)					
Air Drier Repair Kit-Minor	Minor Repair Kit Includes Desiccant Material And All O-Rings	440861100A	NV,NJ Bendix 2005-2010	Chassis	36-94
Cartridge Assembly	Complete Desiccant Cartridge	S443061450	NV,NJ Bendix 2005-2010	Chassis	36-94
Cartridge Assembly	Complete Desiccant Cartridge	S443061440	NA,NB,NC, ND,NE 2008- 2010	Chassis	36-94
Heater Assembly	Heater Element	871102490A	NV,NJ Bendix 2005-2010	Chassis	36-94
Heater Assembly	Heater Element	871102490A	NA,NB,NC, ND,NE 2008- 2010	Chassis	36-94
2005 - 2010 - Bumpers					
Bumpers	White One Piece	52101E0260	NA,NB,NC 2005-2010	Chassis	44-00
Bumpers	Black One Piece	52101E0270	NA,NB,NC 2005-2010	Chassis	44-00
Bumpers	Chrome One Piece	52101E0120	NA,NB,NC 2005-2010	Chassis	44-00
Bumpers	White One Piece	52101E0730	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Black One Piece	52101E0210	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Chrome One Piece	52101E0130	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	White Three Piece Center Section Only	52101E0230	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Black Three Piece Center Section Only	52101E0240	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Three Piece Bumper End Piece Right Hand Side Black	521051190A	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Three Piece Bumper End Piece Right Hand Side White	S521051170	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Three Piece Bumper End Piece Left Hand Side Black	521051200A	ND,NE,NJ,NV 2005-2010	Chassis	44-00
Bumpers	Three Piece Bumper End Piece Left Hand Side White	S521051180	ND,NE,NJ,NV 2005-2010	Chassis	44-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Clutches					
Clutch Kit	Includes A 13.8 " Clutch And Pressure Plate With A Pilot & Release Bearing	31200H3214	NA,NB,NC 2005-2010	Drive	30-00
Spicer Clutch Pack	Includes A Matched Spicer Disc & Pressure Plate (Standard Clutch)	312002010A	ND,NE,NJ 2005 ONLY	Drive	30-00
Spicer Clutch Pack	Includes A Matched Spicer Disc & Pressure Plate (Standard Clutch)	312001961A	NV 2005 ONLY	Drive	30-00
Spicer Clutch Pack	14" Solo Spicer Self Adjusting Pressure Plate And Clutch Disk (Optional)	312002061A	ND,NE,NJ 2005 ONLY	Drive	30-00
Spicer Clutch Pack	Includes A Matched Spicer Disc & Pressure Plate (Standard Clutch)	312001961A	ND,NE,NJ,NV 2006-2010	Drive	30-00
Spicer Clutch Pack	14" Solo Spicer Self Adjusting Pressure Plate And Clutch Disc (Optional)	312002061A	ND,NE,NJ,NV 2006-2010	Drive	30-00
Spicer Clutch Pack	14" Pressure Plate, Center Plate And Clutch Discs (Twin Disk Option)	312002080A	ND,NE,NJ,NV 2006-2010	Drive	30-00
Twin Disk Spicer Clutch Pack	14" Solo Spicer Self Adjusting Pressure Plate, Center Plate And Clutch Discs (Twin Disk Option)	312002090A	ND,NE,NJ,NV 2006-2010	Drive	30-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Clutch - Pilot/Release Bearings/Springs/Forks/Fork Shafts					
Pilot Bearing	Double Shielded Bearing	SZ37120022	ALL 2005-2010	Drive	30-00
Release Bearing	Bearing Only	S312421141	NA,NB,NC 2005-2010	Drive	30-10
Release Bearing Hub	Hub Only	S312311820	NA,NB,NC 2005-2010	Drive	30-10
Fork Springs	2 Required - Holds The Clutch Fork To The Hub	312341020A	NA,NB,NC 2005-2010	Drive	30-10
Clutch Fork	No Shafts	312331330A	NA,NB,NC 2005-2010	Drive	30-10
Clutch Fork	No Shafts	312331470A	ND,NE,NJ,NV 2005-2010	Drive	30-10
Shaft Clutch Release	Right Side Fork Release Shaft	312451440A	ALL 2005-2010	Drive	30-10
Shaft Clutch Release	Left Side Fork Release Shaft And Bushing	312903250A	NA,NB,NC 2005-2010	Drive	30-10
Shaft Clutch Release	Left Side Fork Release Shaft	S312903260	ND,NE,NJ,NV 2006-2010	Drive	30-10
Key	Left Side Shaft Key	953905105A	NA,NB,NC 2005-2010	Drive	30-10
Spacer	Left Side Shaft Key	900312599A	ND,NE,NJ,NV 2006-2010	Drive	30-10
Bushing	Left Side Shaft Bushing	986712118A	NA,NB,NC 2005-2010	Drive	30-10
Bushing	Bushings In Housing For Fork Shafts	986725139A	NA,NB,NC 2005-2010	Drive	30-10
Lube Hose	Hose And Fittings	SZ93031104	NA,NB,NC 2005-2010	Drive	30-10

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 Clutch - Master/Slave Cylinders And Kits					
Master Cylinder	Includes Reservoir	31420E0030	ALL 2005-2010	Chassis	30-82
Slave Cylinder	Does Not Include Rod	S314701171	NA,NB,NC 2005-2010	Drive	30-83
Slave Cylinder	Does Not Include Rod	314701310A	ND,NE,NJ,NV 2005-2010	Drive	30-83
Rod Push	Slave Cylinder Push Rod	319211160A	NA,NB,NC 2005-2010	Drive	30-10
Rod Push	Slave Cylinder Push Rod	S319211350	ND,NE,NJ,NV 2005-2010	Drive	30-10
Nut	Nut For Push Rod	921012100A	ALL 2005-2010	Drive	30-10
Joint Link Rod	Threads On To Push Rod	S782511190	ALL 2005-2010	Drive	30-10
Pin	Clevis Pin For Above Part	951912155A	ALL 2005-2010	Drive	30-10
Pin	Clip For Clevis Pin	950912118A	ALL 2005-2010	Drive	30-10
Hanger Spring	Clutch Return Spring Attaches To This	987906112A	ALL 2005-2010	Drive	30-10
Repair Kit Master Cylinder	Seals, Boot And Piston	314091050A	ALL 2005-2010	Chassis	30-83
Repair Kit Slave Cylinder	Seals, Boot And Piston	S040315018	ALL 2005-2010	Chassis	30-83

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 Clutch - Flywheels/Ring Gears/Bolts/Pins/Collars					
Flywheel W/Ring Gear	Std. Transmission (Note: Not Available For 2008-2010 Na Models)	S134503890	NA,NB,NC 2005-2007	Engine	12-00
Flywheel W/Ring Gear	Auto Transmission	S134503901	NA,NB,NC 2005-2007	Engine	12-00
Flywheel W/Ring Gear	Auto Transmission Aisin Auto Only	S134503901	NA 2008-2010	Engine	12-00
Flywheel W/Ring Gear	Auto Transmission Allison Only	13450E0170	NB,NC 2008- 2010	Engine	12-00
Flywheel W/Ring Gear	Std. Transmission	S134503830	ND,NE,NJ,NV 2005-2010	Engine	12-00
Flywheel W/Ring Gear	Auto Transmission	13450E0180	ND,NE,NJ,NV 2005-2010	Engine	12-00
Flywheel Bolts	8 Required	S134551550	ALL 2005-2010	Engine	12-00
Pressure Plate Bolts	8 Required	SZ11908017	NA,NB,NC 2005-2010	Engine	30-00
Pressure Plate Bolts	8 Required	901909107A	ND,NE,NJ,NV 2005-2010	Engine	30-00
Pressure Plate Bolts	(Twin Disc Option) 8 Required	901909108A	ND,NE,NJ,NV 2005-2010	Engine	30-00
Ring Gear	129 Teeth	S134531310	ALL 2005-2010	Engine	12-00
Dowel Pins	2 Required	SM21200824	NA,NB,NC 2005-2010	Engine	30-00
Collar	1 Required	900129119A	ALL 2005-2010	Engine	12-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Cooling System - Water Pumps/O-Rings/Belts					
Water Pump	No Gasket Used-Use Sealant # 041321207b	161004150A	NA,NB,NC 2005-2007	Engine	16-51
Water Pump	No Gasket Used-Use Sealant # 041321207b	16100E0381	NA,NB,NC 2008-2010	Engine	16-51
Water Pump	No Gasket Used-Use Sealant # 041321207b	161004220A	ND,NE,NJ,NV 2005-2007	Engine	16-51
Water Pump	No Gasket Used-Use Sealant # 041321207b	16100E0090	ND,NE,NJ,NV 2008-2010	Engine	16-51
O-Ring	At Thermostat Housing And Hose Neck 2 Required	SZ30149006	NA,NB,NC 2005-2010	Engine	16-00
O-Ring	At Thermostat Housing - 1 Required	SZ30160008	ND,NE,NJ,NV 2005-2010	Engine	16-00
O-Ring	At Hose Neck - 1 Required	SZ30153006	ND,NE,NJ,NV 2005-2010	Engine	16-00
Engine Drive Belt	V-Belt 2 Required-Goes Around Waterpump, Crank Shaft Pulley And Alternator	SZ91045255	NA,NB,NC 2005-2007	Engine	18-10
Engine Drive Belt	V-Belt 2 Required-Goes Around Water Pump, Crank Shaft Pulley And Alternator V-Belt Set	SZ91049219	NA,NB,NC 2008-2010	Engine	18-10
Engine Drive Belt	Serpentine Belt 1 Required-Goes Around Water Pump, Crankshaft, Tensioner & Alternator	SZ91045254	ND,NE,NJ,NV 2005-2007	Engine	18-10
Engine Drive Belt	Serpentine Belt 1 Required-Goes Around Water Pump, Crankshaft, Tensioner & Alternator	SZ91045306	ND,NE,NJ,NV 2008-2010	Engine	18-10
Pulley Assembly	Idler Pulley Not Tensioner	16603E0060	ND,NE,NJ,NV 2008-2010	Engine	18-10
Pulley Assembly	Serpentine Idler/Tensioner Pulley	16630E0090	ND,NE,NJ,NV 2008-2010	Engine	18-10
Pulley Assembly	Serpentine Idler/Tensioner Pulley	16630E0250	ND,NE,NJ,NV 2005-2007	Engine	18-10
Bolt	Bolt For Serpentine Idler/Tensioner Pulley	SZ11908215	ND,NE,NJ,NV 2005-2010	Engine	18-10

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Cooling System - Thermostat Kits/Gaskets/Radiators/Cap/Fan Clutch					
Thermostat Kit	Thermostat And Thermostat Gasket	040166104A	NA,NB,NC 2005-2009	Engine	16-00
Thermostat Kit	Thermostat And Thermostat Gasket	S040166119	NA,NB,NC 2010 Only	Engine	16-00
Thermostat Kit	Thermostat And Thermostat Gasket	S040166114	ND,NE,NJ,NV 2005-2010	Engine	16-00
Thermostat Gasket	Seals The Thermostat In The Housing- Use Sealant # 041321207b On The Flange	163251390A	NA,NB,NC 2005-2010	Engine	16-00
Thermostat Gasket	Seals The Thermostat In The Housing- Use Sealant # 041321207b On The Flange	S163251400	ND,NE,NJ,NV 2005-2010	Engine	16-00
Radiator, Manual Trans.	Includes The Radiator Cap	S160906860	NA,NB,NC 2005-2007	Chassis	22-00
Radiator, Manual Trans.	Includes The Radiator Cap	16400E0230	ND,NE,NJ,NV 2005-2007	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	S160906850	NA,NB,NC 2005-2007	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	16400E0070	ND,NE,NJ,NV 2005-2007	Chassis	22-00
Radiator, Manual Trans.	Includes The Radiator Cap	16400E0280	NB,NC 2008- 2010	Chassis	22-00
Radiator, Manual Trans.	Includes The Radiator Cap	16400E0250	ND,NE,NJ,NV 2008-2010	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	16400E0290	NA 2008-2010	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	16400E0300	NB,NC 2008- 2010	Chassis	22-00
Radiator, Auto Trans.	Includes The Radiator Cap	16400E0260	ND,NE,NJ,NV 2008-2010	Chassis	22-00
Retainer	Retainer Clip For Auto Transmission Fluid Hose At Bottom Of Radiator	21598E0010	ND,NE,NJ,NV 05-06-07	Chassis	22-00
Radiator Cap	8.3 Psi	164011710A	ALL 2005-2010	Chassis	22-00
Reserve Tank	Plastic Tank With Cap, Hose And Bracket	16470E0030	ALL 2005- 2010	Chassis	22-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Cooling System - Fan Clutch/Radiator Hoses/Sensor					
Fan Clutch	Does Not Include The Fan	16250E0020	NA,NB,NC 2005-2010	Engine	16-00
Fan Clutch	Does Not Include The Fan	16250E0030	ND,NE,NJ,NV 2005-2007	Engine	16-00
Fan Clutch	Does Not Include The Fan	16250E0240	ND,NE,NJ,NV 2008-2010	Engine	16-00
Lower Radiator Hose	Lower Radiator Hose	900155759A	NA,NB,NC 2005-2007	Chassis	22-00
Lower Radiator Hose	Lower Radiator Hose	16572E0120	NA,NB,NC 2008-2010	Chassis	22-00
Upper Radiator Hose	Upper Radiator Hose	16571E0161	NA,NB,NC 2008-2010	Chassis	22-00
Upper Radiator Hose	Upper Radiator Hose	900155760A	NA,NB,NC 2005-2007	Chassis	22-00
Lower Radiator Hose	Lower Radiator Hose	900155767A	ND,NE,NJ,NV 2005-2007	Chassis	22-00
Lower Radiator Hose	Lower Radiator Hose	16572E0110	ND,NE,NJ,NV 2008-2010	Chassis	22-00
Upper Radiator Hose	Upper Radiator Hose	900155758A	ND,NE,NJ,NV 2005-2007	Chassis	22-00
Upper Radiator Hose	Upper Radiator Hose	16571E0140	ND,NE,NJ,NV 2008-2010	Chassis	22-00
Low Coolant Sensor	In Radiator Top Tank	S834601510	ALL MODELS 2005-2010	Chassis	22-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Driveline - Differential Pinion Seals					
Remanufactured Carriers Are Available For Most Models And Applications Call 1-866-372-4466 Hino Customer Service For More Information					
Pinion Seal	Differential Pinion Seal	A1205D1928	NA,NB,NC 2005-2010	Drive	68-20
Nut Lock Pinion	Pinion Flange Nut	1227Q1291	NA,NB 2005-2010	Drive	68-20
Nut Lock Pinion	Pinion Flange Nut	40X1236	NC 2005-2010	Drive	68-20
Pinion Seal	Differential Pinion Seal	A11205Z2730	ND,NE,NJ,NV Standard 2005-2010	Drive	68-20
Pinion Seal	Differential Pinion Seal	A1205Q2695	NV Opt. 2005-2010	Drive	68-20
Nut Lock Pinion	Pinion Flange Nut	40X1237	ND,NE,NJ,NV 2005-2010	Drive	68-20
2005 - 2010 - Driveline - Axle Shafts					
Axle Shaft	Right Side Axle	3206Q1863	NA,NB 2005-2010	Drive	68-00
Axle Shaft	Left Side Axle	3206P1862	NA,NB 2005-2010	Drive	68-00
Axle Shaft	Right Side Axle	3202E9001	NC 2005-2010	Drive	68-00
Axle Shaft	Left Side Axle	3202F9002	NC 2005-2010	Drive	68-00
Axle Shaft	Right Side Axle 12 Hole Flange	3202Y9047	ND,NE,NJ,NV 2005-2010	Drive	68-00
Axle Shaft	Left Side Axle 12 Hole Flange	3202X9046	ND,NE,NJ,NV 2005-2010	Drive	68-00
Axle Shaft	Right Side Axle 8 Hole Flange	3206S1345	ND,NE,NJ,NV 2005-2010	Drive	68-00
Axle Shaft	Left Side Axle 8 Hole Flange	3206Q1343	ND,NE,NJ,NV 2005-2010	Drive	68-00
Axle Shaft	Depends On Options And Axle Ratio	See EPC	NV	Drive	68-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Driveline - Axle Gaskets					
Gasket	Rear Axle Gasket	RTV Silicone Red Grade	NA,NB 2005-2010	Drive	68-00
Gasket	Rear Axle Gasket	2208J426	NC 2005-2010	Drive	68-00
Gasket	Rear Axle Gasket 8 Hole	2208H476	ND,NE 2005-2010	Drive	68-00
Gasket	Rear Axle Gasket 12 Hole	2208E1123	NJ,NV 2005-2008	Drive	68-00
2005 - 2010 - Driveline - U-Joints - Center Bearings - Boot Kits					
Remanufactured Carriers Are Available For Most Models And Applications Call 1-866-372-4466 Hino Customer Service For More Information					
U-Joint Kit	Caps And Cross	SPL70-1X	NA,NB,NC 2005-2010	Drive	34-00
U-Joint Kit	Caps And Cross	SPL100-1X	ND,NE,NJ 2005-2010	Drive	34-00
U-Joint Kit	Caps And Cross	SPL140X	NV 2005-2010	Drive	34-00
Center Bearing	Carrier Bearing, Insulator And Strap	212261-1X	NA,NB,NC, ND,NE,NJ 2005-2010	Drive	34-00
Center Bearing	Carrier Bearing, Insulator And Strap	210121-1X	NV 2005-2010	Drive	34-00
Boot Kit	Boot, Clamps And Grease	212146X	NA,NB,NC, ND,NE,NJ 2005-2010	Drive	34-00
Boot Kit	Boot, Clamps And Grease	212059X	NV 2005-2010	Drive	34-00
U-Joint Strap	Joint Strap Kit Includes 2 Straps And 4 Bolts	3-70-38X	NA,NB,NC 2005-2010	Drive	34-00
U-Joint Strap	Joint Strap Kit Includes 2 Straps And 4 Bolts	90-70-28X	ND,NE,NJ 2005-2010	Drive	34-00
U-Joint Strap	Joint Strap Kit Includes 2 Straps And 4 Bolts	140-70-18X	NV ONLY 2005-2010	Drive	34-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010- Electrical - Switches					
Parking Brake Switch	Under Parking Brake Plastic Cover	845501300A	NA,NB,NC ND,NE 2005-2006	Chassis	38-20
Parking Brake Switch	Under Parking Brake Plastic Cover	845501320A	NA,NB,NC ND,NE 2005-2010	Chassis	38-20
Dimmer Switch	Dash Lights	S841101460	ALL 2005-2007 ONLY	Electrical	27-20
Dimmer Switch	Dash Lights	84110E0010	ALL 2008-2010	Electrical	27-20
Headlamp & Directional Switch	Left Side At Column	S840111490	ALL 2005-2010	Chassis	64-56
Wiper Switch	Right Side At Column	S840311790	ALL 2005-2007	Chassis	64-56
Wiper Switch	Right Side At Column	840311800A	ALL 2008-2010	Chassis	64-56
Cruise Control On/ Off	Left Side At Column	842803750A	ALL 2005-2010	Electrical	27-20
Cruise Control Set/Resume	Left Side At Column	842803760A	ALL 2005-2010	Electrical	27-20
Cargo Box Light Switch	Left Side At Column	S842803780	ALL 2005-2010	Electrical	27-20
Heated Mirror Switch	Heated Mirrors Are Not Standard - Part Of Cold Weather Option Package	S842803770	ALL 2005-2010	Electrical	27-20
Transmission Mode Switch	In Shift Lever Console For Power/Economy Mode	S842803790	ND,NE,NJ 2005-2010	Electrical	27-20
ABS Diagnostic Switch	Right Side At Column	842803710A	ALL 2005-2010	Electrical	27-20
Idle Control Switch	Located Right Side Of Column	84581E0030	ALL 2005-2010	Electrical	27-20
Buzzer	Psi Low Air Warning	866501770A	NJ,NV 2005- 2010	Electrical	27-20
Air Horn Switch	Located On Right Side Column	842804340A	NJ,NV 2005- 2010	Electrical	27-20
Display Switch	Located On Right Side Column For Multi-Display In Instrument Cluster	842803460A	ALL 2008-2010	Electrical	27-20
Ignition Switch	Does Not Include Lock Cylinder	845601050A	ALL 2005-2010	Electrical	27-20
DPR Manual Operation Switch	Regeneration Switch Located On Dash Left Of Steering Wheel	84280E0040	ALL 2008-2010	Electrical	27-20

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Electrical - Engine Sensors					
Water Temp. Sensor	Right Front Corner At Head	S834201250	ALL 2005-2010	Electrical	18-10
Low Coolant Sensor	In Radiator Top Tank	S834601510	ALL 2005-2010	Chassis	22-00
Oil Pressure Sensor	In Oil Cooler At Filter	83530E0220	ALL 2005-2010	Electrical	18-10
Crankshaft Speed Sensor	In Flywheel Housing At Top - 2 Pin	S894111280	ALL 2005-2010	Electrical	18-10
Camshaft Speed Sensor	In Back Of Head - (3 Pin - 90 Degree)	894101570A	NA,NB,NC 2005-2010	Electrical	18-10
Camshaft Speed Sensor	In Back Of Head - (3 Pin - Straight)	894101590A	ND,NE,NJ,NV 2005-2010	Electrical	18-10
Air Intake Pressure Sensor	At Air Intake Manifold (Turbo Boost Pressure Sensor)	S893901080	ALL 2005-2010	Electrical	18-10
Mass Air Flow Sensor	Both 4 Cylinder And 6 Cylinder	S176601020	ALL 2005-2010	Chassis	25-00
Common Rail Pressure Sensor	Both 4 Cylinder And 6 Cylinder	S227621070	ALL 2005-2007	Engine	15-88
Common Rail Pressure Sensor	Both 4 Cylinder And 6 Cylinder	23810E0020	ALL 2008-2010	Engine	15-88
Throttle Position Sensor	Accelerator Pedal Assembly With Throttle Position Sensor	S780101200	ALL 2005-2010	Chassis	61-00
2005 - 2010 - Electrical - Engine - Starters/Alternators					
Starter	Denso Reman	281002910R	NA,NB,NC 2005-2010	Electrical	19-05
Starter	Denso Reman	S281002921	ND,NE,NJ,NV 2005-2010	Electrical	19-05
Starter	Denso (New)	281002911A	NA,NB,NC 2005-2010	Electrical	19-05
Starter	Denso (New)	S281002921	ND,NE,NJ,NV 2005-2010	Electrical	19-05
Alternator Std.	Denso 12v 105 Amp Brushless Reman	270402550R	NA,NB,NC 2005-2010	Electrical	19-04
Alternator Std.	Denso 12v 105 Amp Brushless Reman	270402560R	ND,NE,NJ,NV 2005-2010	Electrical	19-04
Alternator Std.	Delco 12v 100 Amp (Reman) No Fan Or Pulley Core Charge Applies	10459604	NA,NB,NC 2005-2010	Electrical	19-04
Alternator Std.	Delco 12v 100 Amp (New) With Fan And Pulley	270402530A	NA,NB,NC 2005-2010	Electrical	19-04
Alternator Std.	Delco 12v 100 Amp (New) With Fan And Pulley	270402540A	ND,NE,NJ,NV 2005-2010	Electrical	19-04
Alternator Opt.	Denso 12v 105 Amp Brushless (New) With Fan And Pulley	270402550A	NA,NB,NC 2005-2010	Electrical	19-04
Alternator Opt.	Denso 12v 105 Amp Brushless (New) With Fan And Pulley	S270402560	ND,NE,NJ,NV 2005-2010	Electrical	19-04

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Electrical - Relays And Turn Signal Flashers					
Headlight & Tail Lamp	Located In The Cab On The Right Side Behind The Fuse Cover	88630E0040	ALL 2005-2010	Electrical	27-20
Wiper Relay	Located In The Cab On The Right Side Behind The Fuse Cover	S859401130	ALL 2005-2010	Electrical	27-20
Stop Lamp Relay	Located In The Cab On The Right Side Behind The Fuse Cover	88630E0040	ALL 2005-2010	Electrical	27-20
ABS Motor Relay	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	S859202750	ALL 2005-2010	Electrical	27-00
ECU Main Relay	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	88630E0040	ALL 2005-2010	Electrical	27-00
Power Relay	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	88630E0040	ALL 2005-2010	Electrical	27-00
Starter Relay	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	S283001280	ALL 2005-2010	Electrical	27-00
Flasher, Turn Signal	Located In The Cab On The Right Side Behind The Fuse Cover	819801990A	All Models 2005-2006	Electrical	27-20
Flasher, Turn Signal	Located In The Cab On The Right Side Behind The Fuse Cover	81980E0010	All Models 2007-2010	Electrical	27-20
A/C Compressor Relay	Located In The Cab On The Right Side Behind The Fuse Cover	S859202740	ALL 2005-2010	Electrical	27-20
Glow Plug Relay (Option)	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	S286201470	ALL 2005-2010	Electrical	27-00
Fuel Heater Relay (Option)	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	S859202760	ALL 2005-2010	Electrical	27-00
ATM Back-Up Relay (Option)	Located In The Fuse/Relay Box Behind The Left Side Of The Cab	88630E0040	ALL 2005-2010	Electrical	27-00
Brake Light Relay	Located In The Cab On The Right Side Behind The Fuse Cover	S859202840	ALL 2005-2010	Electrical	27-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010- Electrical - Engine - EGR Solenoids					
Computer - Fuel Injection	Engine Ecu	S895606540	ALL 2005-2007	Electrical	27-20
Computer - Fuel Injection	Engine Ecu	89660E0100	ALL 2008-2010	Electrical	27-20
EGR Valve	Includes Manifold And Egr Valve	25620E0040	NA,NB,NC 2005-2007	Engine	13-20
EGR Valve	Includes Manifold And Egr Valve (Valve Not Sold Separately)	25620E0090	NA,NB,NC 2008-2010	Engine	13-20
EGR Valve	Includes Manifold And Egr Valves	25620E0030	ND,NE,NJ NV 2005-2007	Engine	13-20
EGR Valve	Includes Manifold And Egr Valves (Valves Not Sold Separately)	25620E0170	ND,NE,NJ NV 2008-2010	Engine	13-20
2005 - 2010- Electrical - Engine - Intake Shutter, Throttle Body, And Intake Meter Assy					
Shutter	Intake Shutter Assembly Attaches To Intake Pipe On Left Side Of Engine	26100E0061	NA,NB,NC 2008-2010	Engine	13-20
Throttle Body	Diesel Throttle Body Attaches To Intake Pipe On Left Side Of Engine	26100E0050	ND,NE,NJ NV 2008-2010	Engine	13-20
Intake Meter	Intake Air Flow Meter Assembly On Pipe At Air Filter Housing	S176601020	ALL MODELS 2008-2010	Chassis	25-00
2005 - 2010 - Electrical - Fuses/Fusible Links					
Fuse	5a	SZ98057050	ALL 2005-2010	Electrical	27-00/27-20
Fuse	10a	SZ98057051	ALL 2005-2010	Electrical	27-00/27-20
Fuse	15a	900857153A	ALL 2005-2010	Electrical	27-00/27-20
Fuse	20a	900857154A	ALL 2005-2010	Electrical	27-00/27-20
Fuse	30a	900857159A	ALL 2005-2010	Electrical	27-00/27-10
Fusible Link	30a	SZ98058056	ALL 2005-2010	Electrical	27-00/27-20
Fusible Link	40a	SZ98058060	ALL 2005-2010	Electrical	27-00/27-20
Fusible Link	40a	SZ98058062	ALL 2005-2010	Electrical	27-00/27-20
Fusible Link	60a	SZ98058061	ALL 2005-2010	Electrical	27-00
Fusible Link	60a	SZ98058063	ALL 2005-2010	Electrical	27-00
Fusible Link	140a	SZ98058064	ALL 2005-2010	Electrical	27-00
Fuse/Relay Box Cover	Outside Fuse Box Cover	S844961780	ALL 2005-2010	Electrical	27-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Valves,Springs,Guides					
Intake Valve	2 Per Cylinder	S137111632	ALL 2005-2010	Engine	13-10
Exhaust Valve	2 Per Cylinder	S137151733	ALL 2005-2010	Engine	13-10
Outer Valve Spring	1 Per Valve	S137311610	ALL 2005-2010	Engine	13-10
Inner Valve Spring	1 Per Valve	S137321500	ALL 2005-2010	Engine	13-10
Valve Guides Intake & Exhaust	4 Per Cylinder	S111221220	ALL 2005-2010	Engine	10-00
Valve Stem Seals	4 Per Cylinder	S137191470	ALL 2005-2010	Engine	13-10
Lock, Valve Spring Retainer	2 Per Valve	SZ91026013	ALL 2005-2010	Engine	13-10
2005 - 2010 - Engine - Oil Pumps, Oil Caps, Plugs					
Oil Pump Assembly	Does Not Include Gasket For 4 Cyl	S151102160	NA,NB,NC 2005-2010	Engine	14-00
Oil Pump Assembly	Does Not Include Gasket For 6 Cyl	S151102150	ND,NE,NJ,NV 2005-2007	Engine	14-00
Oil Pump Assembly	Does Not Include Gasket For 6 Cyl	15110E0020	ND,NE,NJ,NV 2008-2010	Engine	14-00
Oil Pump Gasket	Seals Pump At Block	S151191134	ALL	Engine	14-00
Oil Filler Cap	For Valve Cover	S121081100	ALL	Engine	10-00
Drain Plug	For Engine Oil Pan	SZ34118014	ALL	Engine	11-00
Washer/Gasket	For Oil Drain Plug	SZ43018006	ALL	Engine	11-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Main And Rod Bearings - Thrust Washers					
Conn Rod Bearing Set	Full Bearing Set Std. For Connecting Rods W/Studs And Nuts Wide Tab Locks	S132011800	NA,NB,NC 2005-2006	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std. For Connecting Rods W/Bolts Narrow Tab Locks	S132012120	NA,NB,NC 2007 ONLY	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std.	13041E0240	NA,NB,NC 2008-2010	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std. For Connecting Rods W/Studs And Nuts Wide Tab Locks	S132011761	ND,NE,NJ,NV 2005-2006	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std. For Connecting Rods W/Bolts Narrow Tab Locks	S132012100	ND,NE,NJ,NV 2007 Only	Engine	12-00
Conn Rod Bearing Set	Full Bearing Set Std.	13041E0140	ND,NE,NJ,NV 2008-2010	Engine	12-00
Main Bearing Set	Full Bearing Set Std. No Thrust Washers	S117012310	NA,NB,NC 2005-2010	Engine	12-00
Main Bearing Set	Full Bearing Set Std. No Thrust Washers	S117012140	ND,NE,NJ,NV 2005-2010	Engine	12-00
Thrust Washer Set	Fits 4 Cylinder And 6 Cylinder	110111380A	ALL 2005-2010	Engine	12-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Piston Liners					
Piston Liner "A"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	114673170A	NA,NB,NC 2005-2010	Engine	11-00
Piston Liner "A"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	114673200A	ND,NE,NJ,NV 2005-2010	Engine	11-00
Piston Liner "B"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	114673180A	NA,NB,NC 2005-2010	Engine	11-00
Piston Liner "B"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	S114673210	ND,NE,NJ,NV 2005-2010	Engine	11-00
Piston Liner "C"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	114673190A	NA,NB,NC 2005-2010	Engine	11-00
Piston Liner "C"	Liner Letter Located On R/S Of Block Just Below Head Deck And Behind Alternator.	114673220A	ND,NE,NJ,NV 2005-2010	Engine	11-00
Piston & Liner Kit "A"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130135	NA,NB,NC 2005-2007	Engine	12-00
Piston & Liner Kit "A"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130311	NA,NB,NC 2008-2010	Engine	12-00
Piston & Liner Kit "A"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	040130138A	ND,NE,NJ,NV 2005-2007 Only	Engine	12-00
Piston & Liner Kit "A"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130314	ND,NE,NJ,NV 2008-2010	Engine	12-00
Piston & Liner Kit "B"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130136	NA,NB,NC 2005-2007	Engine	12-00
Piston & Liner Kit "B"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130312	NA,NB,NC 2008-2010	Engine	12-00
Piston & Liner Kit "B"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130266	ND,NE,NJ,NV 2005-2007	Engine	12-00
Piston & Liner Kit "B"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130315	ND,NE,NJ,NV 2008-2010	Engine	12-00
Piston & Liner Kit "C"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130137	NA,NB,NC 2005-2007	Engine	12-00
Piston & Liner Kit "C"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130313	NA,NB,NC 2008-2010	Engine	12-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Piston Liners (Cont.)					
Piston & Liner Kit "C"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130267	ND,NE,NJ,NV 2005-2007 Only	Engine	12-00
Piston & Liner Kit "C"	Includes Rings, Piston, Liner (1) Does Not Include Wrist Pin Or Retainers	S040130316	ND,NE,NJ,NV 2008-2010	Engine	12-00
Piston With Ring Set	Piston And Rings Only (1)	130051230A	NA,NB,NC 2005-2007	Engine	12-00
Piston With Ring Set	Piston And Rings Only (1)	S130BE0090	NA,NB,NC 2008-2010	Engine	12-00
Piston With Ring Set	Piston And Rings Only (1)	S130BE0010	ND,NE,NJ,NV 2005-2007	Engine	12-00
Piston With Ring Set	Piston And Rings Only (1)	S130BE0020	ND,NE,NJ,NV 2008-2010	Engine	12-00
Ring Set	Rings For 1 Cyl Only	S130191130	NA,NB,NC 2005-2007	Engine	12-00
Ring Set	Rings For 1 Cyl Only	S1304E0070	NA,NB,NC 2008-2010	Engine	12-00
Ring Set	Rings For 1 Cyl Only	S130192080	ND,NE,NJ,NV 2005-2007 Only	Engine	12-00
Ring Set	Rings For 1 Cyl Only	S1304E0030	ND,NE,NJ,NV 2008-2010	Engine	12-00
Wrist Pin Kit	Wrist Pin And Retainers, Rod Bushing For 1cyl.	S040132114	ALL 2005-2006	Engine	12-00
Wrist Pin Kit	Wrist Pin And Retainers, Rod Bushing For 1cyl.	S040132122	ALL 2007-2010	Engine	12-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Gaskets And Gasket Kits					
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	040103833A	NA,NB,NC 2005-2007	Engine	19-91
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	S040104255	NA,NB,NC 2008-2010	Engine	19-91
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	S040103754	ND,NE 2005- 2007	Engine	19-91
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	S040103755	NJ,NV 2005- 2007	Engine	19-91
Engine Overhaul Gasket Set	Complete Overhaul Gasket Set	S040104256	ND,NE,NJ,NV 2008-2010	Engine	19-91
Cylinder Head Gasket	Head Gasket Only	111152900A	NA,NB,NC 2005-2010	Engine	10-00
Cylinder Head Gasket	Head Gasket Only	111152870A	ND,NE,NJ,NV 2005-2010	Engine	10-00
Valve Cover Gasket	Gasket Only	112132020A	NA,NB,NC 2005-2010	Engine	10-00
Valve Cover Gasket	Gasket Only	S112131880	ND,NE,NJ,NV 2005-2010	Engine	10-00
Front Main Seal	Seal Only	SZ31179002	ALL 2005-2010	Engine	10-00
Rear Main Seal	Seal Only	SZ31101045	ALL 2005-2010	Engine	10-00
Camshaft Housing Gasket	Seal Bet-37ween Head And Camshaft Housing	S111181011	ND,NE,NJ,NV 2005-2010	Engine	10-00
Oil Pan Gasket	Pan Gasket Only	S121512622	NA,NB,NC 2005-2010	Engine	11-00
Oil Pan Gasket	Pan Gasket Only	S121512611	ND,NE,NJ,NV 2005-2010	Engine	11-00
Intake Manifold Gasket	Intake Manifold To Cylinder Head	S171712000	NA,NB,NC 2005-2010	Engine	13-20
Intake Manifold Gasket	Intake Manifold To Cylinder Head	S171712200	ND,NE,NJ,NV 2005-2010	Engine	13-20

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Intercooler					
Intercooler	Intercooler Assembly	S243002250	ALL 2005-2007	Chassis	22-00
Intercooler	Intercooler Assembly	17940E0330	ALL 2008-2010	Chassis	22-00
Intercooler Hose	Right Side Turbo To Intercooler	SZ92033903	NA,NB,NC 2005-2007	Chassis	25-00
Intercooler Hose	Right Side Turbo To Intercooler	SZ92033B21	NA,NB,NC 2008-2010	Chassis	25-00
Intercooler Hose	Left Side Intercooler To Intake	900239709A	NA,NB,NC 2005-2007	Chassis	25-00
Intercooler Hose	Left Side Intercooler To Intake	SZ92033B22	NA,NB,NC 2008-2010	Chassis	25-00
Intercooler Hose	Right Side "Short Hose" Turbo To Pipe	900239657A	ND,NE,NJ,NV 2005-2007	Engine	18-30
Intercooler Hose	Right Side "Short Hose" Turbo To Pipe	SZ92033892	ND,NE,NJ,NV 2008-2010	Engine	18-30
Intercooler Hose	Right Side "Long Hose" Pipe To Intercooler	SZ92033B18	ND,NE,NJ,NV 2008-2010	Engine	25-00
Intercooler Hose	Right Side "Long Hose" Pipe To Intercooler	SZ92033896	ND,NE,NJ,NV 2005-2007	Chassis	25-00
Intercooler Hose	Left Side Intercooler To Intake	SZ92033B19	ND,NE,NJ,NV 2008-2010	Chassis	25-00
Intercooler Hose	Left Side Intercooler To Intake	SZ92033897	ND,NE,NJ,NV 2005-2007	Chassis	25-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Exhaust System					
Turbocharger	Turbocharger With Vnt Controller	S040010439	NA,NB,NC 2005-2007	Engine	18-30
Turbo Gasket Set	Complete Gasket Set For Replacment Of Turbo Charger	S040010441	NA,NB,NC 2005-2010	Not Shown	Not Shown
Turbocharger	Turbocharger With Vnt Controller	17201E0361	NA,NB,NC 2008-2010	Engine	18-30
Turbocharger	Turbocharger With Vnt Controller	S040010440	ND,NE,NJ,NV 2005-2007	Engine	18-30
Turbo Gasket Set	Complete Gasket Set For Replacment Of Turbo Charger	S040010442	ND,NE,NJ,NV 2005-2010	Not Shown	Not Shown
Turbocharger	Turbocharger With Vnt Controller	17201E0352	ND,NE,NJ,NV 2008-2010	Engine	18-30
Turbo Gasket	Turbo To Exhaust Manifold	S241091860	NA,NB,NC 2005-2010	Engine	18-30
Turbo Gasket	Turbo To Exhaust Manifold	S241091820	ND,NE,NJ,NV 2005-2010	Engine	18-30
Header Pipe Gasket	Turbo Exhaust Elbow	S241091840	NA,NB,NC 2005-2010	Engine	18-30
Header Pipe Gasket	Turbo Exhaust Elbow	S241091830	ND,NE,NJ,NV 2005-2010	Engine	18-30
Gasket Oil Return	Turbo Oil Return Tube - 2 Required	S241351121	ALL 2005-2010	Engine	18-30
Gasket Oil Supply	Upper Gaskets On Oil Supply Tube	SL72201210	ALL 2005-2010	Engine	18-30
Gasket Oil Supply	Lower Gaskets On Oil Supply Tube	SL72201415	ALL 2005-2010	Engine	18-30
Exhaust Manifold Gasket	(4 Required For 4 Cyl.) (6 Required For 6 Cyl.)	S171041610	ALL 2005-2010	Engine	13-20
EGR Manifold Gasket	Egr To Intake Manifold Gasket	S171731850	NA,NB,NC 2005-2010	Engine	13-20
EGR Manifold Gasket	Egr To Intake Manifold Gasket	S171041910	ALL 2008-2010	Engine	13-20
EGR Manifold Gasket	Egr To Intake Manifold Gasket	S171731860	ND,NE,NJ,NV 2005-2007	Engine	13-20
EGR Crossover Pipe Gasket	Both Ends Of Egr Crossover Pipe And Egr Inter Cooler To Exhaust Manifold (Qty 3)	S171042010	NA,NB,NC 2005-2010	Engine	13-20
EGR Crossover Pipe Gasket	Both Ends Of Egr Crossover Pipe (Qty 2)	S171041990	ND,NE,NJ,NV 2005-2010	Engine	13-20
EGR Crossover Pipe Gasket	Both Ends Of Egr Crossover Pipe And Egr Cooler To Egr Valve (Qty5)	S171041990	ND,NE,NJ,NV 2008-2010	Engine	13-20
EGR Crossover Pipe Gasket	Egr Cooler Cross Over Pipe At Egr Cooler (Qty 1)	S171042000	ND,NE,NJ,NV 2005-2007	Engine	13-20
Front Pipe	Turbo Elbow To Muffler	17401E0560	NA,NB,NC 2008-2010	Chassis	24-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Engine - Exhaust System (Cont.)					
Front Pipe	Turbo Elbow To Muffler	S176022000	ND,NE,NJ,NV 2005-2007	Chassis	24-00
Front Pipe	Turbo Elbow To Muffler	17401E0570	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Front Pipe	Turbo Elbow To Muffler With Vertical Exhaust	17401E0580	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Muffler	Cat/Muffler	S176071990	NA,NB,NC 2005-2007	Chassis	24-00
Muffler	Cat/Muffler	176071780A	ND,NE,NJ,NV 2005-2007	Chassis	24-00
Filter	Particulate Filter Center Section Only	S1805E0260	NA,NB,NC 2008-2010	Chassis	24-00
Filter	Particulate Filter Center Section Only	S1805E0270	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Gasket	Filter Gasket For Above 2 Per Truck	S171041930	ALL MODELS 2008-2010	Chassis	24-00
Filter & Muffler	Particulate Filter Assy. With Mufflers	S1850E0270	NA,NB,NC 2008-2010	Chassis	24-00
Filter & Muffler	Particulate Filter Assy. With Mufflers	S1850E0281	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Pipe Only	S174324090	ALL 2005-2007	Chassis	24-00
Tail Pipe	Pipe Only	17431E0240	ALL 2008-2010	Chassis	24-00
Tail Pipe	Tail Pipe Vertical Exhaust From Flex Pipe Upward To Turn Out	17405E0341	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Flex Pipe For Vertical Exhaust	17401E0580	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Tail Pipe Vertical Exhaust From Muffler To Flex	17405E0351	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Stack Pipe With Turn Out	17431E0261	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Band Clamps For Vertical Exhaust	17452E0070	ND,NE,NJ,NV 2008-2010	Chassis	24-00
Tail Pipe	Gasket Between Front Pipe And Muffler	S171041580	NA,NB,NC 2005-2010	Chassis	24-00
Exhaust Pipe Gasket	Gasket Between Turbo Elbow And Front Exhaust Pipe	S171041490	NA,NB,NC 2005-2010	Chassis	24-00
Exhaust Pipe Gasket	Gasket Between Turbo Elbow And Front Pipe. Also Between Front Pipe And Muffler	S171041580	ND,NE,NJ,NV 2005-2010	Chassis	24-00
Exhaust Sensor	On Front And Rear Of Dpr Filter/ Muffler Two Per Truck	S894416511	ALL 2008-2010	Chassis	24-00
Exhaust Sensor	Pressure Sensor For Particulate Filter	S893901090	ALL 2008-2010	Chassis	24-00
Exhaust Brake	Exhaust Brake Assembly	46700E0030	ALL 2008-2010	Chassis	24-00
Exhaust Brake	Exhaust Brake Control Cylinder	S174902450	ALL 2008-2010	Chassis	24-53

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Fuel - Common Rail Fuel Injection System					
Injector	Complete Injector Assembly	23670E0271	NA,NB,NC 2005-2007	Engine	15-00
Injector	Complete Injector Assembly	23670E0231	NA,NB,NC 2008-2010	Engine	15-00
Injector	Complete Injector Assembly	23670E0291	ND,NE,NJ,NV 2005-2007	Engine	15-00
Injector	Complete Injector Assembly	23670E0202	ND,NE,NJ,NV 2008 Only	Engine	15-00
Injector	Complete Injector Assembly	23670E0391	ND,NE,NJ,NV 2009-2010	Engine	15-01
O-Ring	Orange O-Ring in Head to Seal Nozzle	SZ91015047	ALL 2005-2010	Engine	10-00
Seal	Injector Inlet Pipe at Head	S230741070	NA,NB,NC 2005-2010	Engine	10-00
Seal	Injector Inlet Pipe at Camshaft Housing	S237451020	ND,NE,NJ,NV 2005-2010	Engine	10-00
Pressure/Supply Pump	4 Cylinder Pump	S227301321	NA,NB,NC 2005-2007	Engine	15-00
Pressure/Supply Pump	4 Cylinder Pump	22100E0110	NA,NB,NC 2008-2010	Engine	15-00
Pressure/Supply Pump	6 Cylinder Pump	S227301311	ND,NE,NJ,NV 2005-2007	Engine	15-00
Pressure/Supply Pump	6 Cylinder Pump	22100E0102	ND,NE,NJ,NV 2008-2010	Engine	15-00
Pressure Pump O-Ring	O-Ring Seals Pressure Pump to Flange	SN73210493	ALL 2005-2010	Engine	15-00
Soft Washers	Washers Needed To Replace Fuel Supply Pump 2 Of Each Part Number	S228771100 SZ43010011	NA,NB,NC 2005-2010	Engine	15-00
Soft Washers	Washers Needed To Replace Fuel Supply Pump 2 Of Each Part Number	S228771100 S228771120	ND,NE,NJ,NV 2005-2010	Engine	15-00
Common Rail Assembly	Includes Pressure Sensor	VIN Required Call Customer Service	NA,NB,NC 2005-2010	Engine	15-00
Common Rail Assembly	Includes Pressure Sensor	23810E0020	ND,NE,NJ,NV 2005-2010	Engine	15-00
Common Rail Pressure Sensor	Both 4 Cylinder and 6 Cylinder	S227621070	ALL 2005-2010	Engine	15-88
Gasket - Pressure Sensor	Gasket to Seal Sensor at Common Rail	228472680A	All 2005-2010	Engine	15-88
Common Rail Flow Dampner	Threads into Common Rail - No Gasket	S227401110	ALL 2005-2010	Engine	15-88
Flow Limiter Assembly	Threads into Common Rail Mid Year Change Of 11 Month 2006	227701090A	ALL 2005-2007	Engine	15-87
Flow Limiter Assembly	Threads into Common Rail Late 2007	S227701110	ALL 2007-2010	Engine	15-88

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Filters- Oil /Air /Fuel /Power Steering					
Oil Filter	4 Cylinder	156072170A	NA,NB,NC 2005-2010	Engine	14-52
Oil Filter	6 Cylinder	15613E0030	ND,NE,NJ,NV 2005-2010	Engine	14-52
Air Filter	4 Cylinder	178013430A	NA,NB,NC 2005-2010	Chassis	25-51
Air Filter	6 Cylinder	178013440A	ND,NE,NJ,NV 2005-2010	Chassis	25-51
Air Filter Indicator	In Air Intake Pipe	S178201410	ALL 2005-2010	Chassis	25-00
Fuel Filter	Fuel/Water Separator Element for RACOR	234011700A	ALL w/RACOR	Chassis	20-53
ALL LIGHT DUTY TRUCKS NA/NB/NC 2005-2010 HAVE ONLY THE RACOR FUEL FILTER					
Fuel Filter	Fuel/Water Separator Element for DAVCO	FS1962490	ALL w/DAVCO	Chassis	20-53
ALL MEDIUM DUTY TRUCKS 2008-2010 ND/NE/NJ/NV COME WITH DAVCO FILTER AS STANDARD EQUIPMENT. RACOR FILTER IS OPTIONAL.					
Air, Fuel and Oil Filter Kit	Air, Fuel, and Oil Filter Kit For Use with Racor Fuel Filter	LDTFKIT	NA,NB,NC 2005-2010	Not Shown	Not Shown
Fuel and Oil Filter Kit	Fuel and Oil Filter Kit For use with Racor Fuel Filter	LDTFKITM	NA,NB,NC 2005-2010	Not Shown	Not Shown
Air, Fuel and Oil Filter Kit	Air, Fuel, and Oil Filter Kit For Use with Racor Fuel Filter	MDTFKIT	ND,NE,NJ,NV 2005-2010	Not Shown	Not Shown
Fuel and Oil Filter Kit	Fuel and Oil Filter Kit For use with Racor Fuel Filter	MDTFKITM	ND,NE,NJ,NV 2005-2007	Not Shown	Not Shown
Fuel and Oil Filter Kit	Fuel and Oil Filter Kit For use with Davco Fuel Filter	MDTFKITD	ND,NE,NJ,NV 2005-2008	Not Shown	Not Shown
P/S Reservoir Filter	Filter Element	S443611070	ALL 2005-2010	Chassis	64-53
P/S Reservoir Strainer	Plastic Strainer	S472281050	ALL 2005-2010	Chassis	64-53

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Fuel Tanks, Sending Units					
Primary Fuel Tank	35 Gallon Tank w/Sending Unit	771004611A	NA,NB,NC 2005-2010	Chassis	20-00
Primary Fuel Tank	52 Gallon Tank w/Sending Unit	771004601A	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Primary Fuel Tank	52 Gallon Tank w/Sending Unit FOR VERTICAL STACK TAIL PIPE	S7740E0070	ND,NE,NJ,NV 2008-2010	Chassis	20-00
Primary Fuel Tank	95 Gallon Tank NO/Sending Unit CAN NOT USE ON 2008-2010 ND,NE,NJ,NV WITH VERTICAL EXHAUST	771004620A	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Primary Fuel Tank	Aluminum 35 Gallon Tank w/ Sending Unit	S7740E0420	NA,NB,NC 2005-2010	Chassis	20-00
Primary Fuel Tank	Aluminum 52 Gallon Tank w/ Sending Unit	S7740E0430	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Primary Fuel Tank	Aluminum 52 Gallon Tank w/Sending Unit FOR VERTICAL STACK TAIL PIPE	S7740E0440	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Primary Fuel Tank	Aluminum 95 Gallon Tank NO/ Sending Unit CAN NOT USE ON 2008-2010 ND,NE,NJ,NV WITH VERTICAL EXHAUST	S7740E0450	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Band Strap	35 Gallon Tank	77601E0150	NA,NB,NC 2005-2010	Chassis	20-00
Band Strap	52/95 Gallon Tank	77601E0130	ND,NE,NJ,NV 2005-2010	Chassis	20-00
L-Support Brkt	35 Gallon Tank	77205E0230	NA,NB,NC 2005-2010	Chassis	20-00
L-Support Brkt	52/95 Gallon Tank	776072142A	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Fuel Gauge Sending Unit	35 Gallon Tank	833202311A	NA,NB,NC 2005-2010	Chassis	20-00
Fuel Gauge Sending Unit	52/95 Gallon Tank	833202321A	ND,NE,NJ,NV 2005-2010	Chassis	20-00
Gasket, Fuel Gage	35/52/95 Gallon Tank	S833611190	ALL 2005-2010	Chassis	20-00
Locking Fuel Cap	35/52/95 Gallon Steel Tank	77310H3600	ALL 2005-2010	Not Shown	Not Shown
Cap, Fuel Tank	35/52/95 Gallon Steel Tank	1A900	ALL 2005-2010	Chassis	20-00
Cap, Fuel Tank	35/52/95 Gallon Aluminum Tank	AAA01326S	ALL 2005-2010	Chassis	20-01

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Heater					
Heater Fan Motor	Motor and Cage	S871041120	ALL MODELS 2005-2010	Cab	B9-00
Heater Motor Resistor	Located at A/C-Heater Box	S871381200	ALL MODELS 2005-2010	Cab	B9-00
Heater Core	Located at A/C-Heater Box	871071250A	ALL MODELS 2005-2010	Cab	B9-00
Cable	Black Cable-Fresh Air Control	874151641A	ALL MODELS 2005-2010	Cab	B9-00
Cable	White Cable-Temperature Control	874151630A	ALL MODELS 2005-2010	Cab	B9-00
Cable	Blue Cable-Vent Position	874151660A	ALL MODELS 2005-2010	Cab	B9-00
2005 - 2010 - Horn, Horn Cover, Horn Spiral Cable					
Horn	Low Note	S865201380	ALL 2005-2007	Electrical	27-00
Horn	2nd Horn	S865001260	ALL 2007-2010	Electrical	27-00
Horn Spiral Cable	Under Horn Button Cover	S840511041	ALL 2005-2010	Chassis	64-56
Horn Cover	On Steering Wheel	S451301560	ALL 2005-2010	Chassis	64-55

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Hub And Rotor - Front And Rear					
Front Hub and Rotor	R/H Hub and Rotor Assembly	17159771000	NA 2005-2010	Drive	66-00
Front Hub and Rotor	L/H Hub and Rotor Assembly	17159771001	NA 2005-2010	Drive	66-00
Front Hub and Rotor	Right or Left Hub and Rotor Assembly	17159761001	NB,NC 2005-2010	Drive	66-00
Front Hub and Rotor	Hub and Rotor Assembly	17159641006	ND,NE 8k Axle 2005-2010	Drive	66-00
Front Hub and Rotor	Hub and Rotor Assembly	17159461000	ND 258/LP 2005-2010 8k Axle	Drive	66-00
Front Hub and Rotor	Hub and Rotor Assembly	17159101004	ND,NE 10k Axle 2005-2010	Drive	66-00
Rear Hub and Rotor	R/H Hub and Rotor Assembly	16159741001	NA 2005-2010	Drive	68-00
Rear Hub and Rotor	L/H Hub and Rotor Assembly	16159741000	NA 2005-2010	Drive	68-00
Rear Hub and Rotor	Right or Left Hub and Rotor Assembly	16159751000	NB 2005-2010	Drive	68-00
Rear Hub and Rotor	Right or Left Hub and Rotor Assembly With Tone Ring	16159731000	NC 2005-2010	Drive	68-00
Rear Hub and Rotor	Right or Left Hub and Rotor Assembly	16157191000	ND,NE 2005-2010	Drive	68-00
Rear Hub and Rotor	Right or Left Hub and Rotor Assembly	16159721000	ND 258 LP 2005-2010	Drive	68-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Hubs - Front And Rear					
Front Hub	Right or Left Hub includes Races and ABS tone ring - No Wheel Studs	0515977002	NA 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs and races	0515976002	NB-NC 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs, races	05159641058	ND,NE 8k Axle 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs, races	0515946001	ND258LP 8k Axle 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs and races	0515910002	ND,NE 10k Axle 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes wheel studs and races	05159381002	NJ 258 A/LP 8k Axle 2008- 2010	Drive	66-00
Front Hub	Right or Left Hub includes races and ABS tone ring (For 10k axle option)	0515632001	NJ,NV 2005-2010	Drive	66-00
Front Hub	Right or Left Hub includes races and ABS tone ring (For 12k Axle Option)	05156321003	NJ,NV 2005-2010	Drive	66-00
Right Rear Hub	Right Rear Hub includes wheel studs, axle studs and races	0415974002	NA 2005-2010	Drive	68-00
Left Rear Hub	Left Rear Hub includes wheel studs, axle studs and races	0415974001	NA 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races and Studs	0415975001	NB 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races and Studs	0415973100	NC 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races	04157191005	ND,NE 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races	0415972099	ND-258 Low Profile 2005-2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races	0415673002	NJ 258 A/LP 8k Axle 2008- 2010	Drive	68-00
Rear Hub	Right or Left Hub includes Races NO Studs	0415675003	NJ,NV 2005-2010	Drive	68-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Hub Seals - Front And Rear					
Hub Seal	Front Wheel Seal - Grease only	A1205Q2695	NA,NB,NC 2005-2010	Drive	66-00
Hub Seal	Front Wheel Seal 8k Axle - Oil or Grease	A1205C2161	ND,NE, LO PRO 2005-2010	Drive	66-00
Hub Seal	Front Wheel Seal 10k Axle - Oil or Grease	A1205U2491	ND,NE 2005-2010	Drive	66-00
Hub Seal	Front Wheel Seal 12K - Oil or Grease	A1205B2264	NJ,NV 2005-2010	Drive	66-00
Hub Seal	Rear Inner Hub Seal	A1205V2674	NA,NB 2005-2010	Drive	68-00
Hub Seal	Rear Inner Hub Seal	A1205W1557	NC 2005-2010	Drive	68-00
Hub Seal	Rear Inner Hub Seal	A1205W1349	ND,NE and Low Pro 2005-2010	Drive	68-00
Hub Seal	Rear Inner Hub Seal	A1205V2492	NJ,NV 2005-2010	Drive	68-00
2005 - 2010 - Hub - Gaskets And Front Covers					
Front Hub Cover	4 Hole Hub Cover - Grease Lube	3262K89	NA,NB,NC 2005-2010	Drive	66-00
Front Hub Gasket	4 Hole Hub Cover Gasket - Grease Lube	2208V1036	NA,NB,NC 8k Axle ND,NE 05-10	Drive	66-00
Front Hub Cover	4 Hole Hub Cover - Grease Lube	3262K89	ND,NE 8k Axle 2005-2010	Drive	66-00
Front Hub Gasket	4 Hole Hub Cover Gasket - Oil Lube	2208C835	ND,NE 8k Axle 2005- 2010	Drive	66-00
Front Hub Cover	4 Hole Hub Cover - Oil Lube	A3262C1381	ND,NE 8k Axle 2005- 2010	Drive	66-00
Front Hub Cover	6 Hole Hub Cover for Grease Lube	3262A53	ND,NE,NJ,NV 2005-2010	Drive	66-00
Front Hub Gasket	6 Hole Hub Cover Gasket Grease/Oil Lube	2208Y363	ND,NE,NJ,NV 2005-2010	Drive	66-00
Front Hub Cover	6 Hole Hub Cover for Oil Lube	A3262G215	ND,NE,NJ,NV 2005-2010	Drive	66-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Lettering And Badges					
Badge	Hino Letter Badge	S7541E0010	ALL MODELS 2005-2010	Not Shown	Not Shown
Badge	Model 145	S7542E0010	NA 2005-2010	Not Shown	Not Shown
Badge	Model 165	S7542E0020	NB 2005-2010	Not Shown	Not Shown
Badge	Model 185	S7542E0030	NC 2005-2010	Not Shown	Not Shown
Badge	Model 238	S7542E0040	ND 2005-2010	Not Shown	Not Shown
Badge	Model 258	S7542E0050	ND NJ /LP 2005-2010	Not Shown	Not Shown
Badge	Model 268	S7542E0060	NE,NJ 2005-2010	Not Shown	Not Shown
Badge	Model 338	S7542E0080	NV 2005-2010	Not Shown	Not Shown

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Lighting					
Head Lamp	2005 Only Right Or Left - Sealed Beam	H6054	ALL 2005 ONLY	Cab	B1-40
Head Lamp Assembly	2006-2010 Right Side Assembly	9Hi946025-02	ALL 2006-2010	Cab	B1-40
Head Lamp Assembly	2006-2010 Left Side Assembly	9Hi946025-01	ALL 2006-2010	Cab	B1-40
Lamp Assembly Turn R/F	Right Side Front Turn Signal Assembly 2005 Only	9Hi946020-02	ALL 2005 ONLY	Electrical	28-16
Lamp Assembly Turn L/F	Left Side Front Turn Signal Assembly 2005 Only	9Hi946020-01	ALL 2005 ONLY	Electrical	28-16
Bulb	Bulb For Above 2005 Turn Signal Assemblies	9HiS93843927	ALL 2005 ONLY	Electrical	28-16
Bulb	Bulb For 2006-2010 Headlamp Signal Assemblies	9HiK93989102	ALL 2006-2010	Electrical	28-24
Lamp Assembly Side Turn	Turn Signal Lamp On Hood - Both Sides	S817401080	ALL 2005-2010	Electrical	28-19
Bulb	Bulb For Hood Turn Signal Assembly	900834121A	ALL 2005-2010	Electrical	28-19
Lamp Assembly	Dome Lamp - Base, Bulb and Cover	S812401390	ALL 2005-2010	Electrical	28-21
Bulb	Dome Lamp Bulb	SZ98032018	ALL 2005-2010	Electrical	28-21
Lens	Dome Lamp Lens	812411140A	ALL 2005-2010	Electrical	28-21
Lamp Assembly	Marker Lamp With Lamp and Pigtail	01-4691-85	ALL 2005-2010	Electrical	28-26
Lamp Lens	Marker Lamp Lens Without Light	01-4691-86	ALL 2005-2010	Electrical	28-26
Lamp Assembly	Tail, Turn, Brake Lamp Assembly	01-5297-77	ALL 2005-2010	Electrical	28-34
Lens	Lens Only For Above Lamp Assembly	01-9130-86	ALL 2005-2010	Electrical	28-34
Mirror Light Bulb	Bulb For Mirror Light	H205391312V	ALL 2005-2007	Not Shown	Not Shown
Lamp Assembly	Tail, Turn, Brake Lamp Assembly	01-5297-77	ALL 2005-2008	Electrical	28-34
Lens	Lens Only For Above Lamp Assembly	01-9130-86	ALL 2005-2008	Electrical	28-34

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Locks/Keys/Ignition Switch					
Switch	Ignition Switch Only	845601050A	2005/2006 ALL	Cab	27-20
Switch	Ignition Switch Only	845102490A	2007 ALL	Cab	27-20
Switch	Ignition Switch Only	S845102313	2008-2010	Cab	27-20
Key Blank	Plastic Coated End	S845122230	ALL 2005-2010	Cab	B5-50
Key Blank w/o Cover	No Plastic Coating	S845122240	ALL 2005-2010	Cab	B5-50
Complete Lock Set	Ignition and both doors	S696103643	ALL 2005-2010	Cab	B5-50
Complete Lock Set Keyed Alike	Ignition and both doors If The Dealer Wants Ten Trucks Keyed Alike They Must Order This Part Number Ten Times	69005E0010	ALL 2005-2010	NOT-SHOWN	NOT-SHOWN
L/H Door Lock	L/S Door Lock Cylinder, Key and Clip	696103670A	ALL 2005-2010	Cab	B5-50
R/H Door Lock	R/S Door Lock Cylinder, Key and Clip	S696103660	ALL 2005-2010	Cab	B5-50

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Mirrors					
Mirror	Plain Mirror No Lights Or Heat Fits Both Sides	879023000A	ALL 2005-2007	Cab and Rear Body	B6-81
Mirror Left	Left Hand Heated And Lighted	87906E0020	ALL 2005-2007	Cab and Rear Body	B6-81
Mirror Right	Right Hand Heated And Lighted	87903E0020	ALL 2005-2007	Cab and Rear Body	B6-81
Spot Mirror/Convex	Convex Mirror Fits Both Sides	S8790E0010	ALL 2005-2007	Cab and Rear Body	B6-81
Mirror Kit	Heated Mirror Kit Includes Both Sides Black Only	87902KIT05	ALL 2005-2007	Not Shown	Not Shown
Mirror	Plain Mirror No Lights Or Heat Right Hand Black	87903E0090	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror	Plain Mirror No Lights Or Heat Right Hand Chrome	87903E0102	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror	Plain Mirror No Lights Or Heat Left Hand Black	87906E0050	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror	Plain Mirror No Lights Or Heat Left Hand Chrome	87906E0062	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror Left	Left Hand Heated And Lighted Black Only	87906E0030	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror Left	Left Hand Heated And Lighted Chrome Only	87906E0042	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror Right	Right Hand Heated And Lighted Black Only	87903E0030	ALL 2008-2010	Cab and Rear Body	B6-81
Mirror Right	Right Hand Heated And Lighted Chrome Only	87903E0042	ALL 2008-2010	Cab and Rear Body	B6-81
Spot Mirror/Convex	Convex Mirror Fits Both Sides Chrome	S8790E0032	ALL 2008-2010	Cab and Rear Body	B6-81
Spot Mirror/Convex	Convex Mirror Fits Both Sides Black	S8790E0020	ALL 2008-2010	Cab and Rear Body	B6-81
Left Mirror Bracket	Left Hand Heated Mirror Stay Black	87094E0030	ALL 2008-2010	Cab and Rear Body	B6-81

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Mirrors (Cont.)					
Left Mirror Bracket	Left Hand Heated Mirror Stay CHROME	87094E0042	ALL 2008-2010	Cab and Rear Body	B6-81
Right Mirror Bracket	Right Hand Heated Mirror Stay BLACK	87093E0100	ALL 2008-2010	Cab and Rear Body	B6-81
Right Mirror Bracket	Right Hand Heated Mirror Stay CHROME	87093E0112	ALL 2008-2010	Cab and Rear Body	B6-81
Lamp Assembly	Mirror Amber Light Assembly Complete	CC205391412V	FOR HEATED MIRROR OPT. 2005-2007	Cab and Rear Body	B6-81
Lamp Lens	Amber Lens for Mirror Light	CC205391112V	ALL 2005-2007	Cab and Rear Body	B6-81
Mirror Light Bulb	Bulb for Mirror Light	H205391312V	ALL 2005-2007	Not Shown	Not Shown
Lamp Assembly	Mirror Amber Light Assembly Complete	114272001-PDC	FOR HEATED MIRROR OPT. 2008-2010	Cab and Rear Body	Not Shown

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Paint Codes					
White	2005-2010 Toyota White	058	ALL	Not Shown	Not Shown
White	2005-2008 Dupont Imron 5000 White (Single Stage)	F3405HN	ALL	Not Shown	Not Shown
White	2005-2010 Dupont Imron 6000 White (2 Stage)	F3405HL	ALL	Not Shown	Not Shown
Penske Yellow	2005-2007 Dupont Imron 5000 Yellow (Single Stage)	N2832	ALL	Not Shown	Not Shown
Penske Yellow	2005-2007 Dupont Imron 6000 Yellow (2 Stage)	L2832	ALL	Not Shown	Not Shown
Penske Yellow	2008-2010 Hino- Dupont Imron Elite Basecoat Yellow (2 Stage)	750206EB	ALL 2008-2010	Not Shown	Not Shown
Red	2008-2010 Hino- Dupont Imron Elite Basecoat Red (2 Stage)	786869EB	ALL 2008-2010	Not Shown	Not Shown
Black	2008-2010 Hino- Dupont Imron Elite Basecoat Black (2 Stage)	L0001EB	ALL 2008-2010	Not Shown	Not Shown
Clear Coat	Dupont Clearcoat For Imron Elite Basecoats (2 Stage Paints)	8840S	ALL	Not Shown	Not Shown

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Parking Brake					
Cable P/B	Manual Transmission Park Brake Cable	464029110A	NA,NB,NC 2005-2010	Chassis	38-20
Cable P/B	Auto Transmission Park Brake Cable	S464029121	NA,NB,NC 2005-2010	Chassis	38-20
Cable P/B	Manual Transmission Park Brake Cable	S464029131	ND,NE 2005-2010	Chassis	38-20
Cable P/B	Auto Transmission Park Brake Cable	S464029140	ND,NE 2005-2010	Chassis	38-20
Grip P/B Lever	Plastic Park Brake Handle Cover No Screw	462151231A	NA,NB,NC, ND,NE 2005-2010	Chassis	38-20
Bolt	Special Bolt For Park Brake Handle Cover	910904226A	NA,NB,NC, ND,NE 2005-2010	Chassis	38-20
Drum P/B	Park Brake Drum Manual Transmission	465111660A	NA,NB,NC 2005-2010	Chassis	38-00
Drum P/B	Park Brake Drum Auto Transmission	465111650A	NA,NB,NC 2005-2010	Chassis	38-00
Drum P/B	Park Brake Drum Auto Transmission	465111630A	NB,NC 2008-2010	Chassis	38-00
Drum P/B	Park Brake Drum Manual Transmission	465111640A	ND,NE 2005-2010	Chassis	38-00
Drum P/B	Park Brake Drum Auto Transmission	465111630A	ND,NE 2005-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	A23722G501	NA,NB,NC Automatic 2005-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	X4152206	NA,NB,NC Manual 2005-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	X4152206	NB,NC Automatic 2008-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	X4152206	ND,NE Automatic 2005-2010	Chassis	38-00
Shoe-Brake Lining Assembly	Park Brake Shoe With Lining Installed	A33722D420	ND,NE Manual 2005-2010	Chassis	38-00
Park Brake Assembly	Complete Assembly for Manual Trans	465104150A	NA,NB,NC 2005-2010	Chassis	38-01
Park Brake Assembly	Complete Assembly for Auto Trans	465104170A	NA,NB,NC 2005-2010	Chassis	38-01
Park Brake Assembly	Complete Assembly for Auto Trans	465104150A	NB,NC 2008-2010	Chassis	38-01
Park Brake Assembly	Complete Assembly for Manual Trans	465104160A	ND,NE 2005-2010	Chassis	38-00
Park Brake Assembly	Complete Assembly for Auto Trans	465104150A	ND,NE 2005-2010	Chassis	38-01

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Sealants					
Sealant	Silver Grade	041321207D	ALL 2005-2010	Not Shown	SHOP MANUAL
Sealant	Black Grade	S041321217	ALL 2005-2010	Not Shown	SHOP MANUAL
Sealant	White Grade	041321211A	ALL 2005-2010	Not Shown	SHOP MANUAL
Sealant	Red Grade	041321207A	ALL 2005-2010	Not Shown	SHOP MANUAL
2005 - 2010 - Steering					
Wheel Assembly	Steering Wheel w/o Horn Button	S451101610	ALL 2005-2010	Chassis	64-55
Button Assembly Horn	Horn Button - Cover	S451301560	ALL 2005-2010	Chassis	64-55
Reservoir Assembly P/S	Complete Power Steering Reservoir	443602360A	ALL 2005-2010	Chassis	64-53
Cap Sub Assembly	Reservoir Cap/Dipstick	S443051070	ALL 2005-2010	Chassis	64-53
Cover Sub Assembly	Plastic Cover for Top of Reservoir	443091040A	ALL 2005-2010	Chassis	64-53
Gasket - Oil Filter	Gasket for Plastic Reservoir Cover	443681060A	ALL 2005-2010	Chassis	64-53
Strainer Oil Reservoir	Plastic Strainer Under Dipstick/ Cap	S472281050	ALL 2005-2010	Chassis	64-53
Filter - Oil	Oil Filter Inside of Reservoir	S443611070	ALL 2005-2010	Chassis	64-53
Power Steering Box Assy	Complete Power Steering Box	441102521A	NA,NB,NC 2005-2010	Drive	64-00
Power Steering Box Assy	Complete Power Steering Box	441102530A	ND,NE 2005-2010	Drive	64-00
Power Steering Box Assy	Complete Power Steering Box	441102540A	NJ,NV 2005-2010	Drive	64-00
P/S Oil Pump Assy	Complete Power Steering Pump	443501481A	NA,NB,NC 2005-2010	Engine	19-14
P/S Oil Pump Assy	Complete Power Steering Pump	44310E0200	ND,NE,NJ,NV 2005-2010	Engine	19-14
Tie Rod End (LH)	End Only	R230137	NA,NB,NC 2005-2010	Drive	66-00
Tie Rod End (RH)	End Only	R230138	NA,NB,NC 2005-2010	Drive	66-00
Tie Rod End (LH)	End Only	R230068	ND,NE,NJ,NV 2005-2010	Drive	66-00
Tie Rod End (RH)	End Only	R230069	ND,NE,NJ,NV 2005-2010	Drive	66-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Steering (Cont.)					
Rod Assy-End/Tie	1 5/8" Tube and Clamps Only	A23102P4540	NA,NB,NC 2005-2010	Drive	66-00
Rod Assy-End/Tie	1 9/16" Tube and Clamps Only	A3102K4379	ND,NE 2005-2010	Drive	66-00
Rod Assy-End/Tie	1 3/4" Tube and Clamps Only	A3102L4380	NE (10K Axle) NJ,NV 2005-2010	Drive	66-00
Link Assembly Steering Drag	Drag Link	454802150A	NA,NB,NC 2005-2010	Drive	64-00
Link Assembly Steering Drag	Drag Link	454802160A	ND,NE,NJ,NV 2005-2010	Drive	64-00
Pin Kit	Complete King Pin Kit	R201478	NA,NB,NC 2005-2010	Drive	66-00
Pin Kit	Complete King Pin Kit -Pins are 1.5" X 7.5" Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	R201474	ND,NE W/ 8k Axle 2005-2010	Drive	66-00
Pin Kit	Complete King Pin Kit -Pins are 2" X 10.375"	R201470	ND,NE,NJ,NV 2005-2010	Drive	66-00
2005 - 2010 - Suspension - Shock Absorbers Front And Rear					
Shock Absorber	Front	485003710A	NA,NB,NC 2005-2010	Chassis	55-54
Cushion	Front Shock Rubber Bushing	900481161A	NA,NB,NC 2005-2010	Chassis	55-54
Shock Absorber	Front	S485003720	ND,NE,NJ,NV 2005-2010	Chassis	55-54
Cushion	Front Shock Rubber Bushing	900481162A	ND,NE,NJ,NV 2005-2010	Chassis	55-54
Shock Absorber	Rear	S485303280	NA,NB,NC 2005-2010	Chassis	58-55
Cushion	Rear Shock Rubber Bushing	900481161A	NA,NB,NC 2005-2010	Chassis	55-55
Shock Absorber	Rear	S485303290	ND,NE,NJ,NV 2005-2010	Chassis	58-55
Cushion	Rear Shock Rubber Bushing	900481106A	ND,NE,NJ,NV 2005-2010	Chassis	55-55

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Suspension (Front) - Spring Assembly					
Spring Assembly	Front - 2 Leaves	S481502780	NA,NB,NC 2005-2010	Chassis	55-54
Spring Assembly	Front - 2 Leaves Standard 8k Axle	S481502790	ND,NE,NJ 2005-2010	Chassis	55-54
Spring Assembly	Front - 3 Leaves Optional 10k Axle	S481502800	ND,NJ,NV 2005-2010	Chassis	55-54
2005 - 2010 - Suspension (Front) - Spring Bushings, U-Bolts, Hardware					
Bumper Front Spring	Rubber Bumper on Top of Spring pack	S431141230	ALL 2005-2010	Chassis	55-00
Stabilizer	FRONT STABILIZER KIT	D67	NA,NB,NC 2005-2010	Chassis	NOT SHOWN
Spring Bushing	Front Spring Rubber Bushing	493051730A	ALL 2005-2010	Chassis	55-00
Bolt/Flange	Front Spring Bushing Flanged Bolt	SZ10520015	ALL 2005-2010	Chassis	55-00
Nut/Flange	Nut for Spring Bushing Bolt	924920106A	NA,NB,NC 2005-2010	Chassis	55-00
U-Bolt	Varies With Application	See EPC	ALL 2005-2010	Chassis	55-00
Nut Flange	U-Bolt Nut	SZ17016025	ND,NE,NJ,NV 2005-2010	Chassis	55-00
Nut Flange	U-Bolt Nut	SZ17818002	ND,NE,NJ,NV 2005-2010	Chassis	55-00
Washer Plain	Washer for U-Bolt	926016330A	NA,NB,NC 2005-2010	Chassis	55-00
Washer Plain	Washer for U-Bolt	926918127A	ND,NE,NJ,NV 2005-2010	Chassis	55-00
2005 - 2010 - Suspension (Rear) - Spring Assembly					
Spring Assembly	Rear - 16 Leaves	482207990A	NA 2005-2010	Chassis	58-54
Spring Assembly	Rear - 14 Leaves	482208000A	NB 2005-2010	Chassis	58-54
Spring Assembly	Rear - 14 Leaves	482208010A	NC 2005-2010	Chassis	58-54
Spring Assembly	Rear - 15 Leaves	S482208020	ND,NE,NJ 2005-2010	Chassis	58-54
Spring Assembly	Rear - 15 Leaves - Standard	482208610A	NV 2005-2010	Chassis	58-54
Spring Assembly	Rear - 15 Leaves - Optional	482208550A	NJ,NV 2005-2010	Chassis	58-54

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Suspension (Rear) - Spring Bushings, U-Bolts, Hardware					
Air Ride Suspension Kit	Hendrickson Air Ride Suspension Kit (Both part numbers required)	482501320A 3150D2578	NJ,NV ONLY 2005-2010	Not Shown	Not Shown
Rear Stabilizer	Rear Stabilizer Kit	D68PL	ND,NE,NJ 2005-2010	Not Shown	Not Shown
Rear Stabilizer	Rear Stabilizer Kit	D68PL338	NV 2005-2010	Not Shown	Not Shown
Rear Shocks	Rear Shock Kit	D68LDT	NA,NB,NC 2005-2010	Not Shown	Not Shown
Rear Shocks	Rear Shock Kit	D68MDTC6	ND,NE,NJ 2005-2010	Not Shown	Not Shown
Rear Shocks	Rear Shock Kit	D68MDTC7	NV ONLY 2005-2010	Not Shown	Not Shown
Spring Bushing	At Front of Rear Spring	51463	ALL 2005-2010	Chassis	58-00
Spring Pin	Pin for Above Bushing	484232720A	ALL 2005-2010	Chassis	58-00
Bolt	Bolt for Above Pin	SH56231275	ALL 2005-2010	Chassis	58-00
Nut	Nut for Above Pin	SL15101213	ALL 2005-2010	Chassis	58-00
Fitting	Grease Zerk for Above Pin	SN45101010	ALL 2005-2010	Chassis	58-00
Pin	At Front and Rear of Spring	SZ24016003	ALL 2005-2010	Chassis	58-00
Washer	Washer for Above Pin	926922121A	ALL 2005-2010	Chassis	58-00
U-Bolt	Rear Spring - Front U-Bolt Without Shock Option - Length is 17.75"	SZ94084260	NA,NB,NC 2005-2010	Chassis	58-00
U-Bolt	Rear Spring - Front U-Bolt With Shock Option - Length is 19.75"	900484735A	NA,NB,NC 2005-2010	Chassis	58-00
U-Bolt	Rear Spring - Rear U-Bolt With or Without Shock Option Length is 18"	SZ94084279	NA,NB,NC 2005-2010	Chassis	58-00
Nut- Flange	U-Bolt Nut	SZ17818002	NA,NB,NC 2005-2010	Chassis	58-00
Washer Plain	Washer for U-Bolt	926918127A	NA,NB,NC 2005-2010	Chassis	58-00
U-Bolt	Depends on Options and Axle Ratio	See EPC	ND,NE,NJ,NV 2005-2010	Chassis	58-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Transmission - Manual					
Pipe Plug	Transmission Fill Plug	X12-1209	ALL 2005-2010	Drive	32-10
Pipe Plug	Transmission Drain Plug	X12-1207	ALL 2005-2010	Drive	32-10
Oil seal - Manual Trans	Front Input Shaft Oil Seal	4300204	NA,NB,NC 2005-2010	Drive	32-10
Gasket - Manual Trans	Front Input Shaft Cover Gasket	240321	NA,NB,NC 2005-2010	Drive	32-10
Oil seal - Manual Trans	Rear Output Shaft Seal	4300203	NA,NB,NC 2005-2010	Drive	32-10
Nut - Manual trans	Output Shaft/Flange Nut	21937	NA,NB,NC 2005-2010	Drive	32-10
Gasket - Manual Trans	Top Cover Gasket	240038	NA,NB,NC 2005-2010	Drive	32-10
Gasket - Manual Trans	Shifter To Top Cover Gasket	4301958	NA,NB,NC 2005-2010	Drive	32-10
Gasket - Manual Trans	PTO Cover Gasket	RTV Silicone Red Grade	ALL 2005-2010	Drive	32-10
Oil seal - Manual Trans	Input Shaft Oil Seal	4300121	ND,NE 2005-2010	Drive	32-10
Gasket - Manual Trans	Input Shaft Cover Gasket	240321	ND,NE 2005-2010	Drive	32-10
Oil seal - Manual Trans	Output Shaft Seal	4300119	ND,NE 2005-2010	Drive	32-10
Oil seal - Manual Trans	Input Shaft Oil Seal	4300121	NJ,NV 2005-2010	Drive	32-10
Gasket - Manual Trans	Input Shaft Cover Gasket	3315659	NJ,NV 2005-2010	Drive	32-10
Oil seal - Manual Trans	Output Shaft Seal	4300119	NJ,NV 2005-2010	Drive	32-10
Nut - Manual trans	Output Shaft/Flange Nut	K-3411	ND,NE,NJ,NV 2005-2010	Drive	32-10
Gasket - Manual Trans	Top Cover Gasket	4300854	ND,NE,NJ,NV 2005-2010	Drive	32-10
Gasket - Manual Trans	Shifter To Top Cover Gasket	4301958	ND,NE,NJ,NV 2005-2010	Drive	32-10
Manual Transmission	Eaton Transmission Model FS4205A	TA-696-66	NA,NB,NC 2005-2010	Drive	32-10
Manual Transmission	Eaton Transmission Model FS5406A	TA-C15-41	ND,NE 2005-2010	Drive	32-10
Manual Transmission	Eaton Transmission Model FS5406A	TA-C15-42	NJ Only 2005-2010	Drive	32-10
Manual Transmission	Eaton Transmission Model FS6406A	TA-C11-43	NV 2005-2010	Drive	32-10
Speed Sensor Kit	Manual Transmission Speed Sensor	K-3454	ALL 2005-2010	Drive	32-10

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Transmission - Automatic - Aisin					
Gauge Oil Level	Dipstick Only	351031240A	NA,NB,NC 2005-2007	Drive	33-00
Gauge Oil Level	Dipstick Only	351031240A	NA 2008-2010	Drive	33-00
Tube Sub Assembly	Dipstick Tube, Gauge, O-rings	S350131230	NA,NB,NC 2005-2007	Drive	33-00
Tube Sub Assembly	Dipstick Tube, Gauge, O-rings AISIN ONLY	S350131230	NA 2008-2010	Drive	33-00
Gauge Oil Level	Dipstick Tube, Gauge, O-rings for 1000 HS ALLISON ONLY	35130E0010	NB,NC 2008-2010	Drive	33-00
Seal	Torque Converter Oil Seal	9031142010	NA,NB,NC 2005-2007	Drive	33-00
Seal	Output Shaft Oil Seal	S900750139	NA,NB,NC 2005-2007	Drive	33-00
Nut	Output Shaft/Flange Nut	S900705167	NA,NB,NC 2005-2007	Drive	33-00
O-Ring	O-Ring For Output Shaft/Flange Nut	S900756228	NA,NB,NC 2005-2007	Drive	33-00
Gasket	PTO Cover Gasket	900753123A	NA,NB,NC 2005-2007	Drive	33-00
Oil Strainer	Screen in Trans Oil Pan USE THREE BOND #TB1218 FOR PAN GASKET	S353031040	NA,NB,NC 2005-2007	Drive	33-00
Pin	Alignment Dowel Pin to Flywheel Housing	SM21200824	NA,NB,NC 2005-2010	Drive	11-10
2005 - 2010 - Transmission - Automatic Shift Cables					
Cable T/M Control	Aisin Shift Cable	337027151A	NA,NB,NC 2005-2007 NA 2008-2010	Drive	32-50
Cable T/M Control	Allison Shift Cable	337027160A	ND,NE,NJ 2005-2010	Drive	32-50
Cable T/M Control	Allison Shift Cable	33820E0540	NB,NC 2008-2010	Drive	32-50

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Transmission - Automatic					
Speed Sensor Kit	Aisin Speed Sensor (Top of Trans)	894101640A	NA,NB,NC 2005-2007	Drive	33-00
Speed Sensor Kit	Aisin Speed Sensor (For Speedometer)	S831901550	NA,NB,NC 2005-2007	Drive	33-00
Driven Gear	Pencil Gear At Output Shaft Housing	349151040A	NA 2005-2010	Drive	33-00
Driven Gear	Pencil Gear At Output Shaft Housing	349151030A	NB,NC 2005-2007 Only	Drive	33-00
Switch Assembly	Aisin Automatic Transmission Gear Position Switch	S842201650	NA,NB,NC 2005-2007	Drive	33-00
Auto Transmission	Aisin Automatic Assembly	351003040A	NA 2005-2007	Drive	33-00
Auto Transmission	Aisin Automatic Assembly	35010E0081	NA 2008-2010	Drive	33-00
Auto Transmission	Aisin Automatic Assembly	351003030A	NB,NC 2005-2007 Only	Drive	33-00
Auto Transmission	All Allison Transmissions Are Warrantied Thru Allison	Contact Allison	NB,NC,ND, NE,NJ,NV 2005-2010	Drive	33-00
Retainer	Quick Clip for Transmission Lines at Radiator	21598E0010	ALL 2005-2010	Chassis	22-00

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Wheel Bearings And Races					
Cone - Bearing, Inner	Front - Inner Wheel Bearing	NP449281	NA,NB,NC 2005-2010	Drive	66-00
Cup - Bearing, Inner	Front - Inner Wheel Bearing Race	25520	NA,NB,NC 2005-2010	Drive	66-00
Cone - Bearing - Outer	Front - Outer Wheel Bearing	LM48548A	NA,NB,NC 2005-2010	Drive	66-00
Cup - Bearing - Outer	Front - Outer Wheel Bearing Race	LM48510	NA,NB,NC 2005-2010	Drive	66-00
Cone - Bearing, Inner	Front - Inner Wheel Bearing Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	JM207049A	ND,NE 8k Axle 2005-2010	Drive	66-00
Cup - Bearing, Inner	Front - Inner Wheel Bearing Race Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	JM207010	ND,NE 8k Axle 2005-2010	Drive	66-00
Cone - Bearing - Outer	Front - Outer Wheel Bearing Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	25877	ND,NE 8k Axle 2005-2010.	Drive	66-00
Cup - Bearing - Outer	Front - Outer Wheel Bearing Race Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	25820	ND,NE 8k Axle 2005-2010	Drive	66-00
Cone - Bearing, Inner	Front - Inner Wheel Bearing	HM212049	NE, 10k Axle NJ,NV 2005-2010	Drive	66-00
Cup - Bearing, Inner	Front - Inner Wheel Bearing Race	HM212011	NE, 10k Axle NJ,NV 2005-2010	Drive	66-00
Cone - Bearing - Outer	Front - Outer Wheel Bearing	3782	NE, 10k Axle NJ,NV 2005-2010	Drive	66-00
Cup - Bearing - Outer	Front - Outer Wheel Bearing Race	3720	ND,NE, 10k Axle NJ,NV 2005-2010	Drive	66-00
Cone - Bearing, Inner	Rear - Inner Wheel Bearing	39590	NA,NB 2005-2010	Drive	68-00
Cup - Bearing - Inner	Rear - Inner Wheel Bearing Race	39520	NA,NB 2005-2010	Drive	68-00
Cone- Bearing, Outer	Rear - Outer Wheel Bearing	JLM506849	NA,NB 2005-2010	Drive	68-00
Cup - Bearing - Outer	Rear - Outer Wheel Bearing Race	JLM506810	NA,NB 2005-2010	Drive	68-00
Cone- Bearing, Inner	Rear Axle Hub Inner Bearing	33287	NC 2005-2010	Drive	68-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Wheel Bearings And Races (Cont.)					
Cup Inner Bearing	Rear Axle Hub Inner Bearing Race	33462	NC 2005-2010	Drive	68-00
Cone-Bearing, Outer	Rear Axle Hub Outer Bearing	3982	NC 2005-2010	Drive	68-00
Cup-Outer Bearing	Rear Axle Hub Outer Bearing Race	3920	NC 2005-2010	Drive	68-00
Cone-Bearing, Inner	Rear Axle Hub Inner Bearing	47686	ND,NE and Low Pro 2005- 2010	Drive	68-00
Cup-Bearing, Inner	Rear Axle Hub Inner Bearing Race	47620	ND,NE and Low Pro 2005- 2010	Drive	68-00
Cone-Bearing, Outer	Rear Axle Hub Outer Bearing	39590	ND,NE and Low Pro 2005- 2010	Drive	68-00
Cup-Bearing, Outer	Rear Axle Hub Outer Bearing Race	39520	ND,NE and Low Pro 2005- 2010	Drive	68-00
Cone-Bearing, Inner	Rear Axle Hub Inner Bearing Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	594A	NJ,NV 2005-2010	Drive	68-00
Cup-Bearing, Inner	Rear Axle Hub Inner Bearing Race Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	592A	NJ,NV 2005-2010	Drive	68-00
Cone-Bearing, Outer	Rear Axle Hub Outer Bearing Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	580	NJ,NV 2005-2010	Drive	68-00
Cup-Bearing, Outer	Rear Axle Hub Outer Bearing Race Note: also used on NJ-258 A/LP W/ 8k Axle 2008-2010 Model	572	NJ,NV 2005-2010	Drive	68-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Wheels/Rims					
Wheel	16 X 6.0 (6 Lug) Front And Rear	S426114960	NA 2005-2010	Drive	59-00
Wheel	19.5 X 6.0 (8 Lug) Front And Rear	29584PW	NB,NC 2005-2010	Drive	59-00
Wheel	19.5 X 6.75 (8 Lug) Front And Rear	28680PW	ND Low Profile (258) 2005-2010	Drive	59-00
Wheel	22.5 X 8.25.0 (10 Lug) Front And Rear	28408PW	ND,NE,NJ,NV 2005-2010	Drive	59-00
Wheel	19.5 X 8.5 (10 Lug) Front And Rear Steel	42611E0050	NJ 258 A/LP 2008-2010	Drive	59-00
Wheel	Front And Rear Polished Aluminum Wheels Are Available Call Customer Service For Part Numbers	Phone# 866-372-4466	All Models Except NA 2005-2010	Not Shown	59-00
2005 - 2010 - Wheel/Rim Lug Nuts					
Nut Hub	Lug Nut - R/H Front	900421114A	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - L/H Front	900422106A	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - R/H Rear Inner	SZ94023007	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - L/H Rear Inner	SZ94024007	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - R/H Rear Outer	SZ94021012	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - L/H Rear Outer	SZ94022014	NA 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - R/H and L/H - Front and Rear	900431109A	NB,NC 2005-2010	Chassis	59-00
Nut Hub	Lug Nut - R/H and L/H - Front and Rear	900431110A	ND,NE,NJ,NV 2005-2010	Chassis	59-00

HINO 2005-2010 Quick Reference Guide

Part Name	Description	Part Number	Models	Group	Figure #
2005 - 2010 - Wheel Studs - Front/Rear					
Wheel Studs	Front and Rear (RH)	09002225	NA 2005-2010	Drive	66-00
Wheel Studs	Front and Rear (LH)	09002226	NA 2005-2010	Drive	66-00
Wheel Studs	Front - Both Sides	09002232	NB,NC 2005-2010	Drive	66-00
Wheel Studs	Rear - Both Sides	09002223	NB,NC 2005-2010	Drive	66-00
Wheel Studs	Front - Both Sides	09002013	ND,NE 2005-2010	Drive	66-00
Wheel Studs	Rear - Both Sides	09001989	ND,NE 2005-2010	Drive	66-00
Wheel Studs	Front - Both Sides	09001989	NJ,NV 2005-2010	Drive	66-00
Wheel Studs	Rear - Both Sides	09001728	NJ,NV 2005-2010	Drive	66-00
2005 - 2010 - Windshield					
Glass W/S	Windshield	794111880A	ALL 2005-2010	Cab	B7-00
Weatherstrip W/S	Rubber Gasket for Windshield	56121E0010	ALL 2005-2010	Cab	B7-00
2005 - 2010 - Wiper Blades, Arms, Motor					
Blade	Right Side	S852211120	ALL 2005-2010	Electrical	28-44
Blade	Left Side	S852211110	ALL 2005-2010	Electrical	28-44
Blade Assy	Right Side	S852201560	ALL 2005-2010	Electrical	28-44
Blade Assy	Left Side	S852201540	ALL 2005-2010	Electrical	28-44
Arm Assy	Right Side	85221E0060	ALL 2005-2010	Electrical	28-44
Arm Assy	Left Side	85221E0050	ALL 2005-2010	Electrical	28-44
Motor Assy W/ Bracket	Wiper Motor and Bracket	S851201550	ALL 2005-2010	Electrical	28-44
Jar and Pump Assembly	Windshield Washer Reservoir, Pump, Cap	S850801680	ALL 2005-2010	Electrical	28-43
Cap Washer Jar	Windshield Washer Reservoir Cap	S853321050	ALL 2005-2010	Electrical	28-43
Motor and Pump Assembly	Windshield Washer Pump and Motor	S853101120	ALL 2005-2010	Electrical	28-43

