



Tech Tips

TT 64-12-03

Date: November 2, 2012

2012-2013 Beetle – Door Panel Window Switch Bezel Removal

If the door panel needs to be removed, gently remove the window switch bezel following this procedure:

- Release the switch metal clip on the switch bezel by pulling up on the front side of the trim. If necessary, use a bone tool to release the clip. Avoid excessive upward force.



- Once the metal clip has been released, press into the door panel just above the switch bezel. This will completely release all remaining clips.
- The bezel trim can now be lifted easily without damage to the clips.