



Countries: CANADA, UNITED STATES, MEXICO **Document ID:** IK0800410
Availability: ISIS, FleetSIS **Revision:** 0
Major System: ELECTRICAL SYSTEM **Created:** 12/17/2012
Current Language: English **Last Modified:** 12/18/2012
Other Languages: NONE **Author:** Jon Pierce
Viewed: 200

[Less Info](#)

[Hide Details](#)

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 5	Not Helpful 1
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	-------------------------	-----------------------------


Title: FM/AM Radio with No Sound

Applies To: All Models

DESCRIPTION

Radio will come on, no sound and it can't be tuned to any stations on AM or FM.

SECTION 2 — 08RKB - STEREO RECEIVER



Panasonic® CR-CM120U

- | | | |
|---|--|---|
| 1. Volume/Push to Select – Selects a value/item in the audio menu | 6. Auxiliary (AUX) – From line output of external sound/audio device (e.g. silicon-audio player, HDD player, etc.) | 9. Source (SRC)/Power (PWR) – Selects the source and toggles power ON/OFF |
| 2. Sound Quality Display – Displays a sound type | 7. Auto Preset Memory (APM) – Executes the APM in the radio source | 10. Sound Quality (SQ) – Selects a sound type |
| 3. Up/Down Tune/Seek – Selects a frequency | 8. Preset Buttons – Selects a preset station in the radio source, and presets the current station | 11. Band – Selects FM1, FM2, FM3, or AM |
| 4. Clock Set (CLK) | | 12. Mute |
| 5. Display (DISP) – Switches information on the display | | |

After you have verified battery and accessory power to the unit Please make sure the tuner is in U.S.A. mode

- 1) Make sure the radio is OFF.
- 2) Press "5/RDM" and "Title/Menu" buttons together for around 5 seconds.
- 3) The radio will display "Advanced" Menu.
- 4) Press "6/OK" on Freq Zone.
- 5) Press "UP" to scroll through the following Zones: USA, EUROPE, JAPAN, ARGENTINA, CHINA, SAUDI ARABIA.

6) Press "6/OK" on the proper zone.

7) Press "1/ESC"

[Radio Operators Manual](#)

circuit diagrams

[2010 Prostar/Lonestar with Remote Radio](#)

[12 and 16 way radio connectors all other models](#)

 Hide Details

Feedback Information

Viewed: 199

Helpful: 5

Not Helpful: 1

No Feedback Found

Copyright © 2013 Navistar, Inc.