

SB-10043722-6611SI M16 01 09
Fuel Supply SystemsFebruary 2012
Technical Service

This Service Information bulletin supersedes SI M16 01 09 **dated August 2009.**

NEW designates changes to this revision

SUBJECT**Fuel Level Sensor Repair Procedure****MODEL****NEW** All**NEW INFORMATION**

When replacing the right and/or left side fuel level sensor due to a failure, it is **not** necessary to replace the following complete assemblies/kits:

- The fuel pump with fuel level sensor (right side); and/or
- The fuel filter with fuel level sensor (left side).

For example, the customer complains that the fuel gauge is inoperative. When diagnosed, the problem is a defective fuel level sensor. As listed in ETK, only replace the assembly's fuel level sensor component part.

When applicable the "fuel pump repair kit" or "fuel filter repair kit" with level sensor must not be used to repair fuel level sensor concerns.

NEW WARRANTY INFORMATION

Claims for replacing complete assemblies or kits when the component part is available separately will not be accepted.

[MINI, a division of BMW of North America, LLC
Copyright © 2012 BMW of North America, LLC]