



Date: January 10, 2012
Order No.: V-B-41.10/02
Group: 41

SUBJECT: MY-All, Model 906
Removal and Installation of the Drive Shaft

Do not attempt to remove or install the drive shaft without a second person assisting. The drive shaft must be as straight as possible when removed, installed, transported, or stored; otherwise, vibration and/or humming noises can arise in the passenger compartment.

Always ensure the propeller shaft center support bearing is tension-free when installing the drive shaft.

See WIS document: AR41.10-D-0050H for removal and installation instructions.

This bulletin has been created and maintained in accordance with MBUSA-SLP S423QH001, Document and Data Control, and MBUSA-SLP S424HH001, Control of Quality Records.