



Charging Procedure

PLEASE READ BEFORE CHARGING! Failure to follow these steps may prevent proper charging or cause a communications fault in your Karma.

1. Plug the charger into your wall outlet.

SB-10044135-6942

2. Plug the other end of the charger into your Karma until it clicks into place.

3. When finished, please disconnect the charger from your Karma BEFORE you unplug the charging unit from the wall.

CAUTION:

Immediately disconnect use of the charger if any portion of the cord is damaged, frayed or if any wiring becomes exposed. Do not cover the charger or any cords with carpet or any other material when in use.

