

Fisker Flash



Command Center Tips

The command center in the Fisker Karma is a revolutionary system that integrates all vehicle controls into one area. Due to the fact that this touch panel is a computer, there are a few things to keep in mind and pass along to your customers.

As with any computer, the system needs to fully load before any actions are taken. If the system does not fully load before any buttons are pressed, you may experience delays with the screen. For example, if the "Agree" button is pressed as soon as the vehicle is turned on, this command may not register until the screen has fully loaded.

Also, when selecting other screens such as Audio, Phone, Navigation, or System there may be a slight delay in the initial actions. Similar to a computer, a program will initially require some time to load. However, once all the programs have loaded, you can toggle between different programs rather quickly.

Finally, you may notice that the navigation does not have an option for volume control. The navigation volume is directly proportional to your audio volume control. Therefore as you increase your audio volume, your navigation volume will also increase. Similarly, as audio volume is decreased, navigation volume will decrease.



SB-10044138-8093

