

Rear Wheel Opening Extension Pad Installation

Service Category General

Section Pre-Delivery Service

Market USA

Toyota Supports
 ASE Certification 

Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2013	Prius PHV	

Introduction

The Rear Wheel Extension Pads are located in the luggage compartment at the assembly plant to avoid damage in transit. Install the Rear Wheel Extension Pads on the vehicle during Pre-Delivery Service (PDS) using the following procedure.

Warranty Information

OP CODE	DESCRIPTION	TIME	OFF	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-

Pad Contents

- Rear Wheel Extension Pads (Left and Right)
- Two (2) plastic clips
- Two (2) self-tapping screws

Installation Procedure

HINT
 Use the same procedure for the Left and Right Pads.

Rear Wheel Opening Extension Pad Installation

Installation Procedure (Continued)

1. Install the left rear wheel extension pad with the clip.
2. Install the self-tapping screw.

Figure 1.

