

# Front Wheel Opening Extension Pad Installation During PDS

Service

Category General

Section

Pre-Delivery Service

Market USA



#### Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION	
2014	ES300H, ES350		

#### Introduction

The front wheel opening extension pad set (right and left front wheel opening extension pads, 2 tapping screws) is loaded in the luggage compartment at the assembly plant to avoid damage in transit. Install the front wheel opening extension pads to the vehicle during Pre-Delivery Service (PDS).

## **Warranty Information**

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	-	-	-	


#### Installation Procedure

1. Remove the 2 self-tapping screws from the left front engine under cover.

#### NOTE

The removed self-tapping screws will be reused.

Figure 1.



1 Tapping Screw

L-SB-0055-13



# Front Wheel Opening Extension Pad Installation During PDS


## Installation Procedure (Continued)

 Place the left front wheel opening extension pad in position. Using the 2 original self-tapping screws and 1 of the provided self-tapping screws, install the extension pad by tightening the 3 self-tapping screws as shown in Figure 2.

#### NOTE

There is a distinguishable mark on each pad that identifies the right and left side.

Figure 2.



1 Tapping Screw

3. Repeat steps 1 and 2 to install the right front wheel opening extension pad.