

Tech Tips

TT 37-11-05


Date: June 24, 2011

All Models with DSG (02E) Transmission – Measure Value Block Request

January 25, 2013: UPDATE to information.

If a request has been made for several MVBs from a DSG transmission, the selection for “Read measured values for obligation to report” can be selected. This function will retrieve all of the MVBs from the transmission which can be attached to a VTA ticket. This selection is available under Guided Functions or GFF when using VAS-PC, as shown below.

When using ODIS, there is no selection to read measured values for obligation to report. Instead, right click on the transmission control unit on the control modules screen, select Guided Functions and Read Measured Values. Use the Select All function to record all listed values, and then save this information to attach to the VTA case.





Service Information
