



Countries:	CANADA, UNITED STATES	Document ID:	IK1200422
Availability:	ISIS, Bus ISIS, FleetISIS	Revision:	5
Major System:	ENGINES	Created:	7/27/2009
Current Language:	English	Last Modified:	5/23/2013
Other Languages:	Français , Español ,	Author:	
Viewed:	17828		

[Less Info](#)

Hide Details

Coding Information

Copy Link	Copy Relative Link	Bookmark	Add to Favorites	Print	Provide Feedback	Helpful	Not Helpful
		 View My Bookmarks				 4286	 1816

Title: How to Reset the Service Interval (Oil Change) Light with MaxxForce Engines

Applies To: All Maxxforce engines

DESCRIPTION

You cannot reset the service interval (oil change) light using the Electronic Service Tool. You must follow the procedure below.

PROCEDURE

1. Set parkbrake
2. Turn the key on
3. Turn the cruise on
4. Turn the cruise off
5. Turn the cruise on
6. Very rapidly push the resume switch four times and then hold down on the fifth time for four seconds.
7. The "Change Oil" message should clear from the odometer window.
8. The operation from the time the cruise is turned on for the second time to the fifth activation of the resume switch **must take place within six seconds**. If you fail to reset the

message then repeat the process.

Resetting using DLC Fleet Tool

1. If you do not have the DLC Fleet tool on your EZ-Tech then please check the IKnow article [IK2600074](#) for general instructions on how to use tool and how to get it.

Note: The DLC Fleet Tool does NOT work with 2010 emissions compliant engines

2. Open Fleet tool



3. In the Service Interval section reset the light.

Hide Details	Feedback Information
	Viewed: 17827
	Helpful: 4286
	Not Helpful: 1816
No Feedback Found	

Copyright © 2013 Navistar, Inc.