

# Rear Wheel Opening Extension Pad Installation

**Service Category** General

**Section** Pre-Delivery Service

**Market** USA

Toyota Supports  
 ASE Certification 

## Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2014	Prius PHV	

## Introduction

The Rear Wheel Extension Pads are located in the luggage compartment at the assembly plant to avoid damage in transit. Install the Rear Wheel Extension Pads on the vehicle during Pre-Delivery Service (PDS) using the following procedure.

## Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	–	–	–	–

## Pad Contents

- Rear Wheel Extension Pads (Left and Right)
- 2 plastic clips
- 2 self-tapping screws

## Rear Wheel Opening Extension Pad Installation

---

### Installation Procedure

**HINT**

Use the same procedure for the Left and Right Pads.

1. Install the left rear wheel extension pad with the clip.
2. Install the self-tapping screw.

Figure 1.

