

1 3 10-13



Service Information Bulletin

SUBJECT	DATE
Draining the Fuel System Using J-48710 Prior to Repairs	March 2013

Additions, Revisions, or Updates

Publication Number / Title	Platform	Section Title	Change
DDC-SVC-MAN-0082	EPA10/ GHG14 DD Platform	Draining the Fuel System Using J-48710 Prior to Repairs - Two-Filter System	Step added to beginning of the procedure to remove the fuel fill cap. Another step added at the end of the procedure to install fuel fill cap.
	DD Platform - All Years	Draining the Fuel System Using J-48710 Prior to Repairs - Three-Filter System	



13400 Outer Drive, West, Detroit, Michigan 48239-4001
 Telephone: 313-592-5000
www.demanddetroit.com

2 Draining the Fuel System Using J-48710 Prior to Repairs - Two-Filter System

Drain the fuel system as follows:



WARNING: PERSONAL INJURY

To avoid injury, never remove any engine component while the engine is running.

NOTICE: DO NOT remove the return line from the fuel filter module.

1. Remove the fuel feed line from the fuel filter module.
2. Remove the fuel tank fill caps.
3. Install J-48710 fuel pressure test kit onto the fuel feed port at the fuel filter module.
4. Use regulator and adjust the system pressure to 50 psi.
5. After one to two minutes the system should be drained of fuel.
6. Remove test equipment and install the fuel tank fill caps.

3 Draining the Fuel System Using J-48710 Prior to Repairs - Three-Filter System

Drain the fuel system as follows:



WARNING: PERSONAL INJURY

To avoid injury, never remove any engine component while the engine is running.

NOTICE: DO NOT remove the return line from the fuel filter module.

1. Remove the fuel feed line from the fuel filter module.
2. Remove the fuel tank fill caps.
3. Install J-48710 fuel pressure test kit onto the fuel feed port at the fuel filter module.
4. Use regulator and adjust the system pressure to 50 psi.
5. After one to two minutes the system should be drained of fuel.
6. Remove test equipment and install the fuel tank fill caps.