

# **Technical Bulletin**

Model(s)	Year(s)	Eng. Code(s)	Trans. Code(s)	VIN Range From	VIN Range To
All (Except Routan)	2014	All	All	All	All

#### **Condition**

91 13 23 November 7, 2013 2035473

Infotainment Worksheet (U.S. Only)

## **Technical Background**

This bulletin provides a document that will allow more detail to be provided for repairs related to the Infotainment System (radio, navigation, Bluetooth, telephone systems, etc.). This document must be completed any time a repair is performed to the Infotainment System. Completed forms must be submitted to Infotainment@vw.com.

Because of advanced and frequently changing technology, it is critical that detailed information is provided in order to better understand issues related to Infotainment.

One or more of the following symptoms are possible, but not limited to:

- Poor AM/FM/Satellite radio reception.
- Poor sound quality.
- Inability/difficult to pair phones, phone loses pairing.
- · Navigation system malfunctions or is inoperative.
- · Radio or Navigation display issues.
- Poor sound quality during phone calls.
- CD player/changer malfunctions or is inoperative.
- Voice command(s) malfunctions or is inoperative.

### **Production Solution**

Not applicable.



# **Technical Bulletin**

#### **Service**



Refer to Elsa for other Technical Bulletins that may apply to specific vehicles with customer complaints related to the Infotainment System. These Technical Bulletins provide important information about vehicle and/or component specific issues.

If diagnosis leads to the repair or replacement of one or more component(s) in the Infotainment System, it will be necessary to complete the Infotainment Worksheet.

The Infotainment Worksheet must be included with the part return in addition to submitting the completed form to Infotainment@vw.com.

Format the email subject line to contain only the VIN, one space, followed by the dealer code.

**EXAMPLE:** 1VW3PXXXXXXXX 402XXX

If a repair or replacement is performed to one or more component in the Infotainment System, the Infotainment Worksheet <u>must be</u> completed in its entirety. If any of the components replaced during the repair are requested to be returned to the Warranty Parts Return Center (WPRC) all documentation including a printed copy of the completed Infotainment Worksheet must be included with the part return in addition to submitting the completed form to Infotainment@vw.com.

## **Warranty**

Information only.

## **Required Parts and Tools**

No special parts required.

No special tools required.

### **Additional Information**

All part and service references provided in this Technical Bulletin are subject to change and/or removal. Always check with your Parts Dept. and Repair Manuals for the latest information.





Das Auto.

Dealer Name							Date				
Dealer Code							Claim or R.O. #				
Technician							Removed Part #				
V.I.N.							Removed Serial #				
Fault Occurs When?	(Mark all that apply)			apply)		Fault Occurs Whe		?	Fault Deta	nils	
Always			Inte	ermittent		Anywhere		Time			
Engine Running			Sin	gle Time		City		Date			
Engine Off			At	Start-Up		Rural		Approx. address			
Accessory	Other			Mountains		Approx. Temp					
Extended Driving		How Long?			Rough Roads		Other	,			
Duration of concern					-						
Problem is:	Rep	Reproducible				Intermittent (give details)					
Detailed Problem Description (check all that apply)											
Reception		, ,		1							
AM		Poor		None		Intermittent (give details)					
FM	Poor None			Intermittent (give details)							
HD		Poor		None		Intermittent (give det	ails)				
Radio Station or Stations:											
Satellite Radio: Note subscr	iption ι	under "Addi <b>1</b>	itional	Notes"		Unit Functions		Ī			
No signal or Linking						No sound		Modes:	Equipped with A	AMP?	
No Sat				Slow Response - Touch-Screen		When:	Command(s)?				
No Station List				Slow Response - Button		When:	Button(s)?	Button(s)?			
Activation					Reboots		When:				
Other (Describe)				Locks Up\Freezes		When:					
CD Discount (Change and						Locked in Safe Mode		Radio Safe Code:			
CD Player/Changer		1				Will not turn on					
Won't eject CD(s)				Display Appearance		Where:					
Won't accept CD(s)				No Illumination		Where:					
CD Skips				Rear View Camera			<u> </u>				
Abnormal noise				Blowing Fuse  Media Device		Fuse Number:	External device connected?				
Other (specify details)						None or Loses Connection		1			
						Skips tracks	<del>                                     </del>				
Radio Controls						Abnormal noise					
Sticking		1				Other (specify details)					
Falling Off/Missing						Device Model					
Knob hard to turn						Device Sofware Level					
Touch-Screen						Navigation (If Equipped)					
Other (specify details)						Improper vehicle location					
Telephone						Requesting DVD			Map	Software	
On compatibility List						Incorrect Directions			<del> </del>	<del>-   </del>	
Make & Model		ı				Other (specify details)					
Phone SW at latest?	Level:			Map Missing Information							
Carrier						(Specify location if known)					_
Pairing		Will Not 0	Conne	ct							
<u> </u>		Loses Cor									
Sound Quality		What par									
Dropping calls		villat pai	-y:								
Other (specify details)											