



SERVICE BULLETIN

Classification: EL12-001	Reference: NTB13-006	Date: June 17, 2013
-----------------------------	-------------------------	------------------------

2009-2013 MAXIMA; STEERING WHEEL SWITCH SERVICE PARTS

APPLIED VEHICLES: 2009-2013 Maxima (A35)

SERVICE INFORMATION

If you confirm there is a need to replace the steering wheel switches on an Applied Vehicle for any reason:

- Do not replace the driver air bag module. The steering wheel switches are now available as a separate service part.
- Refer to the Service Procedure in this bulletin for steering wheel switch removal and installation instructions.



Steering Wheel Switch Service Part

Nissan Bulletins are intended for use by qualified technicians, not 'do-it-yourselfers'. Qualified technicians are properly trained individuals who have the equipment, tools, safety instruction, and know-how to do a job properly and safely. NOTE: If you believe that a described condition may apply to a particular vehicle, DO NOT assume that it does. See your Nissan dealer to determine if this applies to your vehicle.

PARTS INFORMATION

DESCRIPTION	PART NUMBER	QUANTITY
Switch Assy-ASCD, Steering	Reference an electronic parts catalog (FAST or equivalent) for the part number applicable to your vehicle	1
Machine Screw	01431-0006U	4
Bolt (for driver air bag module)	01121-0030U	2

CLAIMS INFORMATION

Please refer to the Online Warranty Flat Rate Manual.

SERVICE PROCEDURE

IMPORTANT: Follow all cautions, warnings, and notes in the Electronic Service Manual (ESM) when working on or near a Supplemental Restraint System (SRS), such as an airbag.

1. Write down all radio station presets.

Presets	1	2	3	4	5	6
A						
B						
C						
SAT						

2. Disconnect both battery cables, negative cable first.
3. After disconnecting the battery cables, wait at least three minutes before proceeding with step 4.

4. Remove the Driver Air Bag Module.
 - Refer to section **SR, Driver Air Bag Module > Removal and Installation** in the applicable ESM for removal instructions.
5. Disconnect the horn connector. See Figure 1.
6. Using a suitable tool, gently pry open the three (3) harness retaining clips and release the harness. See Figure 1.




Figure 1

7. Remove the four (4) steering wheel switch screws.




Figure 2

Figure 3

8. Separate the steering wheel switches from the driver air bag module.

9. Attach the new steering wheel switches to the driver air bag module.



Figure 4

10. Install the four (4) new steering wheel switch screws listed in the Parts Information section. See Figures 2 and 3, above.

- DO NOT overtighten.

11. Confirm there are no gaps between the driver air bag module and the steering wheel switches.




Figure 5

12. Route the harness through the three (3) retaining clips and close the retaining clips.

13. Reconnect the horn connector.




Figure 6

14. Reinstall the Driver Air Bag Module.

- Refer to section **SR, Driver Air Bag Module > Removal and Installation** in the applicable ESM for installation instructions.
- For instructions on how to install the direct-connect SRS connectors, refer to section **SRC, SRS Air Bag System > Direct-connect SRS Component Connectors** in the applicable ESM.

15. Reconnect the battery cables, negative cable last.

16. Perform SRS operation check.

- Refer to section **SRC, On Board Diagnostic (OBD) System > SRS Operation Check** for instructions.

17. Reset the radio station presets.

