
2014 Volkswagen *Beetle* Maintenance Schedule For USA 2.5L Engine



												-
Miles	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
Airbag system: Perform visual inspection (Every 1 year regardless of mileage)	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *
Air filter element and snow filter: Replace and clean housing (Every 6 years regardless of mileage)						7, *						7, *
Battery: Check		Х		X		Х		Х		Х		X
Body: Visual inspection for corrosion				X				Х				Х
Brake pads: Check thickness and brake disc condition. Look for contact pattern and corrosion of brake discs (front and rear)	Х		Х		x		X		х		х	
Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition front and rear. Look for contact pattern and corrosion of brake discs, and check brake fluid level subject to abrasion		x		x		x		x		x		x
Brake fluid and clutch unit: Change fluid (Every 3 years regardless of mileage and every 2 years after)			4, *		4, *		4, *		4, *		4, *	
Coolant level and frost protection: Check				Х				Х				Х
CV joints: Check for leaks and damage				Х				Х				Х
Door checks and mounting pins: Lubricate				X				Х				X
Dust and pollen filter: Replace (Every 2 years regardless of mileage)		2, *		2, *		2, *		2, *		2, *		2, *
Engine: Change oil and replace oil filter	Х	Х	Х	X	X	Х	Х	Х	X	X	Х	Х
Engine and engine compartment components: Check (from above) for leaks and damage				x				х				x
Engine and engine compartment components: Check (from below) for leaks and damage, check transmission, final drive, and drive shaft boots				x				х				x
Exhaust system: Check for leaks, damage and secure fittings				Х				Х				Х
Headlights: Check adjustment				Х				Х				Х
Interior lighting and glove box lights, cigarette lighter / power outlets, horn, and all warning lamps: Check				x				x				x

2014 Volkswagen *Beetle* Maintenance Schedule For USA 2.5L Engine



						1			Г — Т		1	1
Miles	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
Lighting: Front and rear lights, luggage compartment lighting, turn signals, hazard warning lights: Check				x				x				x
Power steering: Check oil level				Х				X				X
Rear window: Check cleaning nozzle functionality (if applicable)	Х	X	Х	X	Х	Х	Х	Х	Х	Х	Х	X
Ribbed belt: Check condition (if applicable)				X				Х				Х
Service interval display: Reset	Х	X	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
Service sticker: Enter the date of the next service on the service sticker and apply to the driver's side door pillar	x	x	x	x	x	x	х	x	x	x	x	х
Spark plugs: Replace				6, *				6, *				6, *
Sunroof and panoramic sunroof: Check, clean, and lubricate (if applicable)				Х				X				Х
Sunroof: Open sunroof and check front water drains and clean if necessary (if applicable)				x				x				x
Test drive: Check braking, kickdown, steering, electrical, heating and ventilation systems, air conditioning, handling, and parking brake				x				x				x
Tie rod ends: Check for excessive play and looseness, check boots				X				X				X
Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare)		x		x		х		x		x		x
Tires: Rotate front to rear	X	X	Х	Х	X	X	Х	X	X	X	X	Х
Tire mobility kit: Check and observe expiration date on the tire filler bottle (Every 2 years regardless of mileage)		3, *		3, *		3, *		3, *		3, *		3, *
Tire mobility kit: Replace tire filler bottle (Every 4 years regardless of mileage)				5, *				5, *				5, *
Transmission: Automatic (non DSG): Change fluid					Х					X		
Underbody sealant: Inspect for damage				Х				Х				Х
Windshield washers, headlight cleaning system, and wiper blades: Check for damage and function, Check fluid level and add if necessary	x	x	x	x	x	x	х	x	x	x	x	x

2014 Volkswagen <i>Beetle</i> Maintenance Schedule For USA 2.5L Engine												
Miles	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
* Carefree Maintenance Program - Time dependent items will be incl	luded	in scho	eduled	maint	enanco	e inter	vals if	applica	able			
1. Every 1 year, regardless of mileage: Perform visual check of airbag s	system											
2. Every 2 years, regardless of mileage: Dust and pollen filter: Replace (if applicable)												
3. Every 2 years, regardless of mileage: Tire filler bottle in the tire mobility kit: Check (observe expiration date) (if applicable)												
4. At the 3 year mark, then every 2 years regardless of miles driven: Brake fluid and clutch unit: Replace fluid												
5. Every 4 years, regardless of mileage: Tire filler bottle in the tire mobility set: Replace (Observe expiration date)												
6. Every 6 years regardless of mileage: Replace spark plugs												
7. Every 6 years regardless of mileage: Air filter element and snow filter: Replace element and clean screen and housing (if applicable)												
© 2013 Volkswagen Group of America, Inc.												
All rights reserved. Information contained in this document is base to the copyright and other intellectual property rights of Volkswage rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval s mechanical, photocopying, recording, or otherwise, nor may these expressed written permission of the publisher. Posted: June 2013	en Gro systen	up of A n, or tr	Americ ansmit	a, Inc. tted in	, its af any fo	filiateo orm or	l comp by any	oanies / mear	and its	s licen ctronic	sors. A ;,	•