

SB-10052480-1835

Countries:		Document ID:	IK0800425
Availability:		Revision:	0
Major System:	ELECTRICAL SYSTEM	Created:	5/13/2013
Current Language:	English	Last Modified:	5/29/2013
Other Languages:	NONE	Author:	Chris Moody
Viewed:	35		

[Less Info](#)

Hide Details

Coding Information

Copy Link	Copy Relative Link	Bookmark	Add to Favorites	Print	Provide Feedback	Helpful	Not Helpful
		 View My Bookmarks				 1	 0

Title: Auto Start/Stop Feature Issue**Applies To: ProStar with Body Controller Feature 595BVG****DESCRIPTION**

Customer may state the auto start stop will start the engine and then within a few minutes the engine will shut down.

They may also mention the "Idle shutdown light" in the gauge cluster comes on just before the engine shuts down.

If the vehicle in question has feature code 595BVG in the body controller follow the below repair procedure to install feature code 595BNR.

REPAIR PROCEDURE

If the customer has the above concern, perform the repair procedure.

[Feature change procedure](#)

If feature code 595BNR is installed and the customer complains of extended runtime, follow the parameter change procedure to change the battery high voltage trip point.

[Parameter change procedure](#)

If there are any further concerns after the parameter change, please open a case file.

Hide Details

Feedback Information

Viewed:	34
Helpful:	1
Not Helpful:	0
No Feedback Found	