

Reference	SSM65797
Models	F-TYPE / X152
Title	Main Volume Knob / Radio Power Button Operation Explained
Category	Electrical
Last modified	06-Jun-2013 00:00:00
Symptom	207000 Entertainment Systems
Content	<p><u>Concern</u> <i>Only</i> when reverse is selected, the main volume control knob / radio power button near the shifter, does not operate. Radio and or park distance volume cannot be adjusted from the main volume control knob. Also, the radio power button will not switch the Radio off or on when reverse is selected.</p> <p><u>Cause</u> Currently this is the intended design operation, which limits the customer from fully muting or turning off the park distance volume. Volume control for either the radio or the park distance tones can still be adjusted from the steering wheel volume control switches to limit the or raise the volume of either system.</p> <p><u>Correction</u> At this time the vehicle is operating as designed. No further diagnosis is necessary.</p>