

Installation of Towing Wire Harness Connector During PDS

Service

Category General

Section

Pre-Delivery Service

Market USA



Applicability


YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION	
2015	LX570		

Introduction

The towing wire harness connector set (contains towing wire harness connector assembly and 2 bolts) is loaded in the vehicle at the assembly plant.

Use the following procedure to install the towing wire harness connector to the vehicle during Pre-Delivery Service (PDS).

Figure 1.



1 Towing Wire Harness

Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	-	=	-	=




Installation of Towing Wire Harness Connector During PDS

Installation Procedure

- 1. Connect the towing wire harness connectors.
 - A. Remove the water resistant caps from the 2 frame wire harness connectors.
 - B. Connect the 2 frame wire harness connectors and 2 towing wire harness connectors.

Figure 2.

August 28, 2014



2. Install the towing wire harness assembly bracket to the frame bracket with the 2 bolts.

Torque: 19.5 N·m (199 kgf·cm, 14 ft·lbf)

Figure 3.

