



INSTRUCTION TO SERVICE

ITS: 5694	
SECTION:	420 Body AP EXT
WRITTEN BY:	Kevin Robinson
SUBJECT:	Remove Wiper Relay Module

ITS5694

THIS DOCUMENT AND THE CONTENTS DISCUSSED HEREIN ARE THE CONFIDENTIAL AND PROPRIETARY INFORMATION OF NEW FLYER INDUSTRIES CANADA ULC AND NEW FLYER OF AMERICA INC. AND ARE DISCLOSED BY NEW FLYER IN CONFIDENCE. THIS DOCUMENT AND THE CONTENTS HEREIN ARE NOT TO BE DISCLOSED BY THE INTENDED RECIPIENT WITHOUT THE PRIOR WRITTEN AUTHORIZATION OF NEW FLYER. ANY UNAUTHOIZED DISCLOSURE, REPRODUCTION OR OTHER DISTRIBUTION OF THIS DOCUMENT OR INFORMATION IS STRICTLY PROHIBITED AND MAY RESULT IN ACTION BEING TAKEN AGAINST THE PARTY MAKING THE UNAUTHORIZED DISCLOSURE. THIS DOCUMENT AND ALL COPIES HEREOF MUST BE RETURNED TO NEW FLYER UPON REQUEST.

PROCEDURE:

1. Turn the main battery disconnect switch to the “OFF” position.
2. Remove the dash panel.
3. Locate the wiper relay module. Refer to Figure 1.
4. Unplug the connectors from either side of the module.
5. Remove and discard the module, mounting bracket, and hardware.




Figure 1: Wiper relay module as seen from the back of the driver's dash

6. Attach the two loose harnesses together and secure in place against vibration, etc.
7. Re-install the dash panel.
8. Turn the main battery disconnect switch to the “ON” position.
9. Run test to make sure wipers are working correctly. Repair as required.
10. Remove all tools and debris from the bus and return to service.



NEW FLYER

LABOUR ESTIMATE

	Operation	Men	Hours	Labour Time M X HR
1	Remove wiper relay module.	1	1.0	1.0

KIT 6411830 - PARTS REQUIRED

Item	Part Number	Description	Qty. per Coach	Units	Notes
1	NPN	Cable ties	A/R	EA	As Required