



Countries: CANADA, UNITED STATES, PUERTO RICO
Availability: ISIS
Major System: CLUTCH
Current Language: English
Other Languages: [Français](#), [Español](#),
Viewed: 2033

Document ID: IK1100004
Revision: 2
Created: 10/27/2010
Last Modified: 3/12/2014
Author: Matthew Boyer

[Less Info](#)

Hide Details

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 462	Not Helpful 443
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	---------------------------	-------------------------------

Title: Clutch Linkage Rattle in Transtar,Prostar and Lonestar Truck 07 Or Newer

Applies To: Transtar Prostar Lonestar

DESCRIPTION

Driver will hear a rattle under the cab when under a heavy load. Worse when lugging the engine.

INFORMATION

Part #	Description	Qty.
3836802C95	Transtar Linkage with IBB	1
3867630C92	Prostar Lonestar linkage with IBB	1
3839857C94	Prostar Lonestar with Cummins ISX	1

TROUBLESHOOTING

1. Test drive and confirm issue.
2. Place foot lightly on the pedal while the issue is occurring and see if it reduces the noise.
3. Inspect for loose parts or hitting brackets or motor mount.

RESOLUTION

Install the correct linkage from the information list and test drive to confirm issue is resolved.

Hide Details

Feedback Information

Viewed: 2032
 Helpful: 462
 Not Helpful: 443

No Feedback Found