



Countries:	CANADA, UNITED STATES, PUERTO RICO	Document ID:	IK1600061
Availability:	ISIS	Revision:	1
Major System:	CAB / SLEEPER / HOOD	Created:	10/12/2007
Current Language:	English	Last Modified:	3/10/2014
Other Languages:	NONE	Author:	Patrick Gotschall
Viewed:	421		

[Less Info](#)

Hide Details


Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 103	Not Helpful 107
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	---------------------------	-------------------------------

Title: Door Wind Noise on 5000 and 9000 models built between 1/1/2000 and 1/1/2007

Applies To: 9000 & 5000

1. Clean door lip to remove all grease & dirt
2. Cut 5 foot section of "D" seal (seal can be obtained from local body shop supply house it is approx 5/8" wide and 1/2" tall)
3. Remove strip from "D" seal and install on door starting at top of hinge area to just past rear radius
4. Close door and check that seal can be seen in gap and that it is compressed





 Hide Details

Feedback Information

Viewed: 420

Helpful: 103

Not Helpful: 107

No Feedback Found

Copyright © 2014 Navistar, Inc.