



Countries: AUSTRALIA, BRAZIL, CANADA, UNITED STATES, PUERTO RICO, SOUTH AFRICA
Document ID: IK0800014
Availability: ISIS, Bus ISIS, FleetISIS **Revision:** 4
Major System: ELECTRICAL SYSTEM **Created:** 2/22/2007
Current Language: English **Last Modified:** 2/10/2014
Other Languages: [Français](#), [Español](#), **Author:** Chris Moody
Viewed: 2030

[Less Info](#)

Hide Details

Coding Information

Copy Link	Copy Relative Link	Bookmark	Add to Favorites	Print	Provide Feedback	Helpful	Not Helpful
		 View My Bookmarks				 411	 458

Title: City Horn Blows When Driver Shuts off Truck and Walks Away

Applies To: NGV trucks with ESC or Body Controller

Complaint:

City horn chirps when driver shuts off truck and walks away.

Resolution:

Check programing in ESC/Body controller for park brake alarm feature code 0595328 or 595AZV.

If one of these codes is installed and you haven't set the parking brake, this is normal. With this code set, the driver must set the parking brake **before** turning the key off or the horn will sound to remind them to set the parking brake. See below for operation.

Feature Description

This feature shall provide an external audible alarm that uses the electric city horn. The Park Brake Alarm shall sound when the trucks park brake has not been applied, the ignition is turned off, and a door is opened.

The Park Brake Alarm shall stop after a specified amount of time, the key is no longer in the off position, or after the door is closed and re-opened. If the door remains open for longer than a specified amount of time (after closing and re-opening it), the Park Brake Alarm will sound again.

The Park Brake Alarm shall temporarily stop sounding for a specified amount of time if the brake pedal is depressed.

 Hide Details

Feedback Information

Viewed: 2029

Helpful: 411

Not Helpful: 458

No Feedback Found

Copyright © 2014 Navistar, Inc.