



Countries:	BRAZIL, CANADA, UNITED STATES, PUERTO RICO	Document ID:	IK1200073
Availability:	ISIS, FleetISIS	Revision:	4
Major System:	ENGINES	Created:	3/5/2007
Current Language:	English	Last Modified:	2/5/2014
Other Languages:	Portuguese ,	Author:	Jon Pierce
Viewed:	898		

[Less Info](#)

Hide Details

Coding Information


Copy Link	Copy Relative Link	Bookmark	Add to Favorites	Print	Provide Feedback	Helpful	Not Helpful
		 View My Bookmarks				 200	 235

Title: DTC 242 or VSS Codes in Cummins

Applies To: All International Trucks with Cummins Engines and Automatic Transmissions

On trucks built with automatic transmissions and Cummins engines, and engine is setting 242 fault code or getting other VSS fault codes. Switch Vehicle speed sensor type from Magnetic to [DataLink-Tailshaft](#).

You must also remove the speed signal wires from pins 27 and 36 of the chassis connector at the engine ECM.



[Hide Details](#)**Feedback Information**

Viewed: 897

Helpful: 200

Not Helpful: 235

No Feedback Found

Copyright © 2014 Navistar, Inc.