



Countries:	CANADA, UNITED STATES, PUERTO RICO	Document ID:	IK1300051
Availability:	ISIS, FleetISIS	Revision:	5
Major System:	TRANSMISSION	Created:	12/10/2007
Current Language:	English	Last Modified:	4/28/2014
Other Languages:	Français , Español ,	Author:	Matthew Boyer
Viewed:	565		

[Less Info](#)

Hide Details

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 174	Not Helpful 82
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	---------------------------	------------------------------


Title: Circuit and Installation Diagrams For 5000i Models With the Allison Gen 4 HD Transmission


Applies To: Circuit and Installation Diagrams For 5000i Models With the Allison Gen 4 HD Transmission

DESCRIPTION


The following pages are the Installation diagrams for the transmission wiring, accumulator (where used), shift towers, and wiring diagrams as installed in the 5000i Model Series assembled after April 2, 2006.

CIRCUIT DIAGRAMS





**WITH PUSH
BUTTON SHIFT**



- [Circuit diagram 1](#)
- [Circuit diagram 2](#)

OTHER RESOURCES

- [SFN 06-31](#)

 Hide Details

Feedback Information

Viewed: 564
Helpful: 174
Not Helpful: 82

No Feedback Found