



**Countries:** AUSTRALIA, BRAZIL, CANADA, COLOMBIA, UNITED STATES, PUERTO RICO, SOUTH AFRICA

**Document ID:** IK1900023

**Availability:** ISIS

**Revision:** 5

**Major System:** ACCESSORIES

**Created:** 7/24/2007

**Current Language:** English

**Last Modified:** 7/23/2014

**Other Languages:** [Français](#), [Español](#)

**Author:** Chris Moody

**Viewed:** 1520

[Less Info](#)

Hide Details

Coding Information

Copy Link	Copy Relative Link	Bookmark	Add to Favorites	Print	Provide Feedback	Helpful	Not Helpful
		 <a href="#">View My Bookmarks</a>				 142	 134

**Title: Bad Diode in Bunk A/C Switch could Cause Failure of Front A/C Control on 9000 Models**

**Applies To: All 9000's w/ Bunk A/C controls**

**DESCRIPTION**

If you run into a 9000 truck and the HVAC control head keeps going bad. You probably need to change the bunk A/C switch. Changing this switch will replace the diode which is probably causing your problem.

Hide Details

Feedback Information

Viewed: 1519
Helpful: 142
Not Helpful: 134
No Feedback Found

Copyright © 2014 Navistar, Inc.