

<b>Reference</b>	SSM71960
<b>Models</b>	Range Rover Evoque / L538
<b>Title</b>	L538 Door Lock Cap Cover - Loose Adrift
<b>Category</b>	Body
<b>Last modified</b>	04-Sep-2014 00:00:00
<b>Symptom</b>	112000 Latches/Locks & Security
<b>Attachments</b>	
<b>Content</b>	<p><u>Issue:</u> Door lock cap cover is either loose or adrift.</p> <p><u>Cause:</u> Possible breakage on fitment</p> <p><u>Action:</u> Standardised fitting procedure introduced.</p> <ol style="list-style-type: none"><li>1. First the top two tabs on the lock cover need to be inserted into the top two slots in the door lock gasket, in a downward direction.</li><li>2. Once those are fully inserted, the lock cap can be pushed towards the door to engage the lower tab.</li></ol>