

<b>Reference</b>	SSM71977
<b>Models</b>	Range Rover / L405 Range Rover Sport / L494 Range Rover Evoque / L538
<b>Title</b>	Surround Camera Blue Screen
<b>Category</b>	Electrical
<b>Last modified</b>	11-Sep-2014 00:00:00
<b>Symptom</b>	206000 Warning Indicators
<b>Attachments</b>	Copy of When MR camera is disconnected (1).mp4 Copy of When RV camera is disconnected (4).mp4

**Content**Issue

This SSM is being released to clarify the function of the Surround Cameras when dealing with customers complaints of BLUE SCREEN and due to cameras being replaced when they are not faulty.

Action

Should you have a vehicle exhibiting this condition please refer to the following repair guide lines. See attachments for visual aid.

The Rear View camera is linked with the Front right camera.

If the Rear View camera is faulty (it will permanently be displayed Blue) the Front Right will flicker three times on initial switch-on. And visa-versa if the Front Right camera is faulty.

Therefore only the camera that is permanently displayed Blue requires replacing

The Mirror Right camera is linked with the Front Left camera.

If the Mirror Right camera is faulty (it will be permanently displayed Blue) the Front Left will flicker three times on initial switch-on. And visa-versa if the Front Left camera is faulty.

Therefore only the camera that is permanently displayed Blue requires replacing