

# Front Wheel Opening Extension Pad Installation during PDS

Service

**Category** General

Section Pre-Delivery Service Market USA



## **Applicability**

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2016	RC F, RC200T, RC300, RC350	

#### Introduction

The front wheel opening extension pad set (right and left front wheel opening extension pads, 6 Self-tapping Screws) is loaded in the luggage compartment at the assembly plant to avoid damage in transit.

Install the front wheel opening extension pads on the vehicle during Pre-Delivery Service (PDS).


## **Warranty Information**

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	_	_	_	_

### **Installation Procedure**

 Install the right and left front wheel opening extension pads with the 6 Self-tapping Screws.

Figure 1.



1 Self-tapping Screw