



Countries: BAHAMAS, BOLIVIA, BELIZE, CANADA, CHILE, TAIWAN, COLOMBIA, COSTA RICA, DOMINICAN REPUBLIC, ECUADOR, EL SALVADOR, TRINIDAD AND TOBAGO, UNITED STATES, URUGUAY, VENEZUELA, MEXICO, ARUBA, NICARAGUA, PERU, PUERTO RICO, Curaçao, GUAM, GUATEMALA, GUYANA, HAITI, HONDURAS, JAMAICA, KOREA, SOUTH KOREA, PANAMA

Availability: ISIS, Bus ISIS, FleetSIS, Body Builder

Major System: ENGINES

Current Language: English

Other Languages: [Français](#), [Español](#).

Viewed: 2761

Document ID: IK1200435

Revision: 6

Created: 1/20/2010

Last Modified: 10/27/2015

Author: Jay Weston

[Less Info](#)

Hide Details

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 213	Not Helpful 221
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	---------------------------	-------------------------------

Title: EPA 2007 MaxxForce® 11 and 13 Engine Feature Documentation

Applies To: EPA 2007 MaxxForce® 11 and 13 Engines

CHANGE LOG

Dealers: Please refer to the change log text box below for recent changes to this article:

6/27/2015 - Fixed a link
7/14/2014 - All of the links were fixed.

DESCRIPTION

The following links below can be found on: [Navistar Body Builder Website](#)

- Engine Feature Documentation for all Navistar engines can be found on this site.

1. Go to: [Navistar Body Builder Website](#)
2. Click on 'Engine Feature Documentation'.
3. Click on '2007 EPA MaxxForce 11 and 13'.
- (You have found the links that are below).

These features can be configured to meet the requirements of how you use your truck.

2007 EPA MaxxForce 11 and MaxxForce 13
Cold Ambient Protection
Cruise Control
Data Plate
Driver Reward
Engine Fan Control
Engine Retarder
Engine Warning and Protection

Gear Down Protection
Password Protection
Idle ShutDown Timer
PowerTrain Protection
Progressive Shift
PTO - In Cab
PTO - Remote
Service Interval
Trip Reporting
Up-Shift Indicator
Vehicle Setup
Vehicle Speed Governor
Note: For writing most parameters - NAVISTAR® SERVICEMAXX FLEET PRO is required.

 Hide Details

Feedback Information

Viewed: 2760

Helpful: 213

Not Helpful: 221

No Feedback Found