



Countries: BAHAMAS, BOLIVIA, BELIZE, CANADA, CHILE, TAIWAN, COLOMBIA, COSTA RICA, DOMINICAN REPUBLIC, ECUADOR, EL SALVADOR, TRINIDAD AND TOBAGO, UNITED STATES, URUGUAY, VENEZUELA, ARUBA, NICARAGUA, PERU, PUERTO RICO, Curaçao, GUAM, GUATEMALA, GUYANA, HAITI, HONDURAS, JAMAICA, KOREA, SOUTH KOREA, PANAMA
Document ID: IK1900212
Availability: ISIS
Major System: ACCESSORIES
Current Language: English
Other Languages: NONE
Viewed: 941
Revision: 1
Created: 7/11/2013
Last Modified: 7/28/2015
Author: Charles Schroeder

[Less Info](#)

Hide Details

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 10	Not Helpful 2
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	--------------------------	-----------------------------

Title: Front Blower Motor Runs Briefly At Initial Power Up

Applies To: All HPV

CHANGE LOG

Please refer to the change log text box below for recent changes to this article:

07/28/2015 - Formatted Article

DESCRIPTION

On units equipped with a battery disconnect, the blower motor may turn on for a brief moment when the battery disconnect is turned on. This can also occur when the batteries are replaced, or have been disconnected.

REPAIR PROCEDURE

This is normal operation based on the internal design of the LPM. When battery power is first applied to the LPM, the LPM must reference a fixed voltage from the five volt regulator. During this period of voltage referencing the LPM will allow the blower motor to run, regardless of the control signal from the control head in the center panel.

- This will only happen the first time battery power is supplied to the LPM.
- It does not happen every time ignition power is supplied to the LPM.

Hide Details

Feedback Information

Viewed: 940
 Helpful: 10
 Not Helpful: 2

No Feedback Found