



Service Information

Diagnostic Device Hardware & Windows®

Number: VHW-15-10

Subject: VAS 5054A Diagnostic Interface – Bluetooth® & EDIC Configuration

Date: Dec. 17, 2015

Supersedes VVT-14-21 due to revised EDIC configuration processes from ODIS Service V3.0.0.

Table of Contents

Section	Page
1.0 Introduction	2
2.0 Preparation - Must Read!	2
3.0 Windows Bluetooth Configuration	3
3.1 General Information	3
3.2 Procedure	3
4.0 Diagnostic Interface (EDIC) Configuration	6
4.1 General Information	6
4.2 Procedure	6

Notes:

- Please **read these instructions carefully and in their entirety** before performing any procedures. **If you do not understand these instructions, arrange to have a qualified person perform these procedures.**
- Heed all prerequisite requirements and notes, and **follow all instruction steps in the Section order given.**
- **Discard all printed copies of this document after use.** Revised versions may be issued at any time. Always check ServiceNet for the latest version.



Service Information

1.0 – Introduction

This document describes the **VAS 5054A Diagnostic Interface wireless configuration processes** on eligible diagnostic laptop and tablet devices with Offboard Diagnostic Information System Service (**ODIS Service**) software.

Configuration takes place in the following stages:

- ☐ Configure **Bluetooth** connection in **Windows**.
- ☐ Configure **EDIC** connection software with **Softing EDIC Configuration Manager**.
- ☐ Confirm communication with **ODIS Service**.

Checkboxes are provided throughout this document to note fulfilled prerequisites and completed sections.

2.0 – Preparation

Prerequisites:

- ☐ Windows 7
- ☐ Diagnostic device must have a functional USB functions.
- ☐ Device connected to A/C power adapter and booted to Windows desktop.
- ☐ **ODIS Service V3.0.0 or higher installed.**
- ☐ ODIS Service **NOT** running.
- ☐ Diagnostic tablets mounted in base station with USB mouse and keyboard connected.
- ☐ Vehicle available.

1. Ensure the wireless operation switch is turned **ON** as applicable:



VAS 6150A

(Front panel behind handle)



VAS 6150B & VAS 6150C

(Middle right side behind WIRELESS door)



VAS 6160 & VAS 6160A

(Upper left side behind SC/EX door)

2. **Note the VAS 5054A Serial Number (S#:** from a label on back of the transmitter housing.
3. Connect VAS 5054A to a vehicle **Data Link Connector (DLC)** and **switch the ignition ON**. The blue LED on the transmitter head **must flash**.

☐ Preparation steps completed. Proceed to [Section 3.0 – Page 3](#)



Service Information

3.0 – Windows Bluetooth Configuration

3.1 – General Information

The Windows Bluetooth configuration “pairs” the VAS 5054A with the diagnostic laptop/tablet for Bluetooth (wireless) communication.

3.2 – Procedure

1. Click **Windows Start:**



2. Select **Devices and Printers:**

Devices and Printers

3. From the Devices and Printers window header (top left), select **Add a Device:**


Add a device

A list of available Bluetooth devices is displayed.

Note:

The VAS 5054A serial number shown in the following illustrations is an example only! Each VAS 5054A is assigned a unique serial number.

4. **Select/highlight** the **VAS5054** displayed. Confirm the number displayed between the < > symbols **matches the VAS 5054A serial number previously noted.**
5. Click **Next:**




(cont.)




Service Information

6. Carefully enter the **VAS 5054A serial number** as displayed (without < >) as the "pairing code":
7. Click **Next**:



8. Click **Close**:




(cont.)




Service Information

9. **Wait** a moment for the driver search and installation process to complete.
10. Return to the **Devices and Printers** window and **double-click** the newly-added **VAS5054**:



11. Select the **Hardware Tab**, and make note of the assigned **COM port number**:



Note:

The **COM port number** illustrated is **an example only!**

Each configuration is unique, so it is important to note the **COM port number** assigned during **your configuration**.

12. Close the **Properties** window.

Bluetooth Configuration steps completed. Proceed to [Section 4.0 – Page 6](#)



Service Information

4.0 – Diagnostic Interface (EDIC) Configuration


4.1 – General Information

The EDIC configuration enables data to be exchanged between the Bluetooth (wireless) functions of the VAS 5054A and the ODIS Service diagnostic software.


Configuration is performed using the **Softing EDIC Configuration Manager**.

4.2 – Procedure

1. From the Windows desktop, double click the **ODIS Service Diagnostic Interface Configuration** program icon:
2. Select the **Add a new device....** icon:



3. Confirm the conditions listed, and then click **OK**:




(cont.)




Service Information

5. Select **Enter COM port**:



4. Select the **COM Port** that matches the one noted in [Section 3.2 – Step 11](#), and then select **Next**:



Note:

The COM port number illustrated is an example only!

Each configuration is unique, so it is important to note the COM port number assigned during your configuration.

5. Confirm the highlighted VAS 5054A, and then select the **Configuration Settings** (gear) icon:




(cont.)




Service Information

6. Click the **Device** tab:



7. **If desired**, select **Enable the Buzzer** and enter a **Buzzer Time**. Then select **Apply** and **Finish** respectively:



Notes:

- The **Enable Buzzer** and **Buzzer Time** settings can be changed at any time by opening **ODIS Service Diagnostic Interface Configuration** and selecting the **Configuration Settings (gear)** icon.
- To prevent loss of communication during extended ODIS Service diagnostic sessions, we recommend the **PowerOff** function **remain disabled**.

(cont.)




Service Information

8. Select **Close**:




9. From the Windows desktop, double-click the **ODIS Service** icon:



10. Confirm that vehicle communication is established via the various **Connection Status** icons on the **ODIS Service Main / Welcome** page, and that [Starting diagnosis](#) can be initiated:

Main Page Header:



Welcome Window:



☐ EDIC Configuration steps completed.