

Tech Tip T-TT-0352-15

August 20, 2015

Combination Meter Diagnosis

USA

Vehicle Interior

Meter/Gauge/Display

14-16 MY Highlander/Highlander HV

APPLICABLE VEHICLES

2014-2016	Highlander	2014-2016	Highlander HV

CONDITION

In some cases, combination meters may automatically initialize for options detected on a specific vehicle. If a meter is exchanged between vehicles for diagnostic purposes, it may become unusable in the original vehicle.

For example, if a combination meter is removed from a vehicle not equipped with LDA (Lane Departure Alert) and temporarily installed in a vehicle equipped with LDA, it may display "CHECK LDA SYSTEM" on the multi-information display and set DTC U023A when reinstalled in the original vehicle. This condition cannot be reset, and the combination meter must be replaced.



RECOMMENDATIONS

- It is not advisable to exchange combination meters between vehicles.
- A combination meter should never be exchanged between a vehicle equipped with LDA (Lane Departure Alert) and a vehicle not equipped with LDA.
- If a combination meter is installed in a vehicle equipped with LDA, it will permanently initialize to the LDA system and cannot be used in a vehicle that is not equipped with LDA.

LINK REFERENCES

This Tech Tip does not contain any link references

Expires on

08/20/2016

© 2015, Toyota Motor Sales, USA