

Installation of Towing Wire Harness Connector During PDS

Service

Category General

Section Pre-Delivery Service Market USA



Applicability


YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION	
2016	LX570		

Introduction

The towing wire harness connector set (towing wire harness connector assembly and 2 bolts) is loaded in the vehicle at the assembly plant to avoid damage in transit.

Use the following procedure to install the towing wire harness connector to the vehicle during Pre-Delivery Service (PDS).

Figure 1.



Towing Wire Harness

(L) L-SB-0069-15 October 7, 2015 Page 2 of 2

Installation of Towing Wire Harness Connector During PDS

Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	_	-	_	-

Installation Procedure

- 1. Connect the towing wire harness connectors.
 - A. Remove the water resistant caps from the 2 frame wire harness connectors.
 - B. Connect the 2 frame wire harness connectors and 2 towing wire harness connectors.
- 2. Install the towing wire harness assembly bracket to the frame bracket with the 2 bolts.

Torque: 19.5 N·m (199 kgf·cm, 14 ft·lbf)

Figure 2.




Figure 3.

