

# 2016 CX-9 (EQUIPPED WITH POWER LIFTGATE) *POWER LIFTGATE CONTACTS GARAGE CEILING*

The Power Liftgate (PLG) fully open position can be adjusted to accommodate a garage with a low ceiling.

## PLG Fully Open Position Change:

1. Manually open the liftgate to the desired fully open position.
2. Press the power liftgate close switch for about three seconds. Two beeps are heard to indicate that the position change has been completed.

### Note:

- Adjustment can only be performed at the top half of PLG opening.
- Three rapid beeps are heard if you attempt an adjustment at bottom half of PLG travel.
- PLG fully open position can be lifted higher manually. This is normal condition used to protect PLG motor.



Power Liftgate  
Close Switch



Top half of  
PLG travel is  
adjustable

Bottom half of  
PLG travel is  
NOT adjustable

## PLG Fully Open Position Default Reset:

1. Open the liftgate.
2. Press the power liftgate close switch for about seven seconds. Three beeps are heard to indicate that the reset has been completed.

**Note:** During the seven second switch hold, ignore the two beep indicator. Continue holding the switch until you hear the three beeps.