



Tech Tips

TT 93-16-04

Date: April 29, 2016

2015-2016 eGolf 12 Volt Battery Tip

Anytime that the high voltage system on the eGolf is going to be de-energized for an extended period of time, disconnect the 12 volt battery to ensure that the 12 volt battery does not discharge and then require replacement. Even with the HV system de-energized, the 12 volt system *may* partially power up and discharge the 12 volt battery. Once the AGM style battery has been discharged, it *may* require replacement.