

	GROUP Eng	MODEL All w/1.6L GDI Engine
	NUMBER PS296	DATE February 2014
 		
SUBJECT: OCV DAMAGE WHEN INSTALLING ENGINE COVER		

When re-installing the engine cover on vehicles equipped with a 1.6L GDI engine, make sure not to apply any downward pressure in the area around the Oil Control Valve (OCV) to prevent causing damage to the valve. Clearance between the OCV and the bottom of the engine cover is minimal; therefore, dealer personnel should refrain from using excessive force when trying to ensure the engine cover is fully seated. Before installing the engine cover, make a mental note of the approximate location of the pins and apply downward pressure ONLY to the areas immediately above the pins, as shown below.

