

HONDA

Part Number	Part Description	Action
06770-S0X-A30ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-S0X-A40ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-S5A-A10ZA	AIRBAG ASSY., DRIVER *NH167L* (TAKATA)(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-S5A-A30ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-S5A-A40ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-S5A-A80ZA	AIRBAG ASSY., DRIVER *NH167L* (TAKATA)(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-S84-A11ZA	AIRBAG ASSY., DRIVER *B94L*(DARK LAPIS)	Do Not Install & Return to AHM
06770-S84-A30ZA	AIRBAG ASSY. *B94L*	Do Not Install & Return to AHM
06770-S84-A11ZB	AIRBAG ASSY., DRIVER *NH283L*(QUARTZ GRAY)	Do Not Install & Return to AHM
06770-S84-A30ZB	AIRBAG *NH283L*	Do Not Install & Return to AHM
06770-S84-A11ZC	AIRBAG ASSY., DRIVER *YR164L*(MEDIUM TAUPE)	Do Not Install & Return to AHM
06770-S84-A30ZC	AIRBAG *YR164L*	Do Not Install & Return to AHM
06770-S84-A11ZD	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-S84-A30ZD	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-S9A-A30ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-S9A-A80ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-S9A-A30ZB	AIRBAG *YR202L*	Do Not Install & Return to AHM
06770-S9A-A80ZB	AIRBAG ASSY., DRIVER *YR202L*(DARK SADDLE)	Do Not Install & Return to AHM
06770-S9A-A40ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-S9A-A90ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-S9A-A40ZB	AIRBAG *YR248L*	Do Not Install & Return to AHM
06770-S9A-A90ZB	AIRBAG ASSY., DRIVER *YR248L*(TAUPE)	Do Not Install & Return to AHM
06770-S9V-A50ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-S9V-A30ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-SCV-A30ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-SCV-A80ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-SCV-A30ZB	AIRBAG *NH361L*	Do Not Install & Return to AHM
06770-SCV-A80ZB	AIRBAG ASSY., DRIVER *NH361L*(GRAY)	Do Not Install & Return to AHM
06770-SDA-A30ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-SDA-A80ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-SDA-A30ZB	AIRBAG *YR248L*	Do Not Install & Return to AHM
06770-SDA-A80ZB	AIRBAG ASSY., DRIVER *YR248L*(TAUPE)	Do Not Install & Return to AHM
06770-SDA-A40ZA	AIRBAG *NH167L*	Do Not Install & Return to AHM
06770-SDA-A91ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-SDA-A40ZB	AIRBAG *YR248L*	Do Not Install & Return to AHM
06770-SDA-A91ZB	AIRBAG ASSY., DRIVER *YR248L*(TAUPE)	Do Not Install & Return to AHM
06780-S0X-A10ZA	AIRBAG ASSY., PASSENGER *G48L*(DARK FERN)	Do Not Install & Return to AHM
06780-S0X-A10ZB	AIRBAG ASSY., PASSENGER *NH283L*(QUARTZ GRAY)	Do Not Install & Return to AHM
06780-S0X-A10ZC	AIRBAG ASSY., PASSENGER *YR164L*(MEDIUM TAUPE)	Do Not Install & Return to AHM
06780-S0X-A70ZA	AIRBAG ASSY., PASSENGER *G48L*(DARK FERN)	Do Not Install & Return to AHM
06780-S0X-A70ZB	AIRBAG ASSY., PASSENGER *NH283L*(QUARTZ GRAY)	Do Not Install & Return to AHM
06780-S0X-A70ZC	AIRBAG ASSY., PASSENGER *YR164L*(MEDIUM TAUPE)	Do Not Install & Return to AHM
06780-S5A-A80ZA	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-S5A-A80ZB	AIRBAG ASSY., PASSENGER *YR164L*(MEDIUM TAUPE)	Do Not Install & Return to AHM
06780-S5A-A80ZC	AIRBAG ASSY., PASSENGER *YR248L*(TAUPE)	Do Not Install & Return to AHM
06780-SCA-A80ZA	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-S9A-A80ZA	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-SCA-A80ZB	AIRBAG ASSY., PASSENGER *YR202L*(DARK SADDLE)	Do Not Install & Return to AHM
06780-S9A-A80ZB	AIRBAG ASSY., PASSENGER *YR202L*(DARK SADDLE)	Do Not Install & Return to AHM
06780-SCA-A90ZA	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-S9A-A90ZA	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-SCA-A90ZB	AIRBAG ASSY., PASSENGER *YR248L*(TAUPE)	Do Not Install & Return to AHM
06780-S9A-A90ZB	AIRBAG ASSY., PASSENGER *YR248L*(TAUPE)	Do Not Install & Return to AHM
06780-S9V-A80ZB	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-S9V-A80ZC	AIRBAG ASSY., PASSENGER *YR202L*(DARK SADDLE)	Do Not Install & Return to AHM
06780-S9V-A20ZA	KIT,AS MODU*G48L*	Do Not Install & Return to AHM
06780-S9V-A80ZA	AIRBAG ASSY., PASSENGER *G48L*(DARK FERN)	Do Not Install & Return to AHM
06780-S9V-A81ZA	AIRBAG ASSY., PASSENGER *G48L*(DARK FERN)	Do Not Install & Return to AHM
06780-S9V-A81ZB	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-S9V-A81ZC	AIRBAG ASSY., PASSENGER *YR202L*(DARK SADDLE)	Do Not Install & Return to AHM
06780-S9V-A81ZD	AIRBAG ASSY., PASSENGER *NH574L*(WARM GRAY)	Do Not Install & Return to AHM
06780-S9V-A81ZE	AIRBAG ASSY., PASSENGER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
06780-SCV-A80ZA	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-SCV-A80ZB	AIRBAG ASSY., PASSENGER *NH361L*(GRAY)	Do Not Install & Return to AHM
06780-SDA-A80ZA	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-SDA-A80ZB	AIRBAG ASSY., PASSENGER *YR248L*(TAUPE)	Do Not Install & Return to AHM
06780-SDA-A90ZA	AIRBAG ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-SDA-A90ZB	AIRBAG ASSY., PASSENGER *YR248L*(TAUPE)	Do Not Install & Return to AHM
77810-S9V-A70ZA	SET,DR MO*NH574L*	Do Not Install & Return to AHM
77810-S9V-A70ZB	MOD, DRIVER *NH607L*	Do Not Install & Return to AHM
77810-S9V-A70ZC	MOD, DRIVER *YR202L*	Do Not Install & Return to AHM
77810-SCV-A40ZA	SET DR,MO*NH167L*	Do Not Install & Return to AHM
77810-SCV-A80ZA	MODULE ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77810-SCV-A40ZB	MOD, DRIVER *NH535L*	Do Not Install & Return to AHM

77810-SCV-A802B	MODULE ASSY., DRIVER *NH535L*(STEEL SILVER)	Do Not Install & Return to AHM
77810-SCV-A402C	SET DR,MO*YR355L*	Do Not Install & Return to AHM
77810-SCV-A802C	MODULE ASSY., DRIVER *YR355L*(COPPER METALLIC)	Do Not Install & Return to AHM
77810-SCV-A402D	SET DR,MOD*R166L*	Do Not Install & Return to AHM
77810-SCV-A802D	MODULE ASSY., DRIVER *R166L*(SC RED METALLIC)	Do Not Install & Return to AHM
77810-SDA-A20ZA	MOD, DRIVER *NH167L*	Do Not Install & Return to AHM
77810-SDA-A70ZA	MODULE ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77810-SDA-A202B	MOD, DRIVER *YR248L*	Do Not Install & Return to AHM
77810-SDA-A702B	MODULE ASSY., DRIVER *YR248L*(TAUPE)	Do Not Install & Return to AHM
77810-SJC-A40ZA	MOD, DRIVER *NH607L*	Do Not Install & Return to AHM
77810-SJC-A50ZA	MOD, DRIVER *NH607L*	Do Not Install & Return to AHM
77810-SJC-A80ZA	MODULE ASSY., DRIVER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
77810-SJC-A81ZA	MODULE ASSY., DRIVER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
77810-SJC-A60ZA	MOD, DRIVER *NH574L*	Do Not Install & Return to AHM
77810-SJC-A91ZA	MODULE ASSY., DRIVER *NH574L*(WARM GRAY)	Do Not Install & Return to AHM
77810-SJC-A602B	MOD, DRIVER *NH607L*	Do Not Install & Return to AHM
77810-SJC-A912B	MODULE ASSY., DRIVER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
77810-SWA-A80ZA	MODULE ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77810-SWA-A81ZA	MODULE ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77810-SWA-A70ZA	MODULE ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77810-SZT-A80ZA	MODULE ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77810-TK6-A80ZA	MODULE ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77810-TK6-A802C	MODULE ASSY., DRIVER *B157L*(DARK ROYAL BLUE)	Do Not Install & Return to AHM
77810-TK6-A802D	MODULE ASSY., DRIVER *NH643L*(LIGHT GRAY)	Do Not Install & Return to AHM
77820-SCV-A91ZA	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06780-SJC-A80ZA	AIRBAG ASSY., PASSENGER *NH574L*(WARM GRAY)	Do Not Install & Return to AHM
77820-SJC-A00ZA	MODULE ASSY., PASSENGER *NH574L*(WARM GRAY)	Do Not Install & Return to AHM
06780-SJC-A802B	AIRBAG ASSY., PASSENGER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
77820-SJC-A002B	MODULE ASSY., PASSENGER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
77820-SJC-A91ZA	MODULE ASSY., PASSENGER *NH574L*(WARM GRAY)	Do Not Install & Return to AHM
77820-SJC-A912B	MODULE ASSY., PASSENGER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
77820-SJC-A93ZA	MODULE ASSY., PASSENGER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
06770-SJC-A10ZA	AIRBAG ASSY., DRIVER *NH574L*(WARM GRAY)	Do Not Install & Return to AHM
06770-SJC-A30ZA	AIRBAG *NH574L*	Do Not Install & Return to AHM
77810-SJC-A00ZA	MODULE ASSY., DRIVER *NH574L*(WARM GRAY)	Do Not Install & Return to AHM
06770-SJC-A102B	AIRBAG ASSY., DRIVER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
06770-SJC-A302B	AIRBAG *NH607L*	Do Not Install & Return to AHM
77810-SJC-A002B	MODULE ASSY., DRIVER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
77820-SLN-A81ZA	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77820-SNA-A82ZA	MODULE ASSY., PASSENGER *NH597L*(DARK ATLAS GRAY)	Do Not Install & Return to AHM
77820-SNA-A822B	MODULE ASSY., PASSENGER *YR325L*(EARTH TAUPE)	Do Not Install & Return to AHM
77820-SNA-A822C	MODULE ASSY., PASSENGER *B157L*(DARK ROYAL BLUE)	Do Not Install & Return to AHM
77820-SNA-A822D	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77820-SNA-A70ZA	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77820-SNA-A702B	MODULE ASSY., PASSENGER *NH597L*(DARK ATLAS GRAY)	Do Not Install & Return to AHM
77820-SNA-A702C	MODULE ASSY., PASSENGER *B157L*(DARK ROYAL BLUE)	Do Not Install & Return to AHM
77820-SWA-A80ZA	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77820-TA0-A80ZA	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77820-TA0-A81ZA	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77820-TA0-A802B	MODULE ASSY., PASSENGER *NH597L*(DARK ATLAS GRAY)	Do Not Install & Return to AHM
77820-TA0-A812B	MOD, PASS *NH597L*	Do Not Install & Return to AHM
77820-TA0-A802C	MODULE ASSY., PASSENGER *YR325L*(EARTH TAUPE)	Do Not Install & Return to AHM
77820-TK6-A80ZA	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77820-TM8-A80ZA	MODULE ASSY., PASSENGER *B157L*(DARK ROYAL BLUE)	Do Not Install & Return to AHM
77820-TM8-A802B	MODULE ASSY., PASSENGER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77851-SZA-A12	MODULE ASSY., PASSENGER	Do Not Install & Return to AHM
06770-S0X-A10ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-S0X-A80ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-S9V-A00ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
06770-S9V-A01ZA	AIRBAG ASSY., DRIVER *NH167L*(GRAPHITE BLACK)	Do Not Install & Return to AHM
77810-S9V-A11ZA	MODULE ASSY., DRIVER *NH574L*(WARM GRAY)	Do Not Install & Return to AHM
77810-S9V-A112B	MODULE ASSY., DRIVER *NH607L*(DARK GRAY)	Do Not Install & Return to AHM
77810-S9V-A112C	MODULE ASSY., DRIVER *YR202L*(DARK SADDLE)	Do Not Install & Return to AHM